



The Unofficial  
**SmartCAM<sup>®</sup>**  
**Macro Command**  
**Dictionary**

Compiled by Fred Lauzus

The Unofficial **SmartCAM®** Macro Command Dictionary  
Last updated November 29, 2000

# Preface

## Introduction

This “unofficial” dictionary was created in part because the official documentation shipped with SmartCAM contains numerous instances of missing, incomplete or inaccurate descriptions of the supported functions and commands. Also, the information in the official documentation is scattered throughout various sections making it difficult rapidly locate specific items from different sections. Organizing the information in a dictionary format provides a quick reference guide for the writing, editing and debugging of macro files. It is being freely shared in the spirit of cooperation and exchange of information between the remaining dedicated SmartCAM users.

## Purpose

This dictionary is intended to supplement but not replace the various SmartCAM manuals. It is to serve as an updated macro reference source for SmartCAM macro programmers and attempts to address incorrect and incomplete entries regarding macros in the SmartCAM Customization Guide.

The commands added or amended from the SmartCAM customization Guide include but are not limited to:

AUTO_ABORT[ ]	GRP_FILT_REMOVE[ ]	PTOP[ ]
FILTER_USE[ ]	HOTSAVE[ ]	ROTATE[ ]
FIXUP_51[ ]	INTEGER:	SYSTEM_UNITS[ ]
FPATH_SET[ ]	INTPT[ ]	STRING:
GRP_FILT_ADD[ ]	MIRROR[ ]	WP_CHANGE_NAME[ ]

## Compatibility

The functions and commands listed in this dictionary are for use with SmartCAM v11.x applications but includes some obsolete yet functional commands from previous versions to aid in debugging existing macros created in those older versions. This dictionary does not include any macro commands used prior to SmartCAM v6.x applications or v3.x advanced applications.

## Disclaimer

This publication is not a product of and the author has no affiliation with SDRC. Although every attempt is made to insure the accuracy of this document, the author assumes no liability for any costs incurred by the use of this information.

## Licenses and Trademarks

SmartCAM and CAM Connection are registered trademarks of Structural Dynamics Research Corporation; SmartCAM Advanced Fabrication, SmartCAM Advanced 3-D Machining, SmartCAM Advanced Production Milling, SmartCAM Advanced Turning, SmartCAM Advanced Wire EDM, SmartCAM Customization Toolkit, SmartCAM FreeForm Machining, SmartCAM Production Fabrication, SmartCAM Production Milling, SmartCAM Production Turning, AutoCAD SmartCAM Connection, CAMCAD Standard, CNC Process Model, and Edit Plus are trademarks of Structural Dynamics Research Corporation. All other trademarks or registered trademarks belong to their respective holders.

## Conventions

The conventions in this dictionary attempt to mimic conventional dictionary formats but is applied to the SmartCAM macro language.

### NAME

(Long Name), *type*. Description. {Applications}

Note: optional

NAME[FN=\$\$, ST=##]

FN = String value

ST = Number values

Default: 0

<b>NAME</b>	The "Name", in upper case bold, is the short, cryptic name of the macro function or command as it is used within a macro.
(Long Name)	The "Long Name", in mixed case in parentheses, is the longer common language name of the macro function or command, typically referring to a menu command that may record it.
<i>type</i>	The "type", in lower case italic, Identifies if the item being described is a <i>function</i> , a <i>command</i> or <i>script</i> . A function will returns a value while a command performs an action. Script is used in demo mode to display menus, control panels and dialog boxes in the user interface.
Description	The "description" is a brief description of what the function, command or script does. For a more in depth descriptions of functionality you may need to refer to the "official" SmartCAM users manuals.
{Applications}	The "Applications", within the braces { }, is a list of SmartCAM application that the function or command is valid for. If no applications are listed of a particular function or command it can be assumed that the function or command is valid for all applications.
Note:	Optional information may be provided in addition to the description for the function or command.
NAME[FN=\$\$, ST=##]	Syntax structure and parameter list. This illustrates how the function or command should appear along with its parameters within the macro.
FN = String value ST = Number values Default: 0	Usually there is a short explanation of each of the parameters from the parameter list as well as valid options and default values.

## Designates the parameter requires a numeric value in the form of a number, numeric variable or mathematical formula.

\$\$ Designates the parameter requires a string value in the form of quoted alphanumeric characters, string variable or a string expression.

**- A -****4AXPATH[ ]**

(4 Axis Path), *command*. Creates the 5-axis polyline tool path necessary for a 4-axis machining operation. {Awedm}

4AXPATH[P1=\$\$, P2=\$\$, S1=\$\$, S2=\$\$, DS=##, OF=##, CD=##, FA=##]

P1 = Primary range start (required)

Default: None

P2 = Primary range end (required)

Default: None

S1 = Secondary range start (required)

Default: None

S2 = Secondary range end (required)

Default: None

DS = Offset amount

Default: Null

OF = Offset side

0 = Left

1 = Right

2 = None

Default: None

CD = Chordal deviation

Default: From SMF

FA = Finish amount

Default: 0

**ABS( )**

(Absolute), *function*. Returns the absolute value of a numeric expression.

ABS(numexp)

**ACOS( )**

(Arc Cosine), *function*. Returns the arc cosine value of an angle.

ACOS(numexp)

numexp = angle in degrees

**ADD\_LAYER[ ]**

(Add Layer), *command*, Adds a new layer to the process model.

ADD\_LAYER[LY=##, CO=##, ST=##]

LY = Layer (required)

New layer number

Default: None

CO = Color (required)

Valid color number

Default: None

ST = Style

0 = Solid

1 = Dotted

2 = Broken

Default: 0

**ANG( )**

(Angle), *function*. Returns the angle value of selected line or swept value of selected arc element.

**ANG(elnum)**

elnum = Element number or name

**ARC[ ]**

(Arc), *command*. Creates a full or partial arc.

ARC[XC=##, YC=##, XS=##, YS=##,  
XE=##, YE=##, XI=##, YI=##, SS=##,  
SC=##, TS=\$\$, AS=##, SE=##, TE=\$\$,  
AE=##, SI=##, TI=\$\$, DR=##, RA=##,  
LV=##]

XC = X center

Default: Null

YC = Y center

Default: Null

XS = X start

Default: Null

YS = Y start

Default: Null

XE = X end

Default: Null

YE = Y end

Default: Null

XI = X intermediate

Default: Null

YI = Y intermediate

Default: Null

SS = Start solution designator

0 = +

1 = -

2 = N/A

Default: 0

SC = Center solution designator

0 = +

1 = -

2 = N/A

Default: 0

TS = Start tangent

Arc or line element number

Default: Null

AS = Start angle

Default: Null

SE = End solution designator

0 = +

1 = -

2 = N/A

Default: 0

**TE** = End tangent  
 Arc or line element number  
 Default: Null  
**AE** = End angle  
 Default: Null  
**SI** = Intermediate solution designator  
 0 = +  
 1 = -  
 2 = N/A  
 Default: 0  
**TI** = Intermediate tangent  
 Arc or line element number  
 Default: Null  
**DR** = Direction  
 0 = CW  
 1 = CCW  
 Default: 0  
**RA** = Radius  
 Default: Null  
**LV** = Level (modal)

**ARC\_GRP[ ]**

(Arc Group), *command*. Adds or removes full and/or partial arcs to the active group.

**ARC\_GRP[AR=##, FA=##, NR=##, XR=##]**

**AR**= Add/Remove  
 0 = Add  
 1 = Remove  
 Default: None  
**FA**= Full arc  
 0 = All arcs  
 1 = Full arcs only  
 2 = Partial arcs only  
 Default: 0  
**NR**= Minimum radius  
 Default: All arcs less than **XR**  
**XR**= Maximum radius  
 Default: all arcs greater than **NR**

**ARC\_PROF[ ]**

(Arc Profile), *command*. Creates an arc as part of a continuous profile.

**ARC\_PROF[XC=##, YC=##, XE=##,  
 YE=##, AE=##, XI=##, YI=##, XJ=##,  
 YJ=##, XK=##, YK=##, DR=##, RA=##,  
 TI=##, SS=##, SC=##, SE=##, SP=##]**

**XC** = X center  
 Default: Null  
**YC** = Y center  
 Default: Null  
**XE** = X end  
 Default: Null

**YE** = Y end  
 Default: Null  
**AE** = End angle  
 Default: Null  
**XI** = First intermediate X  
 Default: Null  
**YI** = First intermediate Y  
 Default: Null  
**XJ** = Second intermediate X  
 Default: Null  
**YJ** = Second intermediate Y  
 Default: Null  
**XK** = Third intermediate X  
 Default: Null  
**YK** = Third intermediate Y  
 Default: Null  
**DR** = Direction  
 0 = CW  
 1 = CCW  
 Default: 0  
**RA** = Radius  
 Default: Null  
**TI** = Tangent/intersect to previous element  
 0 = Intersect  
 1 = Tangent  
 Default: 1  
**SS** = Solution start  
 0 = +  
 1 = -  
 2 = N/A  
 Default: 0  
**SC** = Solution center  
 0 = +  
 1 = -  
 2 = N/A  
 Default: 0  
**SE** = Solution end  
 0 = +  
 1 = -  
 2 = N/A  
 Default: 0  
**SP** = Solution pending  
 0 = +  
 1 = -  
 2 = N/A  
 Default: 0

**AREA\_CLR[ ]**

(Area Clear), *command*. Creates tool path for removing material from inside a closed profile. {Afab}

**AREA\_CLR[PB=\$\$, NB=\$\$, XS=##, YS=##,  
 XI=##, YI=##, TY=##, NT=##, WC=##,  
 FA=##, PA=##, OA=##]**

PB = Element in roughing area boundary  
Default: None  
NB = Element in the material closure boundary for notch  
Default: Null  
XS = X start corner  
Default: None  
YS = Y start corner  
Default: None  
XI = X inside area  
Default: None  
YI = Y inside area  
Default: None  
TY = Area clear  
0 = Spiral  
1 = ZigZag  
Default: 1  
NT = Notch  
0 = Closed boundary  
1 = Notch  
Default: 0  
WC = Width of cut  
Default: 0  
FA = Finish amount  
Default: 0  
PA = Pass angle (for ZigZag)  
Default: 0  
OA = Overlap amount  
Default: 0

**ASIN( )**

(Arcsine), *function*. Returns the arcsine of an angle.

**ASIN(numexp)**

numexp = angle in degrees

**ATAN( )**

(Arctangent), *function*. Returns the arctangent of an angle.

**ATAN(numexp)**

numexp = angle in degrees

**AUTO\_ABORT[ ]**

(Auto Abort), *command*. Automatically aborts macro execution when encountering a critical error. No error message will be displayed and the application will close without saving the current model. The auto-abort mode will stay on until macro completes or until it is explicitly turned off by AUTO\_ABORT [ABORT=0].

Note: Auto Abort is not a recordable macro command.

**AUTO\_ABORT[ABORT=##]**

ABORT = Auto-abort mode switch  
0 = Off  
1 = On:

**AUTO\_ANSWER[ ]**

(Auto Answer), *command*. Automatically responds to non-error messages that are displayed. The selected response will be applied to the message and the macro will continue without stopping. Critical errors will not be ignored and will still stop the macro. Auto Answer cannot be used to trigger or accept non-message dialog boxes (such as Save or Display Modes). The auto-answer mode will stay on until macro completes or until it is explicitly turned off by AUTO\_ANSWER [AA="OFF"].

Note: Auto Answer is not a recordable macro command.

**AUTO\_ANSWER[AA=\$\$]****AA = Answer (required)**

"OFF" = Notice will be displayed as it would normally (interactive with user and interrupt macro processing)

"OK" = Answers with "Ok" or "Yes" where applicable.

"YES" = Answers with "Ok" or "Yes" where applicable.

"CANCEL" = Answers with "Cancel" when applicable; if not, then like "OK"

"NO" = Answers with "No" when applicable; if not, then like "Cancel" when applicable; if not, then like "OK"

**AUTO\_BALANCE[ ]**

(Auto Balance Roughing), *command*. Creates mirrored tool path for the second turret, enabling both turrets to cut the same tool path simultaneously. {Aturn}

**AUTO\_BALANCE [TL=##]**

TL = Tool number for copy (required)  
Default: None

**AUT\_NEST[ ]**

(Auto Nest), *command*. Creates multiple copies of elements in the active group into a defined rectangular area.

**AUT\_NEST[XS=##, YS=##, XE=##, YE=##, FD=##, NS=##, SP=##, RO=##, FL=##, CO=##, ST=##]**

XS = X Area start corner  
     Default: None  
 YS = Y Area start corner  
     Default: None  
 XE = X 2nd corner  
     Default: None  
 YE = Y 2nd corner  
     Default: None  
 FD = Row direction  
     0 = X axis  
     1 = Y axis  
 NS = Nest pattern  
     0 = Grid  
     1 = Stagger  
 SP = Space  
     Default: 0  
 RO = 180° rotation allowed  
     0 = No  
     1 = Yes  
 FL = Fill area  
     0 = Limit copies to copy limit  
     1 = Fill the area  
 CO = Copy limit  
 ST = Sort by tools  
     0 = No  
     1 = Yes

## - B -

### **BASE[ ]**

(Base View), *command*. Changes the size of the view in the window to display the full area defined in the Envelope dialog box.

BASE[]

### **BEGIN**

(Begin Block), *script*. Identified the start of a block of user interface script. Part of a set that includes BEGIN, END.

Note: Begin Block only functions while running in the macro demo mode without using the default UI scripts. Each BEGIN must be followed by a corresponding END within the macro.

BEGIN

### **BLEND[ ]**

(Blend), *command*. Inserts an arc with a given radius between two lines or arcs on the same work plane and trim them to the tangency points.

BLEND[E1=\$\$, E2=\$\$, S1=##, S2=##,  
       IN=##, DR=##, RA=##]  
 E1 = First element (required)  
     Default: None  
 E2 = Second element (required)  
     Default: None  
 S1 = First blend side (required)  
     0 = Mouse  
     1 = Right  
     2 = Left  
     Default: None  
 S2 = Second blend side (required)  
     0 = Mouse  
     1 = Right  
     2 = Left  
     Default: None  
 IN = Blend number  
     1 = First blend  
     2 = Second blend  
     Default: 1  
 DR = Arc direction  
     0 = Small  
     1 = Large  
     Default: 0  
 RA = Radius (required)  
     Default: None

### **BLEND\_SURFS[ ]**

(Blend Mesh), *command*. Creates a constant or variable radius polyline blend mesh between two ranges of profiles using the properties and sequence you specify with the Insert Property bar. {Amill, Ffm}

BLEND\_SURFS[E1=\$\$, E2=\$\$, S1=##,  
           T1=##, E3=\$\$, E4=\$\$, S2=##, T2=##,  
           PD=##, SP=##, SV=##, DI=##, DV=##,  
           RS=##, RE=##, CC=##, CM=##,  
           VT=##]

E1 = First surface start element (required)  
     Default: None  
 E2 = First surface end element (required)  
     Default: None  
 S1 = First surface keep side/blend side  
     0 = Pos  
     1 = Neg  
     Default: 0  
 T1 = Trim first surface  
     0 = Off  
     1 = On:  
         Default: 1  
 E3 = Second surface start element  
     (required)  
     Default: None

E4 = Second surface start element  
 (required)  
 Default: None

S2 = Second surface keep side/blend side  
 0 = Pos  
 1 = Neg  
 Default: 0

T2 = Trim second surface  
 0 = Off  
 1 = On:  
 Default: 1

PD = Path direction  
 0 = Cross (arcs)  
 1 = Along (flow)  
 Default: 0

SP = Spacing (type)  
 0 = Distance  
 1 = Count  
 Default: 0

SV = Spacing value (required)  
 Default: None

DI = Division (type)  
 0 = Distance  
 1 = Count  
 Default: 0

DV = Division value (required)  
 Default: None

RS = Start radius (required)  
 Default: None

RE = End radius (required)  
 Default: None

CC = Contact curve  
 0 = Off  
 1 = On:  
 Default: 0

CM = Connect mesh  
 0 = Off  
 1 = On:  
 Default: 0

VT = Virtual mesh tolerance  
 Default: Global variable  
 Initial Default: 0.001

**BOUND\_ALL[ ]**

(Multiple Boundaries), *command*. Creates several 2D or 3D profiles using the surface boundaries that define the faces of a solid. This function does not change the existing surface element.

**BOUND\_ALL[SE=##, TO=##]**

SE = Element index of surface  
 Default: None

TO = Tolerance for curve approximation  
 Default: 0.001.

**BOUND\_ONE[ ]**

(Single Boundary), *command*. Creates a 2D or 3D profile using the surface boundaries that define the face of a solid. This function does not change the existing surface element.

**BOUND\_ONE[SE=##, TO=##, LP=##,  
 VI=##, DI=##]**

SE = Element index of surface

Default: None

TO = Tolerance for curve approximation

Default: 0.001.

LP = Index of boundary

Default: 1

VI = Index of start vertex

Default: 1

DI = Whether or not to reverse the output direction

0 = No

1 = Yes

Default: 0

**BOX\_GRP[ ]**

(Box Group), *command*. Adds elements to the active group by defining a rectangular area in the current view.

**BOX\_GRP[X1=##, Y1=##, X2=##, Y2=##,  
 PC=##, AR=##]**

X1 = First box corner X (required)

Screen coordinate value

Default: None

Y1 = First box corner Y (required)

Screen coordinate value

Default: None

X2 = Second box corner X (required)

Screen coordinate value

Default: None

Y2 = Second box corner Y (required)

Screen coordinate value

Default: None

PC = Partial/complete (required)

0 = Partial

1 = Complete

Default: None

AR = Add/remove (required, modal)

0 = Add

1 = Remove

- C -

**CAVITY[ ]**

(Cavity Roughing), *command*. Creates a pocketing style of tool path for each planar profile in the active group. {Amill, Ffm}

**CAVITY[TY=##, EL=##, WC=##, AN=##, AR=##, XC=##, YC=##, XS=##, YS=##, BC=##, CC=##, IP=##, UA=##, CL=##, RS=##, CI=##, EW=##, OP=##, RM=##, RT=##, AC=##, RD=##, IT=##, LY=##, NN=\$\$, UT=##]**

TY = Cavity method:

- 0 = Spiral
- 1 = Zigzag
- 2 = Linear
- Default: 0

EL = Material boundary element (required)

WC = Width of cut (required)

AN = Pass angle

Default: 0

AR = Ramp angle

Default: 90.0 (vertical)

XC = Cut X (required)

YC = Cut Y (required)

XS = Start X (no default, not required)

YS = Start Y (no default, not required)

BC = Boundary clearance

Default: 0.0

CC = Connect cavity profile

- 0 = Off
- 1 = On:
- Default: 0

IP = Final island pass

- 0 = Off
- 1 = On:
- Default: 0 (not used in v4.0)

UA = Uncut area geometry—use

- 0 = Off
- 1 = On:
- Default: 0

CL = Climb cut

- 0 = Conventional
- 1 = Climb
- Default: 1

RS = Ramp from start

- 0 = Off, use ramp angle
- 1 = On, ramp from start point

CI = Cut inside out

- 0 = Off (cut outside in)
- 1 = On
- Default: 1

EW = Equalize width passes

- 0 = Off
- 1 = On:
- Default: 0

OP = Overlap passes

- 0 = Off
- 1 = On:
- Default: 0

RM = Rough tolerance method

- 0 = Off, minimum
- 1 = On, Mid Tol
- Default: 0

RT = Rough tolerance amount (distance)

Default: 0.00005

AC = Corner roll angle

Default: 60.0

RD = Rapid to depth

- 0 = Off
- 1 = On:
- Default: 0

IT = Island top machining

0 = Full pass

1 = Clear top

Default: 0

LY = Layer

Default: 1

NN = AUM named group name

Default: AUM

UT = Uncut material tolerance

Default: 0.01

**CEX( )**

(Center X), *function*. Returns the X coordinate of the center point of selected arc, ellipse or helix element.

**CEX( elnum )**

elnum = Element number or name

**CEY( )**

(Center Y), *function*. Returns the Y coordinate of the center point of selected arc, ellipse or helix element.

**CEY( elnum )**

elnum = Element number or name

**CEZ( )**

(Center Z), *function*. Returns the Z coordinate of the center point of selected arc, ellipse or helix element.

**CEZ( elnum )**

elnum = Element number or name

**CHAIN[ ]**

(Chain), *command*. Converts connected elements into a contiguous profile of sequential elements (the end point of one element is the start point of the next

element). You can also join individual lines or polylines into one polyline element.

**CHAIN[EL=\$\$, PJ=##]**

EL = Element in profile (required)

Default: None

PJ = Polyline join

0 = Chain

1 = Poly join

2 = Both

Default: 0

### **CHAMF[ ]**

(Chamfer), *command*. Inserts a line of a given size at an angle relative to two line, arc, elliptical, or polyline elements on the same work plane. The Chamfer modeling tool also trims or extends the two existing elements to the intersection point of the chamfer.

**CHAMF[E1=\$\$, E2=\$\$, S1=##, S2=##, IN=##, AN=##, DS=##, D1=##, D2=##]**

E1 = First element (required)

Default: None

E2 = Second element (required)

Default: None

S1 = First chamfer side

0 = Left

1 = Right

Default: 1

S2 = Second chamfer side

0 = Left

1 = Right

Default: 1

IN = Intersect number

1 = First intersection

2 = Second intersection

3 = Third intersection

4 = Fourth intersection

Default: 1

AN = Angle

Default: Null

DS = Length of chamfer (distance)

Default: Null

D1 = Distance parallel

Default: Null

D2 = Distance perpendicular

Default: Null

### **CHECK\_MODEL[ ]**

(Check Model), *command*. Immediately executes the ACIS body checker. It checks the geometry and topology of solids, surfaces, and surface trimming curves. It

processes all surfaces or solids that are in the active group. Warning and error messages are reported to the SmartCAM Diagnostics window. {Amill, Ffm}

**CHECK\_MODEL[MC=##, MA=##]**

MC = Model Checking (level of checking)

0 = None

1 = Low

2 = Medium

3 = High

Default: 0

MA = Action

0 = None

1 = Delete

Default: 0

### **CL\_NAME\_ELMT[ ]**

(Clear Name Element), *command*. Removes a name assigned to an element and removes the element's name from the element list.

**CL\_NAME\_ELMT[EL=\$\$]**

EL = Element name or number to clear (required)

Default: None

### **CLOSE[ ]**

(Close Item), *script*. Closes a dialog box being displayed in the user interface.

Note: Close Item only functions while running in the macro demo mode without using the default UI scripts.

**CLOSE[\$\$]**

\$\$ = Name of dialog box

### **CLR( )**

(Clear), *function*. Returns the clearance value of an element.

CLR(elnum) Clearance value

elnum = Element name or number

### **CNECT\_1WAY[ ]**

(Connect 1 Way), *command*. Connects unconnected mesh by creating connecting lines, inserting them into the database between each pair of elements from the start element to the end element. The new lines are on the same work plane and step or layer as start element.

Note: Connect 1 Way is not a recordable macro command.

CNECT\_1WAY[E1=##, E2=##]

E1 = Start element

E2 = End element

### **CNV\_A2H[ ]**

(Convert Arcs To Holes), *command*. Converts the arc elements in the active group to holes.

CNV\_A2H[CL=##, CN=##, KA=##, LV=##,  
TD=##]

CL = Clear

Default: None

CN = Clear On

0 = off

1 = on

2 - no change from arc setting

Default: 0

KA = Keep original arcs

0 = off

1= on

Default: 0

LV = Level

Level of created holes

Default: None

TD = Tip Depth

Tip Depth

Default: None

### **CODE[ ]**

(Code), *command*. Generates the NC code for all unmasked step-property elements in the database.

CODE[FN=\$\$, MS1=\$\$, MT1=\$\$, SS1=\$\$,  
ST1=\$\$, MS2=\$\$, MT2=\$\$, SS2=\$\$,  
ST2=\$\$, SH=##, DC=##, RP=##,  
ST=##, DT=##, SP=##]

FN = Code output file name

Default: Current model file name

MS1 = filename of Master Smf for turret 1  
(was previously MF).

MT1 = filename of Master Tmp for turret 1  
(was previously TF).

SS1 = filename of Slave Smf for turret 1 (for  
Advanced Turning only).

ST1 = filename of Slave Tmp for turret 1 (for  
Advanced Turning only).

MS2 = filename of Master Smf for turret 2  
(for Advanced Turning only).

MT2 = filename of Master Tmp for turret 2  
(for Advanced Turning only).

SS2 = filename of Slave Smf for turret 2 (for  
Advanced Turning only).

ST2 = filename of Slave Tmp for turret 2 (for  
Advanced Turning only).

SH = Show\_Path

0 = Off

1 = On: Default: 1

DC = Display code

0 = Off

1 = On: Default: 1

RP = Report

0 = Off

1 = On: Default: 0

ST = Show tool

0 = Filled

1 = Nibble, 2=Draw\_End Default: 0

DT = Draw tool

0 = 3-D

1 = Flat Default: 0

SP = Speed

0-9 Default: 8

### **CODFILE( )**

(Code File), *function*. Returns the code file name of the last file coded in the current session.

Note: Code File is not a recordable macro function.

CODFILE()

### **COLOR CHG[ ]**

(Color Change), *command*. Changes the color for existing elements assigned to a step tool, or to change the color and the line style (solid, broken, or dotted) for elements assigned to existing layers.

COLOR\_CHG[CO=##, TY=##, TL=##,  
DI=##, ST=##]

CO = Color

1-15

Default: 1

TY = Type

0 = Step

1 = Layer

2 =Tool

Default: 0

TL = Step/layer/tool (required)

Default: None

DI = Tool diameter (not available in v4.0,

ignored)

Default: Null

ST = Style (for layer only)  
 0 = Solid  
 1 = Broken  
 2 = Dotted  
 Default: 0

**CONNECT[ ]**

(Connect Mesh), *function*. Connects individual mesh profiles in the active group into a continuous zigzag profile by inserting a line element between the end of one profile and the start of the adjacent profile. Can also disconnect grouped profiles, which results in elements traveling in the same direction and sequentially in the database. {Amill, Ffm}

CONNECT[DS=##, DM=##]

DS = Maximum connection distance  
 (required)  
 Default: None

DM = Disconnect mesh  
 0 = Off  
 1 = On:  
 Default: 0

**CONTOUR[ ]**

(Contour Machining), *command*. Creates a tool path that is a series of profile cuts at successive Z levels around grouped NURBS surfaces. {Ffm}

CONTOUR [SU=##, DS=##, DC=##,  
 EU=##, DE=##, US=##, XS=##, YS=##,  
 OA=##, TI=##, TO=##, SS=##, PT=##,  
 CL=##, CP=##, CF=##, LU=##, LN=\$\$,  
 FU=##, IU=##, FN=\$\$, FTS=\$\$, LC=##,  
 TY=##, AN=##, DI=##, RA=##, AS=##,  
 AE=##, AD=##, AV=##]

SU = Use Depth of Start Z/First Pass Level  
 0 = Off  
 1 = On:  
 Default: 0

DS = Depth of Start Z/First Pass Level  
 (required if SU= 1)  
 Default: 0

DC = Depth of Cut (required)  
 Default: 0

EU = Use Depth of Ending Z/Final Pass  
 Level  
 0 = Off  
 1 = On:  
 Default: 0

DE = Depth of Ending Z/Final Pass Level  
 (required if EU = 1)  
 Default: 0

US = Use Profile Start Point

0 = Off  
 1 = On:  
 Default: 0

XS = Profile Start Point X value (required if  
 US = 1)

Default: 0

YS = Profile Start Point Y value (required if  
 US = 1)

Default: 0

OA = Offset (Finish) Amount (required)

Default: 0

TI = In Tolerance (required)

Default: 0.01

TO = Out Tolerance (required)

Default: 0.01

SS = Surface Side

0 = Off  
 1 = On:  
 Default: 0

PT = Path Type

0 = ZigZag  
 1 = One Way Plunge  
 Default: 1

CL = Climb Cut

0 = Conventional  
 1 = Climb  
 Default: 1

CP = Closed Profiles Only (required)

0 = Off/Open+Closed  
 1 = On/Closed Only

Default: 1

CF = Clear/Feed

0 = Absolute  
 1 = Increment  
 Default: 0

LU = Log File, Use

0 = Off  
 1 = On:  
 Default: 0

LN = Log File, Name

Default: ffm.ini::LogFile.machine:  
 Paths.def/machine.log (where Paths.def  
 is the path from the Paths.def variable in  
 the `ffm.ini` file)

FU = External File, Use

0 = Off  
 1 = On:  
 Default: 0

IU = Lead In/Lead Out, Use

0 = Off  
 1 = On:  
 Default: 0

FN = External File, Name  
 Default:  
 ffm.ini::ExternalFile.SurfaceMachine:  
 Paths.def/pmyfile.ext (where  
 Paths.def/pmyfile variable is in the  
 ffm.ini file; ext is .sat, .sab, or  
 .igs, depending on FT.)

FTS = External File, Type  
 SAT, SAB, IGSS

AS = Adjust First Pass (Start)  
 0 = No  
 1 = Yes  
 Default: 1

AE = Adjust Final Pass (End)  
 0 = No  
 1 = Yes  
 Default: 1

AD = Adjust Depth of Cut  
 0 = No  
 1 = Yes  
 Default: 1

AV = Adjustment Value  
 a valid constant or expression  
 Default: 0.01\*(In Tol+Out Tol)/2 where  
 In Tol and Out Tol are input values from  
 the control panel Lead In/Lead Out  
 dialog variables:

LC = Location (required if IU = 1)  
 0 = In  
 1 = Out  
 2 = Both)  
 Default: 2

TY = Type (required if IU = 1)  
 0 = Line  
 1 = Arc  
 2 = Both  
 Default: 2

AN = Angle (required if IU = 1)  
 Default: 30

DI = Distance (Length of Line) (required if IU  
 = 1 and TY = 0 or 2)  
 Default: 2\*TL(TL\_DIA)

RA = Radius, for Arc (required if IU = 1 and  
 TY = 1 or 2)  
 Default: 1\*TL(TL\_DIA)

**CONTOUR\_RGH[ ]**

(Contour Roughing), *command*. Creates tool path with roughing passes that follow the shape of an existing part profile. This command has been superceded by the TCONTOUR[] macro command. An attempt has been made to make this command forward compatible with newer command.  
 {Pturn, Aturn}

Note: Contour Roughing is not a recordable macro command.

CONTOUR\_RGH[ES=##, EE=##, XS=##,  
 YS=##, EM=##, ZF=##, XF=##, DP=##,  
 CL=##, NP=#]

ES = Finish profile start (required)  
 Default: None

EE = Finish profile end (required)  
 Default: None

XS = Z start (required)  
 Default: None

YS = X start (required)  
 Default: None

EM = Material element (required)  
 Default: None

ZF = Z finish amount (required)  
 Default: None

XF = X finish amount (required)  
 Default: None

DP = Pass depth (required)  
 Default: None

CL = Clear (required)  
 Default: None

NP = Number of passes  
 Default: Null

**COONS[ ]**

(Coons Mesh), *command*. Creates sculpted mesh profiles by using four connected boundary profiles that define the mesh area and cross-section profiles that define interior contour. {Amill, Ffm}

COONS[E1=\$\$, E2=\$\$, E3=\$\$, E4=\$\$,  
 BP=##, PD=##, SP=##, SV=##, ZT=##,  
 DI=##, DV=##, OF=##, OA=##, GC=##,  
 CM=##]

E1 = First profile start (required)  
 Default: None

E2 = First profile end (required)  
 Default: None

E3 = Second profile start (required)  
 Default: None

E4 = Second profile end (required)  
 Default: None

BP = By patch tangents  
 0 = Off  
 1 = On:  
 Default: 0

PD = Path direction  
 0 = Cross  
 1 = Along  
 2 = Planar  
 Default: 0

SP = Spacing  
   0 = Distance  
   1 = Count  
   2 = Cusp Hgt  
   Default: 0  
 SV = Spacing value (required)  
   Default: None  
 ZT = Planar Z  
   Default: 0.0  
 DI = Division  
   0 = Distance  
   1 = Count  
   2 = Mid Tol  
   3 = In Tol  
   4 = Out Tol  
   Default: 0  
 DV = Division value (required)  
   Default: None  
 OF = Offset  
   0 = Positive  
   1 = Negative  
   2 = 0  
   Default: 2  
 OA = Finish amount  
   Default: 0.0  
 GC = Gouge correction  
   0 = Off  
   1 = On:  
   Default: 0  
 CM = Connect mesh  
   0 = Off  
   1 = On:  
   Default: 0

**COORDLST[ ]**

(Coordinate List), *command*. Assigns a list of 2D or 3D coordinate to a variable to be used as a coordinate list variable.

Note: Coordinate List is not a recordable macro command.

**COORDLST[VN=\$\$, DM=##]**

VN = Variable name (required)  
   Default: None  
 DM = Dimension, number of ordinates  
   2 = 2-D (.sh2)  
   3 = 3-D (.sh3)  
   Default: 3

**COS( )**

(Cosine), *function*. Returns the cosine of an angle.

**COS(numexp)**  
numexp = angle in degrees

**CPX( )**

(Control Point X), *function*. Returns the X coordinate of a specified control point of selected polyline or spline element.

**CPX(elenum,ptnum)**

elnum = Element number or name  
 ptnum = Point number of polyline or spline

**CPY( )**

(Control Point Y), *function*. Returns the Y coordinate of a specified control point of selected polyline or spline element.

**CPY(elenum,ptnum)**

elnum = Element number or name  
 ptnum = Point number of polyline or spline

**CPZ( )**

(Control Point Z), *function*. Returns the Z coordinate of a specified control point of selected polyline or spline element.

**CPZ(elenum,ptnum)**

elnum = Element number or name  
 ptnum = Point number of polyline or spline

**CRE\_LINK[ ]**

(Create Links), *command*. Creates lines to establish links between two defining profiles. {Awedm}

**CRE\_LINK[CC=##, P1=##, P2=##, S1=##, S2=##, XS=##, YS=##, ZS=##, XE=##, YE=##, ZE=##]**

**CC= Create Choice**

0 = Range  
 1 = Element  
 Default: None

**P1 = Primary range start**

Default: None

**P2 = Primary range End**

Default: None

**S1 = Secondary range start**

Default: None

**S2 = Secondary range end**

Default: None

**XS = X start**

Default: None

**YS = Y start**

Default: None

ZS = Z start  
Default: None  
XE = X end  
Default: None  
YE = Y end  
Default: None  
ZE = Z end  
Default: None

**CYLDIAM( )**

(Cylinder Diameter), *function*. Returns the cylinder diameter of an acis cylinder. {Amill, Ffm}

**CYLDIAM( elnum )**  
elnum = Element number or name

**- D -****DLGADD[ ]**

(Dialog Add), *script*. Displays a dialog boy in the user interface.

Note: Dialog Add only functions while running in the macro demo mode without using the default UI scripts.

**DLGADD[\$\$]**

\$\$ = Name of dialog box

**DRL\_DEFINE[ ]**

(Define Drill Sub), *command*. Assigns the active group of hole elements to a drilling subroutine, then places a related Drill Call element in the database. {Pmill, Amill, Ffm}

**DRL\_DEFINE[NN=##, CP=##, XE=##,  
YE=##, ZE=##, PK=##]**

NN = Drill subroutine name

Default: None

CP = Repeats

Default: 0

XE = Handle point X

YE = Handle point Y

ZE = Handle point Z

PK = Peck

0 = Off

1 = On:

**DEF\_PLANE[ ]**

(Define Plane), *command*. Creates a new work plane for the model or change the parameters for an existing non-reserved work plane.

**DEF\_PLANE[TY=##, FR=##, WP=\$\$,  
TP=\$\$, X1=##, Y1=##, Z1=##, X2=##,  
Y2=##, Z2=##, XI=##, YI=##, ZI=##,  
RO=##, AA=##, AB=##, AC=##, ZD=##,  
MP=##]**

TY = Type (definition method)

0 = 3 points

1 = Line/angle

2 = Rotation

Default: 0

FR = From (which coordinate system)

0 = Active plane

1 = World

Default: 1

WP = Work plane (required)

Default: None

TP = Tool plane (required)

Default: None

X1 = X of origin point (required)

Default: None

Y1 = Y of origin point (required)

Default: None

Z1 = Z of origin point (required)

Default: None

X2 = X of plus-X point (required for 3-point and line/angle plane definitions)

Default: None

Y2 = Y of plus-X point (required for 3-point and line/angle plane definitions)

Default: None

Z2 = Z of plus-X point

Default: Z1

XI = X of third point (required for 3-point plane definitions)

Default: None

YI = Y of third point (required for 3-point plane definitions)

Default: None

ZI = Z of third point (required for 3-point plane definitions)

Default: None

RO = Rotation order (required)

0 = ABC

1 = BAC

2 = ACB

3 = BCA

Default: None

AA = Angle A (required for line/angle and rotation)

Default: None

AB = Angle B (required for rotation)

Default: None

AC = Angle C

Default: 0.0 for rotation

ZD = Z-axis direction

0 = Pos

1 = Neg

Default: 0

MP = Match plane

0 = Off

1 = On:

Default: 0

### DELETE[ ]

(Delete Element), *command*. Removes a single element from the model.

DELETE[EL=\$\$]

EL = Element number or name (required)

Default: None

### DIM\_RECT[ ]

(Linear Dimension), *command*. Creates a dimension for a 2-D linear distance.

DIM\_RECT[XE=##, YE=##, XS=##, YS=##,  
XI=##, YI=##, LV=##, TX=\$\$, PX=\$\$,  
SX=\$\$, AL=##, DT=##, NF=##, EG=##,  
ED=##, DG=##, L1=##, L2=##, HT=##,  
LA=##, AR=##, FN=\$\$, AF=\$\$]

XE, YE = 2nd point to dimension

XS, YS = 1st point to dimension

XI, YI = Text location

LV = Level for dimension

TX = Text (optional). Will override dimension value specified

PX = Text prefix (optional)

SX = Text suffix (optional)

AL = Align text

0 = Off

1 = On:

Default: 0

DT = Dimension type parallel

0 = x axis

1 = y axis

2 = aligned with points

Default: 2

NF = Numerical format

Range 1-5

EG = Extension line gap

Default: 0.0

ED = Extension line distance

Default: 0.0

DG = Dimension line text gap

Default: 0.0

L1 = 1st extension line create

0 = Off

1 = On:

Default: 1

L2 = 2nd extension line create

0 = Off

1 = On:

Default: 1

HT = Height of text

Default: 1.0

LA = Length of arrow

Default: 1.0

AR = Arrow (line terminators)

0 = Off

1 = On:

Default: 1

FN = Text font file name

Default: None

AF = Arrow file name

Default: None

### DIM\_TEX[ ]

(Dimension Text), *command*. Creates a note on a model with or without a leader from the note's text that points to a particular area on the model.

DIM\_TEX[XE=##, YE=##, LV=##, TX=\$\$,  
AL=##, AN=##, DG=##, HT=##, LA=##,  
AR=##, FN=\$\$, AF=\$\$, CL={}]

XE = X coordinate

YE = Y coordinate

LV = Z location of all text/leaders

Default: None

TX = Text input

Default: Blank

AL = Align text

0 = Off

1 = On:

Default: 0

AN = Rotation angle for text

Default: 0

DG = Dimension line text gap

Default: 0.0

HT = Height of text

Default: 1.0

LA = Length of arrow

Default: 1.0

AR = Arrow (line terminators)

0=Off, 1=On

Default: 1

FN = Text font file name

Default: None

AF = Arrow file name

Default: None

CL = 2-D coordinate list {X1,Y1,...,X9, Y9}

location of text/leader

Default: None

**DIR( )**

(Direction), *function*. Returns the direction of an arc, helix, or ellipse.

## DIR(elnum)

- 0 = CW
- 1 = CCW
- 1 = Not an arc element

**DISP\_MODE[ ]**

(Display Modes), *command*. Controls how SmartCAM displays your model in the graphic view.

DISP\_MODE[TH=##, WA=##, WI=##,  
GR=##, DL=##, IP=##, RL=##, VF=##,  
SZ=##, GI=##, CS=##, DT=##, GM=##,  
AR=##, SN=##, GC=##, CR=##,  
CG=##, CB=##, GA=##]

## TH = Thickness

- 0 = Off
- 1 = On:
- Default: N/C

## WA = World XYZ axes

- 0 = Off
- 1 = On:
- Default: N/C

## WI = Work plane indicator

- 0 = Off
- 1 = On:
- Default: N/C

## GR = Grid

- 0 = Off
- 1 = On:
- Default: N/C

## DL = Data list in world

- 0 = No
- 1 = Yes
- Default: N/C

## IP = Input plane in world

- 0 = No
- 1 = Yes
- Default: N/C

## RL = Ruler

- 0 = Off
- 1 = On:
- Default: N/C

## VF = Vertical frequency

- 0–99
- Default: N/C

## SZ = Relative size for work plane indicator

- 0–1
- Default: N/C

## GI = Grid increment

- Default: N/C

## CS = Curve segment count

- 0–99
- Default: N/C

## DT = Draw tools

- 0 = No tools
- 1 = Flat tools
- 2 = Blips
- 3 = No tools
- Default: N/C

## GM = Group marking

- 0 = Arrow
- 1 = Dotted
- 2 = Both
- Default: N/C

## AR = Auto Redraw

- 0 = Off
- 1 = On:

## SN = Surface normal display

- 0 = Off
- 1 = All
- 2 = Group
- Default: 0

## GC = Surface grid color

- 0 = Match surface
- 1 = Shade darker
- 2 = Shade lighter
- 3 = Fixed color RGB
- 4 = Fixed default dark
- 5 = Fixed default light
- Default: 3

## CR = Surface grid red

- 0–255
- Default: 82

## CG = Surface grid green

- 0–255
- Default: 139

## CB = Surface grid blue

- 0–255
- Default: 139

## GA = Shade adjustment amount

- 1–254
- Default: 80

**DMS( )**

(Degrees Minutes and Seconds), *function*. Returns a decimal angle from degrees, minutes and seconds.

## DMS(ddd.mmss)

- ddd = degrees
- mm = minutes (must be 2 digits)
- ss = seconds (must be 2 digits)

**DRAFT\_SURF[ ]**

(Draft Mesh), *command*. Creates mesh profiles by sweeping a generator profile

along a 3-D director profile's path. {Amill, Ffm}

DRAFT\_SURF[E1=\$\$, E2=\$\$, E3=\$\$, E4=\$\$, PD=##, SP=##, OF=##, SV=##, ZT=##, OA=##, CM=##, GC=##, VT=##]

E1 = Generator profile start (required)  
Default: None

E2 = Generator profile end (required)  
Default: None

E3 = Director profile start (required)  
Default: None

E4 = Director profile end (required)  
Default: None

PD = Path direction  
0 = Generator  
1 = Planar  
Default: 0

SP = Spacing  
0 = Distance  
1 = Count  
Default: 0

OF = Offset  
0 = Positive  
1 = Negative  
2 = 0  
Default: 2

SV = Spacing value (required)  
Default: None

ZT = Planar Z  
Default: 0.0

OA = Finish amount  
Default: 0.0

CM = Connect mesh  
0 = Off  
1 = On:  
Default: 0

GC = Gouge correction  
0 = Off  
1 = On:  
Default: 0

VT = Virtual mesh tolerance  
Default: Global variable  
Initial default: 0.001

**DRL\_CALL[ ]**

(Drill Subroutine Call), *function*. Assigns a previously defined drilling subroutine to different locations on the model. {Pmill, Amill, Ffm}

DRL\_CALL[NN=##, CP=##, XE=##, YE=##, ZE=##, PK=##]

NN = Name of subroutine  
Default: None

CP = Number of repeats  
Default: 0

XE = Insert point X coordinates

YE = Insert point Y coordinates

ZE = Insert point Z coordinates

PK = Peck  
0 = Off  
1 = On:

**DUMP\_GR[ ]**

(Print Graphics), *command*. Prints the current graphic view to the configured printing device.

DUMP\_GR[LM=##, TM=##, RM=##, ST=##, SF=##]

LM = Left margin

TM = Top margin

RM = Right margin

BM = Bottom margin

ST = Show tool

0 = None

1 = Nibble

2 = Draw End - 2-D (.sh2)

3 = Draw End - 3-D (.sh3)

Default: 0

SF = Scale value

Default: 1

**DUMP\_LST[ ]**

(Print Element Data List), *command*. Prints a list of the element data for the entire file or the active group in the open process model.

DUMP\_LST[GP=##, OM=##, FN=\$\$]

GP = What should be listed

0 = Entire file

1 = Active group

Default: None

OM = Output method

0 = Printer

1 = File

Default: None

FN = Filename (required for OM=1)

Default: None

**DYNAMIC\_VIEW[ ]**

(Dynamic View), *command*. Changes the orientation of the model view in the active window.

DYNAMIC\_VIEW[XX=##, XY=##, XZ=##, YX=##, YY=##, YZ=##, OX=##, OY=##, OZ=##, LX=##, RX=##, TY=##, BY=##]

XX = Rotation plane vector  
 XY = Rotation plane vector  
 XZ = Rotation plane vector  
 YX = Rotation plane vector  
 YY = Rotation plane vector  
 YZ = Rotation plane vector  
 OX = X origin of view plane  
 OY = Y origin of view plane  
 OZ = Z origin of view plane  
 LX = Location/size of view window in view plane  
 RX = Location/size of view window in view plane  
 TY = Location/size of view window in view plane  
 BY = Location/size of view window in view plane

## - E -

### **ELLIPSE[ ]**

(Ellipse), *command*. Creates a full or partial ellipse oriented at any angle.

```
ELLIPSE[D1=##, D2=##, XC=##, YC=##,
XS=##, YS=##, XE=##, YE=##, AS=##,
AE=##, AN=##, DR=##, SS=##, SE=##,
LV=##]
```

D1 = Primary distance (required)  
 Default: None

D2 = Secondary distance (required)  
 Default: None

XC = X center (required)  
 Default: None

YC = Y center (required)  
 Default: None

XS = X start  
 Default: Null

YS = Y start  
 Default: Null

XE = X end  
 Default: Null

YE = Y end  
 Default: Null

AS = Angle start  
 Default: Null

AE = Angle end  
 Default: Null

AN = Angle of inclination  
 Default: 0.0

DR = Direction  
 0 = CW  
 1 = CCW  
 Default: 0

SS = Solution start

0 = +  
 1 = -  
 2 = N/A  
 Default: 0

SE = Solution end

0 = +  
 1 = -  
 2 = N/A  
 Default: 0

LV = Level (modal)

### **ELMT\_GRP[ ]**

(Element Group), *command*. Adds or removes an element to or from the active group.

```
ELMT_GRP[EL=##, AR=##]
```

EL = Element (required)  
 Default: None

AR = Add/Remove (modal)  
 0 = Add  
 1 = Remove

### **ELMT\_SEQ[ ]**

(Element Sequence), *command*. Sets the insertion point in the database relative to a specific element.

```
ELMT_SEQ[BA=##, EL=##, ME=##]
```

BA = Before/after (required)  
 0 = Before

1 = After  
 Default: 1

EL = Element (required)  
 Element number or element name

Default: None

ME = Match element  
 0 = Off  
 1 = On:  
 Default: 0

### **ELSE**

(Logical Else), *command*. Is followed by macro commands to be preformed if a preceding conditional test proves false. Part of a command set that includes IF( ), ELSE, ENDIF.

Note: Logical Else is not a recordable macro command. Each ELSE command must be located between corresponding IF and ENDIF commands within the macro.

```
IF(expression)
    true
ELSE
    false
ENDIF
```

expression = A logic expression.  
true = Macro commands to be performed if the logic expression proves true.  
False = Macro commands to be performed if the logic expression proves false

**END**

(End Block), *script*. Identified the end of a block of user interface script. Part of a set that includes BEGIN, END.

Note: End Block only functions while running in the macro demo mode without using the default UI scripts. Each END must be preceded by a corresponding BEGIN within the macro.

END

**ENDIF( )**

(Logical End If), *command*. Identifies the end of an IF command set. Part of a command set that includes IF( ), ELSE, ENDIF.

Note: Logical End If is not a recordable macro command. Each ENDIF command must be preceded by a corresponding IF command within the macro.

```
IF(expression)
    true
ELSE
    false
ENDIF
```

expression = A logic expression.  
true = Macro commands to be performed if the logic expression proves true.  
False = Macro commands to be performed if the logic expression proves false.

**ENDW**

(Logical While Loop End), *command*.  
Identifies the end of a WHILE command set.  
Part of a command set that includes WHILE( ), ENDW.

Note: Logical While Loop End is not a recordable macro command. Each ENDW command must be preceded by a

corresponding WHILE command within the macro.

```
WHILE(expression)
    true
ENDW
```

expression = A logic expression.  
true = Macro commands to be performed if the logic expression proves true.

**ENV\_XE( )**

(Envelope X end), *function*. Returns the X coordinate of the end of the view envelope.

ENV\_XE()

**ENV\_YE( )**

(Envelope Y end), *function*. Returns the Y coordinate of the end of the view envelope.

ENV\_YE()

**ENV\_ZE( )**

(Envelope Z end), *function*. Returns the Z coordinate of the end of the view envelope.

ENV\_ZE()

**ENV\_XS( )**

(Envelope X Start), *function*. Returns the X coordinate of the end of the view envelope.

ENV\_XS()

**ENV\_YS( )**

(Envelope Y Start), *function*. Returns the Y coordinate of the end of the view envelope.

ENV\_YS()

**ENV\_ZS( )**

(Envelope Z Start), *function*. Returns the Z coordinate of the end of the view envelope.

ENV\_ZS()

**ENVELOPE[ ]**

(Envelope), *command*. Defines how much of the model and space around it to include in the base graphic view.

```
ENVELOPE[XS=##, YS=##, ZS=##, XE=##,
          YE=##, ZE=##]
```

XS = X start (required)  
Default: None

YS = Y start (required)  
Default: None  
ZS = Z start (required)  
Default: None  
XE = X end (required)  
Default: None  
YE = Y end (required)  
Default: None  
ZE = Z end (required)  
Default: None

**ENX( )**

(End Point X), *function*. Returns the X coordinate of the end point of selected element.

## ENX(element)

element = Element number or name

**ENY( )**

(End Point Y), *function*. Returns the X coordinate of the end point of selected element.

## ENY(element)

element = Element number or name

**ENZ( )**

(End Point Z), *function*. Returns the Z coordinate of the end point of selected element.

## ENZ(element)

element = Element number or name

**EXECUTE[ ]**

(Execute Action), *script*. Executes the macro command that preceded the block of script supporting it.

Note: Execute Action only functions while running in the macro demo mode without using the default UI scripts.

## EXECUTE[]

**EXPLODE[ ]**

(Explode), *command*. Converts elements in the active group into primitive elements.

## EXPLODE[EX=##, TO=##]

EX = Explode level  
0 = Lines  
1 = Arcs  
2 = Polylines  
Default: 2

TO = Tolerance  
Default: 0.001

**EXPORT[ ]**

(Export), *command*. Converts the elements in the existing model and produces an ACIS, DXF, DWG, IGES, or VDA-FS file. {Amill, Ffm}

Note: The Export can be recorded but will not function when executed.

## EXPORT[FN=\$\$, FTS=\$\$, EX=##, LU=##, LN=\$\$, SF=\$\$, TF=\$\$]

FN = Filename (required)

FTS= Export file type

SAT21

SAB21

SAT17

SAT16

SAT15

DWG

DXF

IGS

VDAFS

EX = Export Solids

0 = On

1 = Off

LU = Log file—use (optional)

0 = No log file written

1 = Write log file

Default: 0

LN = Log file name (required)

SF = Setup File Name (required for CAM Connection file

types DWG, DXF, IGES. Optional for other file types.)

Default: from .ini file

TF = Temporary CAM Connection Input File

Name

(required for CAM Connection file types

DWG, DXF, IGES. Optional for other file types.)

Default: from .ini file

**EXTEND[ ]**

(Extend Mesh), *command*. Extends a selected range of mesh profiles beyond the mesh's defining boundaries. {Amill, Ffm}

## EXTEND[E1=\$\$, E2=\$\$, D1=##, D2=##, DS=##, DE=##, CM=##]

E1 = Mesh start element (required)

Default: None

E2 = Mesh end element (required)  
Default: None  
D1 = Along division start distance  
Default: 0.0  
D2 = Along end  
Default: 0.0  
DS = Across spacing start distance  
Default: 0.0  
DE = Across end  
Default: 0.0  
CM = Connect mesh  
0 = Off  
1 = On:  
Default: 0

**EXTEND\_SURF[ ]**  
(Extend Surface), *command*. Extends an existing surface from a single edge boundary by creating a new NURBS surface that shares the edge boundary with the original surface element. {Amill, Ffm}

```
EXTEND_SURF [ES=$$, LN=##, EN=##,
ET=##, XS=##, YS=##, ZS=##, XE=##,
YE=##, ZE=##]
```

ES = Element number of surface to edit (required)  
Default: None  
LN = Loop number, relative to boundary ordering in ES database (required)  
Default: None  
EN = Edge number, relative to boundary ordering in ES database (required)  
Default: None  
ET = Extend type  
0=G0, 1=G1  
Default: 0  
XS = Start/mid vector, X component  
Default: 0.0  
YS = Start/mid vector, Y component  
Default: 0.0  
ZS = Start/mid vector, Z component  
Default: 0.0  
XE = End vector, X component  
Default: 0.0  
YE = End vector, Y component  
Default: 0.0  
ZE = End vector, Z component  
Default: 0.0

**EXTRACT[ ]**  
(Extract), *command*. Explodes surfaces from solids or extract the constituent elements from a surface or group of surfaces. {Amill, Ffm}

EXTRACT[ET=##, CE=##, BE=##, TE=##,
DE=##, AP=##, KO=##, HS=##, OL=##]  
ET = Extract Type  
0 = Extract surfaces from solids  
1 = Extract elements from surfaces  
Default: 1  
CE = Construction geometry elements  
0 = No extract  
1 = Extract  
Default: 0  
BE = Base surface edges  
0 = No extract  
1 = Extract  
TE = Trimming curve elements  
0 = No extract  
1 = Extract  
Default: 0  
DE = Display grid elements  
0 = No extract  
1 = Extract  
Default: 0  
AP = Assign properties  
0 = Original  
1 = Active properties  
2 = Parent surface properties  
Default: 0  
KO = Keep original surface  
0 = No keep/delete  
1 = Keep  
Default 1  
HS = Hide surface  
0 = No hide  
1 = Hide  
Default: 1  
OL = Hide on layer (required)  
1-99  
Default: 99

## - F -

**F\_CLOSE[ ]**  
(File Close), *command*. Closes an open ASCII text file.

Note: File Close is not a recordable macro command.

**F\_CLOSE[FN=\$\$]**

FN = Filename (required)

**F\_EOF( )**  
(End Of File), *function*. Returns the end of file status of an open ASCII text file.

Note: End Of File is not a recordable macro function.

**F\_EOF(file)**  
file = Filename (required)  
Return values:  
0 = If not end of file  
1 = If end of file

**F\_ERROR()**  
(File Error), *function*. Returns the error status of an open ASCII text file.

Note: File Error is not a recordable macro function.

**F\_ERROR()**

Return values:  
0 = Successful operation (F\_READ,  
F\_OPEN, F\_WRITE, F\_CLOSE)  
1 = File already open (F\_OPEN)  
2 = File not found (F\_OPEN)  
3 = Path not found (F\_OPEN)  
4 = File Is read-only (no write or append allowed) (F\_OPEN)  
5 = File not open (F\_READ)  
6 = File not open for read (F\_READ)  
7 = End of file reached (F\_READ)  
8 = File not open for write (F\_WRITE)  
9 = Too many files already opened (F\_OPEN)  
10 = Bad or missing mode; use A W R (F\_WRITE)  
11 = Expected variable for formatter missing (F\_WRITE, F\_READ)  
12 = Bad character encountered in variable list (F\_WRITE, F\_READ)  
13 = Variable is not of format type (F\_WRITE, F\_READ)  
14 = Bad formatter (F\_WRITE, F\_READ)

**F\_ERRST()**

(File Error String), *function*. Returns the string for the error status returned by F\_ERROR()

Note: File Error String is not a recordable macro function.

**F\_ERRSTR()**

**F\_EXIST()**  
(File Exist), *function*. Returns a value verifying the existence of a file.

Note: File Exist is not a recordable macro function.

**F\_EXIST(strexpr)**  
strexp = Filename (required)  
Return values:  
0 = File does not exist  
1 = File does exist

**F\_LINE()**  
(File Line), *function*. Returns the line number just read by the F\_READ() command.

Note: File Line is not a recordable macro function.

**F\_LINE(strexpr)**  
strexp = Filename (required)

**F\_OPEN[ ]**  
(File Open), *function*. Opens an ASCII text file.

Note: File Open is not a recordable macro command.

**F\_OPEN[FN=\$\$, TY=\$\$]**

FN = Filename (required)  
TY = Open file "TY" file type  
Options: W = Write  
R = Read  
A = Append

**F\_READ[ ]**  
(File Read), *command*. Reads information from an open ASCII text file.

Note: File Read is not a recordable macro command.

**F\_READ[FN=\$\$, FMT="Format of string", VR="VARLIST"]**

FN = Filename (required)  
FMT = The format for each user variable specified by the VR option.  
VR = The name of the user variables to be stored.  
Note: The variables must exist and be initialized or stringed.

**F\_WRITE[ ]**  
(File Write), *command*. Writes information to an open ASCII text file.

Note: File Write is not a recordable macro command.

**F\_WRITE**[FN=\$\$, FMT="Format of string", VR ="VARLIST"]

FN = Filename (required)

FMT = The format for each user variable specified by the VR option.

Format characters:

% = signals a variable follows

%% = prints a preceding % sign

~ = do not interpret the next character, output as a literal

~n = new line (carriage return) identifier

~t = insert a tab character

Numerical output formats:

D =decimal (suppress trailing / leading zeros)

T = trailing zero (no decimal, suppress leading zeros)

L =leading zero (no decimal, suppress trailing zeros)

F =filled (no decimal, fill unfilled fields with zeros)

P =padded (decimal, suppress leading zero)

E =filled (decimal, fill unfilled fields with zeros)

I =integer output

S =string (outputs all characters in the string)

VR =The name of the user variable

Note: The variables must exist and be initialized or stringed.

### FAB\_HOLE[ ]

(Fabrication Hole), *command*. Creates a hole-making operation by using the active step and related properties. {Afab}

**FAB\_HOLE**[XE=##, YE=##, XS=##, YS=##, AE=##, AN=##, DS=##, LV=##, RI=##, SE=##]

XE = X end

Default: Null

YE = Y end

Default: Null

XS = X anchor

Default: Null

YS = Y anchor

Default: Null

AE = Tool angle

Default: Null

AN = Angle

Default: Null

DS = Distance

Default: Null

LV = Level

Default: Modal

RI = Radius input

0 = No

1 = Yes

SE = End solution designator

0 = +

1 = -

2 = N/A

Default: 0

### FABRULE[ ]

(Fabrication Ruled Mesh), *command*.

Creates ruled transitions between two defining profiles. {Afab}

**FABRULE**[E1=\$\$, E2=\$\$, E3=\$\$, E4=\$\$, PD=##, SP=##, SV=##, ZT=##, DI=##, DV=##, CM=##]

E1 = Start element of first profile (required)

E2 = End element of first profile (required)

E3 = Start element of second profile (required)

E4 = End element of second profile (required)

PD = Path direction

SP = Spacing type

0 = Distance

1 = Count

Default: 1

SV = Spacing value

ZT = Planar Z

DI = Division type

DV = Division value

CM = Build face binary

0 = Off

1 = On:

Default: 0

### FACE[ ]

(Face Roughing), *command*. Creates tool path for removing material from a part face. {Pmill, Amill, Ffm}

**FACE**[TY=##, EL=##, FA=##, WC=##, AN=##, XS=##, YS=##, BC=##, DS=##, DC=##, DE=##, EP=##, IN=##, IP=##, AR=##, UA=##, CC=##, RS=##, FL=##, CI=##, EW=##, OP=##, RM=##, RT=##, AC=##, RD=##, IT=##, LY=##, NN=\$\$, UT=##]

TY = Face method

0 = Spiral

1 = Zigzag  
 2 = Linear  
 Default: 0  
**EL** = Outside boundary element (required)  
**FA** = Finish amount  
 Default: 0.0  
**WC** = Width of cut (required)  
**AN** = Pass Angle  
 Default: 0.0  
**XS** = Start X (no default, not required)  
**YS** = Start Y (no default, not required)  
**BC** = Boundary clearance  
 Default: 0.0  
**DS** = First pass level (depth, required)  
**DC** = Depth of cut (required)  
**DE** = Final level (depth, required)  
**EP** = Equalized passes (modal)  
 0 = Off  
 1 = On:  
**IN** = Group island—use  
 0 = Off  
 1 = On:  
 Default: 0  
**IP** = Final (island) pass (modal)  
 0 = Off  
 1 = On:  
**AR** = Ramp angle  
 Default: 90.0 (vertical)  
**UA** = Uncut area geometry—use  
 0 = Off  
 1 = On:  
 Default: 0  
**CC** = Climb cut  
 0 = Conventional  
 1 = Climb  
 Default: 1  
**RS** = Ramp from start  
 0 = Off, use ramp angle  
 1 = On, ramp from start point  
**FL** = Floor allowance  
 Default: 0.0  
**CI** = Cut inside out  
 0 = Off (cut outside in)  
 1 = On  
 Default: 1  
**EW** = Equalize width passes  
 0 = Off  
 1 = On:  
 Default: 0  
**OP** = Overlap passes  
 0 = Off  
 1 = On:  
 Default: 0  
**RM** = Rough tolerance method  
 0 = Off, minimum  
 1 = On, Mid Tol  
 Default: 0

**RT** = Rough tolerance amount (distance)  
 Default: 0.00005  
**AC** = Corner roll angle  
 Default: 60.0  
**RD** = Rapid to depth  
 0 = Off  
 1 = On:  
 Default: 0  
**IT** = Island top machining  
 0 = Full pass  
 1 = Clear top  
 Default: 0  
**LY** = Layer  
 Default: 1  
**NN** = AUM named group name  
 Default: AUM  
**UT** = Uncut material tolerance  
 Default: 0.01

**FACES[ ]**  
(Build Faces), *command*. Creates closed faces from existing ruled elements. {Afab}

**FACES[E1=\$\$, E2=\$\$, SC=##]**

**E1** = Start surface (required)  
 Default: Surface range  
**E2** = End surface (required)  
 Default: Surface range  
**SC** = Scribe surface  
 0 = Off  
 1 = On:  
 Default: 0

**FAUTOSEL[ ]**  
(Fabrication Automatic Tool Select), *command*. Searches the active group for closed profiles representing common fabrication shapes, automatically selects tools that fit the shapes, and creates tool path for removing material from inside the profiles using the selected tools. {Afab}

**FAUTOSEL[RO=##, SQ=##, RE=##,  
OB=##, CO=##, PT=##, LO=##, LS=##,  
LN=##, RD=##, EA=##, CC=##, TF=##,  
TT=##, AC=##]**

**RO** = Round punches  
 0 = Off  
 1 = On  
**SQ** = Square punches  
 0 = Off  
 1 = On  
**RE** = Rectangular punches  
 0 = Off  
 1 = On

OB = Obround punches

  0 = Off

  1 = On

CO = Contouring tools

  0 = Off

  1 = On

PT = Punch tolerance

LO = Lead in/out option

  0 = None

  1 = In

  2 = Out

  3 = Both

LS = Lead in/out style

  0 = Line

  2 = Arc

  3 = Both

LN = Line length

RD = Arc radius

EA = Entry/exit angle

CC = Compensation codes

  0 = Off

  1 = On

TF = Use thinning tolerance

  0 = Off

  1 = On

TT = Thinning tolerance

AC = Corner roll angle

### FILTER\_USE[ ]

(Filter Use), *command*. Turns the use of the Group/Snap filter on or off.

Note: Filter Use on command is recorded when setting the group/snap filters but appears to have no effect on execution regardless of setting or if omitted entirely.

### FILTER\_USE[ON=##]

ON = Use of group/snap filters

  0 = Off

  1 = On

  Default: None

### FIXUP\_51[ ]

(File Fix Up), *command*. Fixes .PM4 files created between 4/27/94 and the release of version 4.2 of the advanced milling applications.

### FLOWLINE[ ]

(Flow Line), *command*. Creates uniform tool path across single surfaces having a cylindrical or spherical shape or an isoparametric tool path in either the U direction or the V direction for a single untrimmed surface element. {Ffm}

FLOWLINE[EL=\$\$, PD=##, SP=##, SV=##,  
DI=##, DV=##, OA=##, OF=##]

EL = Element number of the surface

  Default: None

PD = Path direction

  0 = U direction

  1 = V direction

  Default: 0

SP = Spacing type

  0 = Distance

  1 = Count

  2 = Mid Tol

  Default: 0

SV = Spacing value

  Default: None

DI = Divisions type

  0 = Distance

  1 = Count

  2 = Mid Tol

  Default: 0

DV = Divisions value

  Default: None

OA = Offset (finish) amount value

  Default: 0

OF = Offset direction

  0 = Pos

  1 = Neg

  Default: 1

### FOLD[ ]

(Fold), *command*. Folds geometry in the active group automatically calculating the required bend allowance by entering values for Bend Angle, Thickness, Inside Radius, and K Factor. {Afab}

FOLD[BE=##, FE=##, FL=##, AN=##,  
DI=##, ML=##, TH=##, IR=##, KF=##,  
HC=##, MT=##, AD=##, MO=##]

BE = Base element (required)

  Number of elements in base profile

FE = Face element (required)

  Number of elements in face profile

FL = Fold line element

  Number of line elements on fold line

BS = Bend side

  0 = Inside

  1 = Middle

  2 = Outside

  Default: 1

AN = Angle to bend to (required)

  Default: 0

DI = Direction

  0 = Neg

1 = Pos  
 Default: 1  
 ML = Mold lines  
 0 = Off  
 1 = 0  
 Default: 0  
 TH = Thickness  
 Default: 0  
 IR = Inside radius  
 Default: 0  
 KF = K factor  
 Default: 0  
 HC = Hem compensation  
 Default: 0  
 MT = Multiply  
 Default: 1  
 AD = Add  
 Default: 0  
 MO = Mode  
 0 = Fold  
 1 = Flatten  
 Default: 0

**FORM\_PATCH[ ]**

(Form Patch), *command*. Create sculpted mesh profiles by using four connected boundary profiles that define the surface area. {Amill, Ffm}

**FORM\_PATCH[E1=\$\$, E2=\$\$, E3=\$\$,  
E4=\$\$, PD=##, SP=##, SV=##, ZT=##,  
DI=##, DV=##, OF=##, OA=##, CM=##,  
GC=##]**

E1 = First director start (required)  
 Default: None  
 E2 = First director end (required)  
 Default: None  
 E3 = Second director start (required)  
 Default: None  
 E4 = Second director end (required)  
 Default: None  
 PD = Path direction  
 0 = Cross  
 1 = Along  
 2 = Planar  
 Default: 0  
 SP = Spacing  
 0 = Distance  
 1 = Count  
 2 = Cusp Hgt  
 Default: 0  
 SV = Spacing value (required)  
 Default: None  
 ZT = Planar Z  
 Default: 0.0

DI = Division  
 0 = Distance  
 1 = Count  
 2 = Mid Tol  
 3 = In Tol  
 4 = Out Tol  
 Default: 0  
 DV = Division value (required)  
 Default: None  
 OF = Offset  
 0 = Positive  
 1 = Negative  
 2 = 0  
 Default: 2  
 OA = Finish offset amount  
 Default: 0  
 CM = Connect mesh  
 0 = Off  
 1 = On:  
 Default: 0  
 GC = Gouge correction  
 0 = Off  
 1 = On:  
 Default: 0

**FPATH\_SET[ ]**

(File Path Set), *command*. Changes the default path for a specified file type in the [Paths] section of the application ini file.

Note: File Path Set is not a recordable macro command.

**FPATH\_SET[IN=\$\$, FP=\$\$]**

IN = Type of path  
 ctg = Path for custom tool graphic files  
 def = Path for current Process Model file  
 export = path for internal export files (not Cam Connections)  
 fnt = Path for current font file  
 jof = Path for current job file  
 smf = Path for code generator files  
 import = path for internal import files (not Cam Connections)  
 FP = Path

**FROM\_MESH[ ]**

(From Mesh), *command*. Creates a surface from an existing mesh. From Mesh uses the value in the Point Set Fitting field of the Surface Modes dialog box to control the tolerance for creating the surface. {Ffm}

**FROM\_MESH[ES=\$\$, EE=\$\$]**

ES = Mesh starting element (required)

EE = Mesh ending element (required)

### FULL[ ]

(Full), *command*. Redraws the graphic view to display all non-hidden elements of the model.

FULL[]

## - G -

### GEN\_MESH[ ]

(Generate Mesh), *command*. Creates a polyline mesh from a surface. {Ffm}

GEN\_MESH[EL=\$\$, PD=##, SP=##,  
SV=##, DI=##, DV=##]

EL = Element number of the surface  
Default: None

PD = Path direction arguments

0 = U direction

1 = V direction

Default: 0

SP = Spacing type

0 = Distance

1 = Count

2 = Mid Tol

Default: 0

SV = Spacing value

Default: None

DI = Division type

0 = Distance

1 = Count

2 = Mid Tol

Default: 0

DV = Division value

Default: None

### GET\_GRP[ ]

(Get Group), *command*. Adds geometry previously assigned to a named group to the active group.

GET\_GRP[GN=\$\$]

GN = Group name (required)

Current group name

Default: None

### GET\_NAME( )

(Get Name), *function*. Returns the name and extension of the filename.

Note: Get Name is not a recordable macro function.

GET\_NAME(strexp)

strexp = File pathname

### GET\_PATH( )

(Get Path), *function*. Returns path portion of filename.

Note: Get Path is not a recordable macro function.

GET\_PATH(strexp)

strexp = File pathname

### GET\_VIEW[ ]

(Get View), *command*. Displays any existing views from the Views list.

GET\_VIEW[VN=\$\$]

VN = View name (required)

Default: None

### GOTO( )

(Go To), *command*. Redirects the execution of macro commands to another section of the macro. Part of a command set that includes GOTO( ), @label.

Note: Go To is not a recordable macro command. Each GOTO command must have a corresponding label within the macro. The GOTO command can only advance forward in the macro and cannot be made to loop backward.

GOTO(label)

@label

label = Name identifying a section of a macro (required)

### GRAPHICS\_OFF[ ]

(Graphics Off), *command*. Disables the redrawing of the graphics and list view to speed up long-processing macros. The graphics and list view will remain disabled even after the macro terminates until the GRAPHICS\_ON[] command is issued.

Note: Graphics Off is not a recordable macro command.

GRAPHICS\_OFF[]

**GRAPHICS\_ON[ ]**

(Graphics On), *command*. Enables the redrawing of the graphics and list view after being disabled with the GRAPHICS\_OFF[] command.

Note: Graphics On is not a recordable macro command.

**GRAPHICS\_ON[]****GROOVE[ ]**

(Groove), *command*. Creates tool path to cut a groove on the inside diameter, outside diameter, or face of a part. {Pturn, Aturn}

**GROOVE[FX=#, FY=#, DW=#, DD=#, DA=#, DM=#, P1=#, P2=#, P3=#, P4=#, R1=#, R2=#, R3=#, R4=#, TS=#]**

FX = Anchor point X ordinate

Default: Null

FY = Anchor point Y ordinate

Default: Null

DW = Groove Width

Default: Null

DD = Groove Depth

Default: Null

DA = Finish Allowance

Default: Null

DM = Groove max width of cut

Default: Width of tool from Job Plan

P1 = T1 corner feature

0 = Sharp

1 = Radius

2 = Chamfer

Default: Null

P2 = T2 corner feature

0 = Sharp

1 = Radius

2 = Chamfer

Default: Null

P3 = B1 corner feature

0 = Sharp

1 = Radius

2 = Chamfer

Default: Radius is 1

P4 = B2 corner feature

0 = Sharp

1 = Radius

2 = Chamfer

Default: Radius is 1

R1 = T1 size value

Default: Null

R2 = T2 size value

Default: Null

R3 = B1 size value

Default: Corner radius specified in Job Plan

R4 = B2 size value

Default: Corner radius specified in Job Plan

TS = To size

Options: 0 = Off

1 = On:

Default: 0

**GROOVE\_RGH[ ]**

(Groove Rough), *command*. Creates tool path with straight-plunge roughing tool path to an ID, OD, or face profile. This command has been superceded by the TGROOVE[] macro command. An attempt has been made to make the former command forward compatible with newer command. {Pturn, Aturn}

Note: Groove Rough is not a recordable macro command.

**GROOVE\_RGH[ES=##, EE=##, XS=##, YS=##, EM=##, ZF=##, XF=##, DW=##, CL=##, CP=##, OP=##]**

ES = Finish profile start (required)

Default: None

EE = Finish profile end (required)

Default: None

XS = Z start (required)

Default: None

YS = X start (required)

Default: None

EM = Material element (required)

Default: None

ZF = Z finish amount (required)

Default: None

XF = X finish amount (required)

Default: None

DW = Pass width (required)

Default: None

CL = Clear (required)

Default: None

CP = Cleanup pass binary

0 = Off

1 = On

Default: 0

**GRP( )**

(Grouped element Index), *function*. Returns the element number of an element in the active group or the total number of elements in the active group.

**GRP(index)**

index = 0, returns the number of elements in the active group or -1 If there is no group.  
 index > 0, returns the element number of the nth element in the active group or -1 If the number is out of range.

**GRP\_BLEND[ ]**

(Group Blend), *command*. Adds or modifies blend elements (arcs) to corner elements in an active group of elements.

**GRP\_BLEND[RA=##, RO=##, RC=##]**

RA = Inside radius (required)

Default: Null

RO = Outside radius

Default: Null

RC = Change radius

Default: Null

**GRP\_CHAIN[ ]**

(Group Chain), *command*. Converts connected elements in the active group into contiguous profiles of sequential elements or polylines.

**GRP\_CHAIN[PJ=##]**

PJ = Polyline join

0 = Chain

1 = PolyJoin

2 = Both

Default: 0

**GRP\_DELETE[ ]**

(Group Delete), *command*. Deletes all elements in the active group.

**GRP\_DELETE[ ]****GRP\_FILT\_ADD[ ]**

(Group Filter Add), *command*. Adds all elements that satisfy the filter criteria to the active group.

**GRP\_FILT\_ADD[ ]****GRP\_FILT\_REMOVE[ ]**

(Group Filter Remove), *command*. Removes all elements that satisfy the filter criteria from the active group.

**GRP\_FILT\_REMOVE[ ]****GRP\_POCK[ ]**

(Group Pocket), *command*. Creates tool path for removing material from the inside of a group of closed profiles. {Pmill, Amill, Ffm, Aturn}

**GRP\_POCK[TY=##, FA=##, WC=##, AN=##, DC=##, EP=##, AR=##, UA=##, CC=##, RS=##, FL=##, CI=##, EW=##, OP=##, RM=##, RT=##, AC=##, RD=##, LY=##, NN=\$\$, UT=##]**

TY = Pocketing method

0 = Spiral

1 = Zigzag

2 = Linear

Default: 0

FA = Finish amount

Default: 0.0

WC = Width of cut (required)

AN = Pass angle

Default: 0.0

DC = Depth of cut (required)

EP = Equalized passes (modal)

0 = Off

1 = On

AR = Ramp angle

Default: 90.0 (vertical)

UA = Uncut area geometry—use

0 = Off

1 = On:

Default: 0

CC = Climb cut

0 = Conventional

1 = Climb

Default: 1

RS = Ramp from start

0 = Off, use ramp angle

1 = On, ramp from start point

FL = Floor allowance

Default: 0.0

CI = Cut inside out

0 = Off (cut outside in)

1 = On

Default: 1

EW = Equalize width passes

0 = Off

1 = On

Default: 0

OP = Overlap passes

0 = Off

1 = On

Default: 0

RM = Rough tolerance method

0 = Off, minimum

1 = On, Mid Tol

Default: 0

RT = Rough tolerance amount (distance)  
Default: 0.00005

AC = Corner roll angle  
Default: 60.0

RD = Rapid to depth  
0 = Off  
1 = On  
Default: 0

LY = Layer  
Default: 1

NN = AUM named group name  
Default: AUM

UT = Uncut material tolerance  
Default: 0.01

#### **GROUP\_POLYARC\_FIT[ ]**

(Group Polyarc Fit), *command*. Creates a series of lines and arcs that approximate a smooth fit, within desired tolerances, over polylines in the active group.

GROUP\_POLYARC\_FIT[TO=##, SA=##,  
LL=##, KP=##, MP=##]

TO = Fit tolerance (required)  
Default: 0.0005

SA = Sharp angle (required)  
Default: 34.0

LL = Long line (required)  
Default: 17.0

KP = Keep original code (required)  
0 = erase polyline from database and  
replace by polyarc profile  
1 =keep original code  
Default: 1

MP = Match properties code (required)  
0 = Use active properties  
1 = Use polyline  
Default: 1

#### **GRP\_REVERSE[ ]**

(Group Reverse), *command*. Reverses the direction and/or database order of profiles in the active group.

GRP\_REVERSE[RP=##]

RP = Reverse profile  
0 = Order and direction  
1 = Direction only  
2 = Order only  
Default: 0

#### **GRP\_TRIM[ ]**

(Group Trim), *command*. Trims or splits the active group of elements at the intersections with a selected profile or element.

GRP\_TRIM[EL=\$\$, S1=##, TS=##, TY=##,  
TO=##]

EL = Element in trimming profile (required)  
Default: None

S1 = Keep side (required)  
0 = Right  
1 = Left  
Default: None

TS = Trim/split  
0 = Trim  
1 = Split  
Default: 1

TY = Type  
0 = 2D  
1 = 3D  
Default: None

TO = Intersect tolerance  
Default: None

#### **GRP\_WALL[ ]**

(Group Wall), *command*. Creates parallel geometry that is offset from an existing, group of elements or profiles.

GRP\_WALL[SD=##, DS=##, ME=##,  
RP=##, LR=##, TA=##, TO=##, AN=##]

SD = Side (required)  
0 = Left  
1 = Right  
Default: None

DS = Distance (required)  
Default: None

ME = Match element's properties  
0 = No  
1 = Yes  
Default: 0

RP = Repeat  
1–999  
Default: 1

LR = Loop removal  
0 = No  
1 = Yes  
Default: 0

TA = Tolerance application  
0 = Off  
1 = On:  
Default: 0

TO = Tolerance amount  
Default: 0.000005 [0.001]

AN = Corner roll angle  
5–180  
Default: 180

**- H -****HELIX[ ]**

(Helix), *command*. Creates helical and spiral curves that travel at a constant or changing radius along a defined axis.

**HELIX[XS=##, YS=##, ZS=##, XE=##,  
YE=##, ZE=##, XC=##, YC=##, AS=##,  
AE=##, AT=##, RS=##, RE=##, DR=##,  
DS=##, FT=##, PT=##]**

XS = X start

Default: None

YS = Y start

Default: None

ZS = Z start

Default: None

XE = X end

Default: None

YE = Y end

Default: None

ZE = Z end

Default: None

XC = X center (required)

Default: None

YC = Y center (required)

Default: None

AS = Angle start

Default: None

AE = Angle end

Default: None

AT = Angle total

Default: None

RS = Radius start

Default: None

RE = Radius end

Default: None

DR = Direction

0 = CW, 1= CCW

Default: 0

DS = Distance (axis length)

Default: None

FT = Full turns

Default: None

PT = Pitch

Default: None

**HILITE[ ]**

(Highlight Item), *script*. Highlights an item in the user interface.

Note: Highlight Item only functions while running in the macro demo mode without using the default UI scripts.

**HILITE[\$\$]**

\$\$ = Name of main menu, pull down or workbench item

**HOLE[ ]**

(Hole), *command*. Creates a hole element at the selected location. {Pmill, Amill, Ffm, Pturn, Aturn, Awedm}

**HOLE[XE=##, YE=##, XS=##, YS=##,  
AN=##, DS=##, LV=##, RI=##, SE=##]**

XE = X end

Default: Null

YE = Y end

Default: Null

XS = X anchor

Default: Null

YS = Y anchor

Default: Null

AN = Angle

Default: Null

DS = Distance

Default: Null

LV = Level (modal)

RI = Radius input

0 = No

1 = Yes

SE = End solution designator

0 = +

1 = -

2 = N/A

Default: 0

Note: See PROPERTY to output other variables as needed.

**HOLE\_ALL[ ]**

(All Holes From Solid), *command*. Creates one or multiple hole elements using all the cylinders contained in an ACIS solid body. {Amill, Ffm}

**HOLE\_ALL[SE=##, WS=##, MA=##,  
SC=##, MD=##, HE=##, DI=##, TO=##]**

SE = Surface element. Element index.

(required) Indicates the search area.

WS = Entire Solid

1 = Yes

0 = No

Default: 1

MA = Match Axis

0 = No

1 = Yes

Default: 1

SC = Search split cylinders  
 0 = No  
 1 = Yes  
 Default: 0  
 MD = Match diameter  
 0 = No  
 1 = By example  
 2 = By value  
 Default: 0  
 HE = Cylindrical surface element. Element index. (required if MD = 1)  
 DI = diameter Positive floating point value  
 Default = 1.0  
 TO = Match diameter tolerance  
 Default: 0.001

**HOLE\_ONE[ ]**

(Single Hole From Solid), *command*.  
 Creates a hole elements using a cylinder contained in an ACIS solid body. {Amill, Ffm}

**HOLE\_ONE[SE=##, HI=##]**

SE = Surface element Indicates the search area.  
 HI = Hole index. Index of the hole within the search area.

**HOTSAVE[ ]**

(Save), *command*. Saves the current process model and job operations setup file to disk with the designated file name and type.

Note: No message box will be displayed prompting to overwrite If the file already exists on disk.

**HOTSAVE[FN=\$\$, FT=##]**

FN = Filename  
 Default: None

FT = File type  
 Non-ACIS SmartCAM products  
 0 = 2-D (.sh2)  
 1 = 3-D (.sh3)  
 2 = V6.x CAM Connect (.sh3)  
 3 = Process Model (.pm4)  
 Default: 3  
 FreeForm Machining and Advanced Milling only  
 0 = 2-D (.sh2)  
 1 = 3-D (.sh3)  
 2 = V6.x CAM Connect (.sh3)  
 3 = Process Model SAB (.pm4)  
 4 = No Surfaces (.pm4)

5 = FreeForm V4.6 (.pm4)  
 6 = Process Model SAT (.pm4)  
 Default: 4

- | -

**IF( )**

(Logical If), *command*. Performs a conditional test for the branching of operations within a macro. Part of a command set that includes IF( ), ELSE, ENDIF.

Note: Logical If is not a recordable macro command. Each IF command must be followed by a corresponding ENDIF command within the macro. The ELSE command is optional.

IF(expression)  
 true  
 ELSE  
 false  
 ENDIF

expression = A logic expression that may contain the following operators

=	(equal)
<>	(not equal)
>	(greater than)
>=	(greater than or equal to)
<	(less than)
<=	(less than or equal to)
,AND	(logical and)
,OR	(logical or)

true = Macro commands to be performed if the logic expression proves true.

False = Macro commands to be performed if the logic expression proves false

**IMPORT[ ]**

(Import), *command*. Imports external geometric models from ACIS, ATS, DXF, DWG, IGES, and VDA-FS files into a SmartCAM process model file.

**IMPORT[FN=\$\$, FTS=\$\$, EX=##, LU=##, LN=\$\$, SF=\$\$, TF=\$\$]**

FN = From Filename (required)

FTS = Import file type  
 SAT  
 SAB  
 ATS  
 DWG

DXF  
 IGESW or IGES  
 IGSS  
 VDAFS  
 EX = Export Solids  
   0 = On  
   1 = Off  
 MR = Model resolution choice (required)  
   0 = Default  
   1 = IGES Global Value  
   2 = ACIS RESABS  
   3 = User constant value  
 MV = Model resolution user constant value  
   (required)  
 EX = Explode solids (required)  
   0 = No explode  
   1 = Explode  
   Default: 0  
 LU = Log file—use (optional)  
   0 = No log file written  
   1 = Write log file  
   Default: 0  
 LN = Log file name (required)  
 SF = Setup File Name (required for CAM  
   Connection wireframe file types DWG,  
   DXF, IGES. Optional for other file  
   types.)  
   Default: from .ini file  
 TF = Temporary CAM Connection Output  
   File Name. (required for CAM  
   Connection file types DWG, DXF, IGES  
   Wireframe. Optional for other file types.)  
   Default: from .ini file

**INCREMENT[ ]**

(Increment), *command*. Sets the precision of coordinates and pointer movement in the graphic view, the pick distances for Snap, and the default behavior for the Snap Z-level setting.

**INCREMENT[DS=##, AN=##, PL=##,  
 TO=##, DZ=##, SZ=##]**

DS = Linear increment (distance)  
   Default: N/C  
 AN = Angular increment  
   Default: N/C  
 PL = Pick limit  
   Default: N/C  
 TO = Pick tolerance  
   Default: N/C  
 DZ = Default Z  
   0 = Off  
   1 = On:  
   Default: 1

SZ = Snap Z  
   0 = Off  
   1 = On:  
   Default: 1

**INT()**  
 (Integer), *function*. Returns the integer value of a numeric expression.

**INT(numexp)**

**INTEGER:**

(Declare Variable as Integer), *command*. Declares the variable that follows as a integer type.

Note: Declare Variable as Integer is not a recordable macro command. A variable must be declared as an integer prior to being assigned a value. Used primarily to manipulate variables shared by control panels and dialog boxes.

**INTEGER:variable**

**INTERSECT[ ]**

(Intersect), *command*. Trims the elements in the active group where a plane, cone, cylinder, sphere, or mesh intersects it.  
 {Amill, Ffm}

**INTERSECT[TY=\$\$, E1=\$\$, E2=\$\$, SD=##,  
 OA=##, KP=##, VT=##]**

TY = Type  
   0 = Plane  
   1 = Cone  
   2 = Sphere  
   3 = Mesh  
   Default: 0  
 E1 = Generator/start element (required)  
   Default: None  
 E2 = Director/end element (required)  
   Default: None  
 SD = Keep side (required)  
   0 = Positive  
   1 = Negative  
   Default: None  
 OA = Offset amount  
   Default: 0  
 KP = Keep pieces  
   0 = All  
   1 = First  
   2 = Last  
   Default: 0

VT = Virtual mesh tolerance  
Default: Global variable  
Initial default: 0.001

**INTPT[ ]**

(Intersection Points), *command*. Creates point elements at the intersections of the selected line or arc elements.

Note: Intersection Points is not a recordable macro command.

**INTPT[E1=\$\$, E2=\$\$]**

E1 = First element (required)

Default: None

E2 = Second element (required)

Default: None

**- J -**

**JOBFILE()**

(Job File), *function*. Returns the job file path plus job file name.

Note: Job File is not a recordable macro function.

**JOBFILE()**

**JOBINFO[ ]**

(Print Job Information), *command*. Prints the job information or creates a report file that contains job information for the open process model.

**JOBINFO[OM=##, FN=##, TS=##]**

OM = Output method

0 = Printer

1 = File

FN = Filename (required for OM=1)

TS = Tool setup

0 = No tool setup

1 = Tool

Default: 0

**JOBPLN[ ]**

(Job Plan), *command*. Attaches a different job file to the current process model.

**JOBPLN[FN=\$\$, JT=##]**

FN = Filename (required)

JT = Job type

0 = Read .jsf and convert to .jof

1 = Read .jof

Note: JT is ignored in .jsf mode and defaults to 0 in .jof mode.

**JOS()**

(Job Operation Setup), *function*. Returns the numeric value of a jos data tag.

**JOS(tag)**

tag = Any valid numeric data tag for information in the planner.

**JOS\_CONTEXT\_CLOSE[ ]**

(Jos Context Close), *command*. Closes a JOS data context opened by a call to one of the three JOS context open calls:

JOS\_CONTEXT\_OPEN,

JOS\_CONTEXT\_DUP, or

JOS\_CONTEXT\_NEW. Must be paired with one of these calls.

**JOS\_CONTEXT\_CLOSE[]**

**JOS\_CONTEXT\_DUP[ ]**

(Jos Context Duplicate), *command*. Opens a JOS context for editing by duplicating an item. Must be paired with a JOS\_CONTEXT\_CLOSE[] call.

**JOS\_CONTEXT\_DUP[BASEITEM=##,  
USERNAME=\$\$]**

BASEITEM = Basic Item for the Duplicate (required)

1 = Step (Duplicate a Step)

2 = Tool (Duplicate a tool assignment).

Default: None

USERNAME = User name of the basic item to be duplicated. (required)

The Step Number of the step to duplicate for steps or the Tool Number for the Tool to duplicate for Tools.

Default: None.

**JOS\_ITEM\_DUPLICATE[ ]**

(Jos Item Duplicate), *command*. Creates a new item in context by duplicating an existing item. The current item of the specified type is replaced in context.

**JOS\_ITEM\_DUPLICATE[BASEITEM=##,  
USERNAME=\$\$]**

BASEITEM = Basic Item for the Duplicate (required)

2 = Tool (duplicate a tool assignment).

Default: None.

USERNAME = User name of the basic item to be duplicated. (required)  
 The Tool Number for the Tool to duplicate for Tools.  
 Default: None.

**JOS\_FIELD\_EDIT[ ]**

(Jos Field Edit), *command*. Changes a JOS value. This must be within paired calls to one of the three JOS context open macros; JOS\_CONTEXT\_OPEN, JOS\_CONTEXT\_DUP, or JOS\_CONTEXT\_NEW and the JOS context close call: JOS\_CONTEXT\_CLOSE. Will not be retained as a JOS value unless followed by a JOS\_CHANGES\_PROMOTE call within the same JOS context changes pairing.

JOS\_FIELD\_EDIT[FLDNAME=\$\$,  
 EXPR=\$\$]

FLDNAME = The JOS data tag of the field to be changed. (required)  
 Possible values are given in the JOS Expressions specification.  
 Default: None.

EXPR = The expression to set the value to.  
 (required)  
 Any valid expression given as a string.  
 Default: None.

**JOS\_ITEM\_EDIT[ ]**

(Jos Item Edit), *command*. Brings an item into a JOS context for editing replacing the currently active item in the structure.

JOS\_ITEM\_EDIT[BASEITEM=##,  
 USERNAME=\$\$]

BASEITEM = Basic Item for the Edit  
 (required)  
 2 = Tool (edit a tool assignment).  
 Default: None

USERNAME = User name of the basic item to be edited. (required)  
 The Tool Number for the Tool to edit for Tools.  
 Default: None.

**JOS\_CONTEXT\_NEW[ ]**

(Jos Context New), *command*. Opens a JOS context for editing by creating a new item of the specified type. Must be paired with a JOS\_CONTEXT\_CLOSE[] call.

JOS\_CONTEXT\_NEW[BASEITEM=##,  
 NEWSNCS=##, USERNAME=\$\$]

BASEITEM = Basic Item for the New  
 (required)  
 1 = Step (Create a Step)  
 2 = Tool (Create a tool assignment).  
 Default: None

NEWSNCS = The Section number of the item to create. This provides defaults and specifies the user interface for the item. (required)  
 For Steps this will be an Op Section number (generally in the 1030000 - 1039999 range) as defined in the Global Specification  
 Shelf/Notebook/Chapter/Section. For Tools this will be a Tool Assembly Section number (generally in the range 2410000 - 2499999) as defined in the Global Specification  
 Shelf/Notebook/Chapter/Section.  
 Default: None

USERNAME = User name of the basic item after which the new item will be inserted.  
 If this is empty the item is added at the end of the list.  
 The Step Number of the insert step for steps or the Tool Number for the insert Tool to for Tool s.  
 Default: Empty String.

**JOS\_ITEM\_NEW[ ]**

(Jos Item New), *command*. Creates a new item in context from the specified Section number defaults.

JOS\_ITEM\_NEW[BASEITEM=##,  
 NEWSNCS=##]

BASEITEM = Basic Item for the New  
 (required)  
 2 = Tool (create a new Tool assignment).  
 8 = Operation (create a new Operation)  
 Default: None.

NEWSNCS = The Section number of the item to create. This provides defaults and specifies the user interface for the item. (required)  
 For Operations this will be an Op Section number (generally in the 1030000 - 1039999 range) as defined in the Global Specification  
 Shelf/Notebook/Chapter/Section. For Tools this will be a Tool Assembly Section number (generally in the range

<p>2410000 -2499999) as defined in the Global Specification Shelf/Notebook/Chapter/Section. Default: None</p> <p><b>JOS_CONTEXT_OPEN[ ]</b> (Jos Context Open), <i>command</i>. Opens a JOS context for editing. Must be paired with a JOS_CONTEXT_CLOSE[] call.</p> <p>JOS_CONTEXT_OPEN[BASEITEM=##, USERNAME=\$\$]</p> <p>BASEITEM = Basic Item for the Edit (required) 1 = Step (Open a Step changes context) 2 = Tool (open a tool assignment edit context) 6 = Job Info (open a job information edit context). Default: None</p> <p>USERNAME = User name of the basic item to be edited. (required) The Step Number of the step to edit for steps, the Tool Number for the Tool to edit for Tools, or an empty string for Job Information editing. Default: None</p> <p><b>JOS_CHANGES_PROMOTE[ ]</b> (Jos Changes Promote), <i>command</i>. Commits all active changes to a JOS context to the current JOS data. This must be within paired calls to one of the three JOS context open macros: JOS_CONTEXT_OPEN, JOS_CONTEXT_DUP, or JOS_CONTEXT_NEW and the JOS context close call: JOS_CONTEXT_CLOSE.</p> <p>JOS_CHANGES_PROMOTE[]</p> <p><b>JOS_STR()</b> (Job Operations Setup String), <i>function</i>. Returns the string value of a jos data tag.</p> <p>JOS_STR(tag) tag = Any valid string data value from the planner</p> <p><b>JTOOL()</b> (Job Tool), <i>function</i>. Returns tool number of a specified element.</p> <p>JTOOL(elnum) Returns tool number of a specified element.</p>	<p><b>JTOOL_SEQ[ ]</b> (Job Tool Sequence), <i>command</i>. Sets the insert properties to insert new elements before the first use, or after the last use of the identified tool. Note: This replaces TOOL SEQUENCE in applications using Job Operations Setup.</p> <p>JTOOL_SEQ[BA=##, TL=##, ME=##]</p> <p>BA = Before/after 0 = Before 1 = After Default: 1</p> <p>TL = Tool (required) Valid tool number Default: None</p> <p>ME = Match element (modal) 0 = Off 1 = On</p> <p style="text-align: center;"><b>- K -</b></p> <p><b>KILL_PLANE[ ]</b> (Kill Plane). <i>command</i>. Deletes un-reserved work planes that do not have elements associated with them.</p> <p>KILL_PLANE[WP=\$\$]</p> <p>WP = Plane name ? = Wild character * = Wildcard (kill all unused planes)</p> <p style="text-align: center;"><b>- L -</b></p> <p><b>LAST_VIEW[ ]</b> (Last View), <i>command</i>. Returns the graphics to the previously active view.</p> <p>LAST_VIEW[]</p> <p><b>LAY()</b> (Layer), <i>function</i>. Returns layer assignment of selected element.</p> <p>LAY(elnum) -1 = when element is with step</p> <p><b>LAYER_GRP[ ]</b> (Layer Group), <i>command</i>. Adds or removes elements to the active group according to their layer assignment.</p>
--	--

LAYER\_GRP[LY=##, AR=##]

LY = Layer (required)

Default: None

AR = Add/remove (modal)

0 = Add

1 = Remove

### LAYER\_SEQ[ ]

(Layer Sequence), *command*. Sets the insert properties to insert new elements before the first use, or after the last use of the identified layer.

LAYER\_SEQ[BA=##, LY=##, ME=##]

BA = Before/after

0 = Before

1 = After

Default: 1

LY = Layer (required)

Valid layer number

Default: None

ME = Match element (modal)

0 = Off

1 = On

### LEAD\_IN[ ]

(Lead In/Out), *command*. Creates lines or arcs to produce gradual tool-feed movement into and out of a profile.

LEAD\_IN[EL=\$\$, AN=##, DS=##, RA=##,  
D2=##, LC=##, TY=##, CS=##, RX=##,  
RY=##, RP=##, MO=##]

EL = Element (required)

Default: None

AN = Angle

Default: Null

DS = Distance (length of line)

Default: Null

RA = Radius (for arc)

Default: Null

D2 = Distance perpendicular

Default: Null

LC = Location

0 = In

1 = Out

2 = Both

Default: 2

TY = Type

0 = Line

1 = Arc

2 = Both

Default: 0

CS = Change start

0 = No

1 = Yes

Default: 0

RX = Reference Point X

Default: None

RY = Reference Point Y

Default: None

RP = Use reference point

0 = No

1 = Yes

Default: 0

MO = Line offset match

0 = Off, no offset line

1 = OFFSET on lines match profile  
offset

Default: Off

### LEAVE[ ]

(Exit), *command*. Closes the SmartCAM application.

LEAVE[]

Note: This does not test for file modification  
in macro  
execution.

### LEN( )

(Length), *function*. Returns the length value or hole depth of selected element.

LEN(element)

element = Element number or name

### LENE( )

(Element Path Length), *function*. Returns the path length of selected element.

Note: You cannot use this function on a helix. If you use this in a macro to measure a helix, SmartCAM will display an error message.

LENE(element)

element = Element number or name

### LENP( )

(Profile Path Length), *function*. Returns the path length of the profile of selected element.

Note: You cannot use this function on a helix. If you use this in a macro to measure a helix, SmartCAM will display an error message.

LENP(element)

element = Element number or name

**LINE[ ]**(Line), *command*. Creates a line element.

**LINE[XS=##, YS=##, XE=##, YE=##, XI=##,  
YI=##, AN=##, DS=##, TS=\$\$, TE=\$\$,  
SS=##, SE=##, PK=##]**

XS = X start  
Default: Null

YS = Y start  
Default: Null

XE = X end  
Default: Null

YE = Y end  
Default: Null

XI = X intermediate  
Default: Null

YI = Y intermediate  
Default: Null

AN = Angle  
Default: Null

DS = Distance (length)  
Default: Null

TS = Start tangent element  
Arc element number  
Default: Null

TE = End tangent element  
Arc element number  
Default: Null

SS = Start solution designator  
0 = +  
1 = -  
2 = N/A

Default: 0  
SE = End solution designator  
0 = +  
1 = -  
2 = N/A  
Default: 0

PK = Peck  
0 = Off  
1 = On:

ZE = Z end

ZI = Z intermediate

ZS = Z start

**LINE\_PROF[ ]**(Line Profile), *command*. Adds a line as part of a continuous profile.

**LINE\_PROF[XE=##, YE=##, XI=##, YI=##,  
XJ=##, YJ=##, AN=##, DS=##, TI=##,  
SS=##, SE=##, SP=##]**

XE = X end  
Default: Null

YE = Y end

Default: Null

XI = First intermediate X

Default: Null

YI = First intermediate Y

Default: Null

XJ = Second intermediate X

Default: Null

YJ = Second intermediate Y

Default: Null

AN = Angle

Default: Null

DS = Distance (length)

Default: Null

TI = Tangent/intersect to previous element

0 = Intersect

1 = Tangent

Default: 1

SS = Solution start

0 = +

1 = -

2 = N/A

Default: 0

SE = Solution end

0 = +

1 = -

2 = N/A

Default: 0

SP = Solution pending

0 = +

1 = -

2 = N/A

Default: 0

**LINEAR\_RGH[ ]**(Linear Roughing), *command*. Creates tool path with straight line roughing passes that are parallel to each other and equal distances apart. This macro command has been superceded by the TLINEAR[] macro command. An attempt has been made to make the former command forward compatible with newer command. {Pturn, Aturn}

Note: Linear Roughing is not a recordable macro command.

**LINEAR\_RGH[TY=##, ES=##, EE=##,  
XS=##, YS=##, EM=##, ZF=##, XF=##,  
DP=##, CL=##, AN=##, AP=##, CP=##,  
OP=##]**

TY = Type of operation

0 = Turning

1 = Facing

Default: 0

ES = Finish profile start (required) Default: None	1 = Along 2 = Planar Default: 0
EE = Finish profile end (required) Default: None	SP = Spacing (type) 0 = Distance 1 = Count 2 = Cusp Hgt Default: 0
XS = Z start Default: None	SV = Spacing value (required) Default: None
YS = X start Default: None	ZT = Planar Z, Z top Default: 0.0
EM = Material element Default: None	DI = Division (type) 0 = Distance 1 = Count 2 = Mid Tol 3 = In Tol 4 = Out Tol Default: 0
ZF = Z finish amount (required) Default: None	DV = Division value (required) Default: None
XF = X finish amount (required) Default: None	OF = Offset 0 = Positive 1 = Negative 2 = 0 Default: 2
DP = Pass depth (required) Default: None	OA = Finish offset amount Default: 0.0
CL = Clear (required) Default: None	CM = Connect mesh 0 = Off 1 = On Default: 0
AN = Pass angle (required) Default: None	GC = Gouge correction 0 = Off 1 = On Default: 0
AP = Plunge angle (required) Default: None	
CP = Cleanup pass 0 = Off 1 = On Default: 0	
OP = Overlap passes binary 0 = Off 1 = On Default: None	
<b>LNUM( )</b> (Layer Number), <i>function</i> . Returns the active layer number or -1 if a step number.	
<b>LNUM()</b>	
<b>LOFTED[ ]</b> (Lofted Mesh), <i>function</i> . Creates sculpted mesh profiles that travel over a series of sequential cross-section profiles.	<b>LVL( )</b> (Level), <i>function</i> . Returns level value of selected element.
LOFTED[XS=\$\$, YS=\$\$, ZS=\$\$, PD=##, SP=##, SV=##, ZT=##, DI=##, DV=##, OF=##, OA=##, CM=##, GC=##]	LVL (elnum)
XS = X start Valid ordinate value Default: 0.0	<b>- M -</b>
YS = Y start Valid ordinate value Default: 0.0	
ZS = Z start Valid ordinate value Default: 0.0	
PD = Path direction 0 = Cross	<b>MAC_DEMO[ ]</b> (Macro Demo), <i>command</i> . Executes an existing macro including the display of menu picks and panel interaction.
	MAC_DEMO[FN=\$\$, SP=##, DS=##]
	FN = Filename (required) Default: None

SP = Speed (required)

0–9

Default: None

DS = Default UI script (required)

0 = Off

1 = On

Default: None

### **MAC\_EXE[ ]**

(Macro Execute), *command*. Executes an existing macro without displaying the menu picks or panel interaction.

**MAC\_EXE[FN = \$\$]**

FN = Filename (required)

Default: None

### **MASK[ ]**

(Show/Mask), *command*. Will hide or show elements or to mask elements by Z level in the graphic view.

**MASK[ST=##,TL=##, LY=##, WP=##,  
SH=##, ZT=##, ZB=##]**

ST = STEP

Valid step number, step range, or wildcard

Default: Null

TL = Tool

Valid tool number, tool range, or wildcard

Default: Null

LY = Layer

Valid layer number, layer range, or wildcard

Default: Null

WP = Work plane

Default: Null

SH = Show/hide

0 = Hide

1 = Show

Default: 1

ZT = Mask Z top

ZB = Mask Z Bottom

Note: MASK[ ] shows all Z levels.

### **MCLFILE( )**

(Macro File), *function*. Returns the macro path plus current executing macro name.

**MCLFILE()**

### **MEAS\_2D\_EL( )**

(Measure 2D to Element), *function*. Returns the 2D distance between a point and an element.

**MEAS\_2D\_EL(x, y, elnum)**

x = 1<sup>st</sup> Point X (required)

Default: None

y = 1<sup>st</sup> Point Y (required)

Default: None

elnum = Element name or number (required)

Default: None

### **MEAS\_2D\_PT( )**

(Measure 2D to Point), *function*. Returns the 2D distance between two points.

**MEAS\_2D\_PT(x1, y1, x2, y2)**

x1 = 1<sup>st</sup> Point X (required)

Default: None

y1 = 1<sup>st</sup> Point Y (required)

Default: None

x2 = 2<sup>nd</sup> Point X (required)

Default: None

y2 = 2<sup>nd</sup> Point Y (required)

Default: None

### **MEAS\_3D\_PT( )**

(Measure 3D to Point), *function*. Returns the 3D distance between two points.

**MEAS\_3D\_PT(x1, y1, z1, x2, y2, z2)**

x1 = 1<sup>st</sup> Point X (required)

Default: None

y1 = 1<sup>st</sup> Point Y (required)

Default: None

z1 = 1<sup>st</sup> Point Z (required)

Default: None

x2 = 2<sup>nd</sup> Point X (required)

Default: None

y2 = 2<sup>nd</sup> Point Y (required)

Default: None

z2 = 2<sup>nd</sup> Point Z (required)

Default: None

### **MERGE[ ]**

(Merge), *command*. Inserts geometry from a model file on disk into the current process model.

**MERGE[FN=\$\$, FT=##, XS=##, YS=##,  
ZS=##]**

FN = Filename (required)

FT = File type  
 0 = 2-D (.sh2)  
 1 = 3-D (.sh3)  
 2 = PM4 (.pm4)  
 Default: 1  
 XS = Base point (required)  
 YS = Base point (required)  
 ZS = Base point (required)

**MERGE\_PLANE[ ]**

(Merge Plane), *command*. Combines elements associated with one or more selected work planes with the first parallel work plane found in the dialog box list.

MERGE\_PLANE[WP=\$\$, MO=##]

WP = Plane name  
 ? = Wild character  
 \* = Wildcard  
 MO = Merge opposite  
 0 = Off  
 1 = On  
 Default: 0

**MIRROR[ ]**

(Mirror), *command*. Creates a reverse, or "mirror," image of the elements in the active group.

MIRROR[XS=##, YS=##, ZS=##, XE=##,  
 YE=##, ZE=##, XI=##, YI=##, ZI=##,  
 CP=##, TS=##, RP=##, TY=##, SP=##]

XS = 1<sup>st</sup> Point X (required)  
 Default: None  
 YS = 1<sup>st</sup> Point Y (required)  
 Default: None  
 ZS = 1<sup>st</sup> Point Z (required for 3D)  
 Default: None  
 XE = 2<sup>nd</sup> Point X (required)  
 Default: None  
 YE = 2<sup>nd</sup> Point Y (required)  
 Default: None  
 ZE = 2<sup>nd</sup> Point Z (required for 3D)  
 Default: None  
 XI = 3<sup>rd</sup> Point X (required for 3D)  
 Default: None  
 YI = 3<sup>rd</sup> Point Y (required for 3D)  
 Default: None  
 ZI = 3<sup>rd</sup> Point Z (required for 3D)  
 Default: None  
 CP = Copy  
 0 = No  
 1 = Yes  
 Default: 0

TS = Tool sort  
 0 = Off  
 1 = On  
 Default: 1  
 RP = Reverse Order and Direction  
 0 = No  
 1 = Yes  
 TY = Type  
 0 = 2D  
 1 = 3D  
 SP = Suppress Planes  
 0 = No  
 1 = Yes

**MO\_SPLINE[ ]**

(Modify Spline), *command*. Changes the geometric information for an existing spline element.

MO\_SPLINE[EL=\$\$, IS=##, JS=##, KS=##,  
 IE=##, JE=##, KE=##, DS=##, DE=##,  
 CE=##, CL={ } or #CLVAR]

EL = Element number or name

IS = Start vector I

Default: Null

JS = Start vector J

Default: Null

KS = Start vector K

Default: Null

IE = End vector I

Default: Null

JE = End vector J

Default: Null

KE = End vector K

Default: Null

DS = Start vector distance (length)

Default: 0.0

DE = End vector distance (length)

Default: 0.0

CE = Close end

0 = No

1 = Yes

Default: 0

CL = Coordinate list (required)

A coordinate list or a variable declared as a coordinate list

Default: None

**MOD\_ARC[ ]**

(Modify Arc), *command*. Changes the geometric information for an existing selected arc element.

MOD\_ARC[EL=\$\$, XC=##, YC=##, XS=##,  
 YS=##, XE=##, YE=##, XI=##, YI=##,  
 SS=##, SC=##, TS=\$\$, AS=##, SE=##,

TE=\$\$, AE=##, SI=##, TI=\$\$, DR=##,  
RA=##, LV=##]

EL = Element number or name  
XC = X center  
Default: Null  
YC = Y center  
Default: Null  
XS = X start  
Default: Null  
YS = Y start  
Default: Null  
XE = X end  
Default: Null  
YE = Y end  
Default: Null  
XI = X intermediate  
Default: Null  
YI = Y intermediate  
Default: Null  
SS = Start solution designator  
0 = +  
1 = -  
2 = N/A  
Default: 0  
SC = Center solution designator  
0 = +  
1 = -  
2 = N/A  
Default: 0  
TS = Start tangent  
Arc or line element number  
Default: Null  
AS = Start angle  
Default: Null  
SE = End solution designator  
0 = +  
1 = -  
2 = N/A  
Default: 0  
TE = End tangent  
Arc or line element number  
Default: Null  
AE = End angle  
Default: Null  
SI = Intermediate solution designator  
0 = +  
1 = -  
2 = N/A  
Default: 0  
TI = Intermediate tangent  
Arc or line element number  
Default: Null  
DR = Direction  
0 = CW  
1 = CCW  
Default: 0

RA = Radius  
Default: Null  
LV = Level (modal)

**MOD\_DRLS[ ]**

(Modify Drill Subroutine), *command*.  
Changes the geometric information for an existing selected drill call element. {Pmill, Amill, Ffm}

MOD\_DRLS[EL=\$\$, NN=##, CP=##,  
XE=##, YE=##, ZE=##, PK=##]

EL = Element number or name  
NN = Name of subroutine  
Default: None  
CP = Number of repeats  
Default: 0  
XE = Insert point X coordinates  
YE = Insert point Y coordinates  
ZE = Insert point Z coordinates  
PK = Peck  
0 = Off  
1 = On:

**MOD\_ELLIPSE[ ]**

(Modify Ellipse), *command*. Changes the geometric information for an existing selected ellipse element.

MOD\_ELLIPSE[EL=\$\$, D1=##, D2=##,  
XC=##, YC=##, XS=##, YS=##, XE=##,  
YE=##, AS=##, AE=##, AN=##, DR=##,  
SS=##, SE=##, LV=##]

EL = Element number or name  
D1 = Primary distance (required)  
Default: None  
D2 = Secondary distance (required)  
Default: None  
XC = X center (required)  
Default: None  
YC = Y center (required)  
Default: None  
XS = X start  
Default: Null  
YS = Y start  
Default: Null  
XE = X end  
Default: Null  
YE = Y end  
Default: Null  
AS = Angle start  
Default: Null  
AE = Angle end  
Default: Null

AN = Angle of inclination  
Default: 0.0

DR = Direction  
0 = CW

1 = CCW  
Default: 0

SS = Solution start  
0 = +

1 = -

2 = N/A

Default: 0

SE = Solution end  
0 = +

1 = -

2 = N/A

Default: 0

LV = Level (modal)

### **MOD\_FAB\_HOLE[ ]**

(Modify Fab Hole), command. Changes the geometric information for an existing selected fab hole element.

MOD\_FAB\_HOLE[EL=\$\$, XE=##, YE=##,  
XS=##, YS=##, AE=##, AN=##, DS=##,  
LV=##, RI=##, SE=##]

EL = Element number or name

XE = X end  
Default: Null

YE = Y end  
Default: Null

XS = X anchor  
Default: Null

YS = Y anchor  
Default: Null

AE = Tool angle  
Default: Null

AN = Angle  
Default: Null

DS = Distance  
Default: Null

LV = Level  
Default: Modal

RI = Radius input  
0 = No

1 = Yes

SE = End solution designator  
0 = +

1 = -

2 = N/A

Default: 0

### **MOD\_GROOVE[ ]**

(Modify Groove), command. Changes the geometric information for an existing selected groove element.

MOD\_GROOVE[EL=\$\$, FX=#, FY=#,  
DW=#, DD=#, DA=#, DM=#, P1=#,  
P2=#, P3=#, P4=#, R1=#, R2=#, R3=#,  
R4=#, TS=#]

EL = Element number or name

FX = Anchor point X ordinate

Default: Null

FY = Anchor point Y ordinate

Default: Null

DW = Groove Width

Default: Null

DD = Groove Depth

Default: Null

DA = Finish Allowance

Default: Null

DM = Groove max width of cut

Default: Width of tool from Job Plan

P1 = T1 corner feature

0 = Sharp

1 = Radius

2 = Chamfer

Default: Null

P2 = T2 corner feature

0 = Sharp

1 = Radius

2 = Chamfer

Default: Null

P3 = B1 corner feature

0 = Sharp

1 = Radius

2 = Chamfer

Default: Radius is 1

P4 = B2 corner feature

0 = Sharp

1 = Radius

2 = Chamfer

Default: Radius is 1

R1 = T1 size value

Default: Null

R2 = T2 size value

Default: Null

R3 = B1 size value

Default: Corner radius specified in Job Plan

R4 = B2 size value

Default: Corner radius specified in Job Plan

TS = To size

Options: 0 = Off

1 = On:

Default: 0

**MOD\_HELIX[ ]**

(Modify Helix), *command*. Changes the geometric information for an existing selected helix element.

**MOD\_HELIX[EL=\$\$, XS=##, YS=##,  
ZS=##, XE=##, YE=##, ZE=##, XC=##,  
YC=##, AS=##, AE=##, AT=##, RS=##,  
RE=##, DR=##, DS=##, FT=##, PT=##]**

EL = Element number or name

XS = X start

Default: None

YS = Y start

Default: None

ZS = Z start

Default: None

XE = X end

Default: None

YE = Y end

Default: None

ZE = Z end

Default: None

XC = X center (required)

Default: None

YC = Y center (required)

Default: None

AS = Angle start

Default: None

AE = Angle end

Default: None

AT = Angle total

Default: None

RS = Radius start

Default: None

RE = Radius end

Default: None

DR = Direction

0 = CW, 1= CCW

Default: 0

DS = Distance (axis length)

Default: None

FT = Full turns

Default: None

PT = Pitch

Default: None

**MOD\_HOLE[ ]**

(Modify Hole), *command*. Changes the geometric information for an existing selected hole element. {Pmill, Amill, Ffm, Pturn, Aturn, Awedm}

**MOD\_HOLE[EL=\$\$, XE=##, YE=##,  
XS=##, YS=##, AN=##, DS=##, LV=##,  
RI=##, SE=##]**

EL = Element number or name

XE = X end

Default: Null

YE = Y end

Default: Null

XS = X anchor

Default: Null

YS = Y anchor

Default: Null

AN = Angle

Default: Null

DS = Distance

Default: Null

LV = Level (modal)

RI = Radius input

0 = No

1 = Yes

SE = End solution designator

0 = +

1 = -

2 = N/A

Default: 0

Note: See PROPERTY CHANGE to alter other variables as needed.

**MOD\_LINE[ ]**

(Modify Line), *command*. Changes the geometric information for an existing selected line element.

**MOD\_LINE[EL=\$\$, XS=##, YS=##, XE=##,  
YE=##, XI=##, YI=##, AN=##, DS=##,  
TS=\$\$, TE=\$\$, SS=##, SE=##, PK=##]**

EL = Element number or name

XS = X start

Default: Null

YS = Y start

Default: Null

XE = X end

Default: Null

YE = Y end

Default: Null

XI = X intermediate

Default: Null

YI = Y intermediate

Default: Null

AN = Angle

Default: Null

DS = Distance (length)

Default: Null

TS = Start tangent element

Arc element number

Default: Null

TE = End tangent element  
Arc element number  
Default: Null

SS = Start solution designator  
0 = +  
1 = -  
2 = N/A  
Default: 0

SE = End solution designator  
0 = +  
1 = -  
2 = N/A  
Default: 0

PK = Peck  
0 = Off  
1 = On:

ZE = Z end

ZI = Z intermediate

ZS = Z start

**MOD\_POINT[ ]**

(Modify Point), *command*. Changes the geometric information for an existing selected point element.

MOD\_POINT[EL=\$\$, XE=##, YE=##,  
XS=##, YS=##, AN=##, DS=##, LV=##,  
CO=##, SE=##]

EL = Element number or name  
XE = X end  
Default: Null

YE = Y end  
Default: Null

XS = X anchor  
Default: Null

YS = Y anchor  
Default: Null

AN = Angle  
Default: Null

DS = Distance  
Default: Null

LV = Level (modal)

CO = Clear Only  
0 = Off  
1 = On  
Default: 0

SE = End solution designator  
0 = +  
1 = -  
2 = N/A  
Default: 0

**MOD\_POLYLINE[ ]**

(Modify Polyline), *command*. Changes the geometric information for an existing selected polyline element.

MOD\_POLYLINE[EL=\$\$, CE=##, CL={} or  
#CLVAR]  
#clvar can be used instead of CL{}.

EL = Element number or name

CE = Close ends

0 = No

1 = Yes

Default: 0

CL = Coordinate list (required)

A coordinate list or a variable declared as a coordinate list

Default: None

Note: See COORDINATE LIST.

**MOD\_PO5X[ ]**

(Modify % Axis Polyline), *command*. Changes the geometric information for an existing selected 5 axis polyline element. {Awedm}

MOD\_PO5X[EL=\$\$, CE=##, CL={x, y, z, u,  
v, w, ... x, y, z, u, v, w} or #CLVAR]  
#clvar can be used instead of CL{}. The default on macro record is DM = 4

EL = Element number or name

CE = Close ends

0 = No

1 = Yes

Default: 0

CL = Coordinate list (required)

A coordinated list or variable declared as coordinate list.

**MOD\_SUBROUTINE[ ]**

(Modify Subroutine), *command*. Changes the geometric information for an existing selected sub call element. {Pmill, Amill, Ffm, Afab, Awedm}

MOD\_SUBROUTINE[EL=\$\$, NN=##,  
CP=##, UE=##, XE=##, YE=##, ZE=##,  
AS=##, RR=##]

EL = Element number or name

NN = Name of subroutine (required)

CP = Number of repeats to create

Default: 0

UE = Use properties of grouped elements

0 = No

1 = Yes

XE = Insert point X coordinates

YE = Insert point Y coordinates

ZE = Insert point Z coordinates

AS = Start angle

Default: 0

RR = Rotate repeats

0 = No

1 = Yes

Default: 0

### **MOD\_THREAD[ ]**

(Modify Thread), *command*. Changes the geometric information for an existing selected thread element. {Pturn, Aturn}

```
MOD_THREAD[EL=$$, ND=##, PT=##,
YS=##, XS=##, YE=##, XE=##, CX=##,
AN=##, AL=##, DS=##, CL=##, TL=##,
FN=$$]
```

EL = Element number or name

ND = Nominal diameter

Default: Null

PT = Pitch

Default: Null

YS = X root start

Default: Null

XS = Z root start

Default: Null

YE = X root end

Default: Null

XE = Z root end

Default: Null

CX = Crest X at start

Default: Null

AN = Taper angle

Default: Null

AL = Axial length

Default: Null

DS = First pass depth

Default: Null

CL = Clear

Default: Null

TL = Thread lead in

Default: Null

FN = Thread table filename

Default: Null

Note: The values required to define a Thread are Root Start and End, Crest, Clearance, Pitch, and depth of first pass. Any of these values can be calculated from other inputs as defined in interactive operations.

Note: If a thread table (FN) is not specified, the macro looks for the default thread table if a nominal diameter (ND) variable is in the option list. Both the ND and FN variables need to be removed from the command list to avoid using a thread table and ensure that the hard-

coded values in the command are used as is.

Note: If a thread lookup table is specified, it writes to the fields not specified in the Macro; changing values of entered data if need be.

### **MOD\_TXT[ ]**

(Modify Text), *command*. Changes the geometric information for an existing selected text element.

```
MOD_TXT[EL=$$, FN=$$, TX=$$, XC=##,
YC=##, XS=##, YS=##, AN=##, RA=##,
HT=##, TY=##, LV=##]
```

EL = Element number or name

FN = Filename of font file (modal)

TX = Text string (required)

Default: None

XC = X center

Default: Null

YC = Y center

Default: Null

XS = X start

Default: Null

YS = Y start

Default: Null

AN = Angle start

Default: Null

RA = Radius

Default: Null

HT = Height (required)

Default: None

TY = Type (text orientation)

0 = Linear

1 = CW

2 = CCW

Default: 2

LV = Level

Default: Null

### **MOD\_UEVENT[ ]**

(Modify User Event), *command*. Changes the geometric information for an existing selected user command element.

```
MOD_UEVENT[EL=$$, XS=##, YS=##,
LV=##, TX=$$]
```

EL = Element number or name

XS = Start point X coordinate (required)

Default: None

YS = Start point Y coordinate (required)

Default: None

LV = Level

Default: None

TX = Text string (required)  
 Default: None

**MOD\_LINK[ ]**

(Modify Links), *command*. Changes the start and end points of links between elements that control the wire inclination between the primary and secondary profiles at various points along the profiles. {Awedm}

MOD\_LINK[EL=\$\$, XS=##, YS=##, ZS=##,  
 XE=##, YE=##, ZE=##]

EL = Element number or name of link to modify (required)

Default: None

XS = X coordinate for link start point  
 Default: None

YS = Y coordinate for link start point  
 Default: None

ZS = Z coordinate for link start point  
 Default: None

XE = X coordinate for link end point (required)

Default: None

YE = Y coordinate for link end point (required)

Default: None

ZE = Z coordinate for link end point (required)

Default: None

**MOVE[ ]**

(Move), *command*. Changes the location of the active group of elements or, with the Copy option, creates one or more copies to new locations.

MOVE[CP=##, NC=##, TS=##, XS=##,  
 YS=##, XE=##, YE=##]

CP = Copy mode (overrides NC if false)

0 = Off

1 = On

Default: 0

NC = Num. of copies (requires CP=1 to work)  
 0-999

Default: 1

TS = Tool sort (modal)

0 = Off

1 = On

XS = X start

Default: 0.0

YS = Y start

Default: 0.0

XE = X end (required)

Default: None

YE = Y end (required)

Default: None

**MOVE\_REF[ ]**

(Move Reference), *command*. Changes the location of the active group of elements or, with the Copy option, move one or more copies while changing from the current work plane to a destination plane.

MOVE\_REF[DP=\$\$, CP=##]

DP = Destination plane (required)

Default: None

CP = Copy mode (overrides NC if false)

0 = Off

1 = On

Default: 0

**- N -****NAME\_ELMT[ ]**

(Name Element), *command*. Assign a name to an element and place the element's name in the element list.

NAME\_ELMT[EL=\$\$, EN=\$\$]

EL = Element number or name to be named (required)

Default: None

EN = Name of element (required)

Default: None

**NAME\_GRP[ ]**

(Name Group), *command*. Assigns a name to the current active group to retrieve for future use.

NAME\_GRP[GN=\$\$, RM=##]

GN = Group name (required)

Valid name

Default: None

RM = Remove

0 = Off

1 = On

Default: 0

**NAME\_VIEW[ ]**

(Name View), *command*. Assigns a name to the current view orientation.

NAME\_VIEW[VN=\$\$, RM=##]

VN = View name  
Default: None

RM = Remove  
0 = No  
1 = Yes  
Default: 0

**NEST\_MOV[ ]**

(Nest Move), *command*. Moves or copies elements in the active group on a two-dimensional plane. {Afab}

NEST\_MOV[XS=##, YS=##, XE=##,  
YE=##, CP=##, ST=##]

XS = X From Point (required)  
Default: None

YS = Y From Point (required)  
Default: None

XE = X To Point (required)  
Default: None

YE = Y To Point (required)  
Default: None

CP = Copy

0 = Move  
1 = Copy

ST = Sort by tools  
0 = No  
1 = Yes

**NEST\_PAR[ ]**

(Nest Parallel), *command*. Moves, rotates, or copies elements in the active group parallel to a reference element on a two-dimensional plane. {Afab}

NEST\_PAR[RE=\$\$, PE=\$\$, XS=##, YS=##,  
CP=##, ST=##, SP=##]

RE = Reference element  
Default: None

PE = Parallel element  
Default: None

XS = X From Point (required)  
Default: None

YS = Y From Point (required)  
Default: None

CP = Copy  
0 = Move  
1 = Copy

ST = Sort by tools  
0 = No  
1 = Yes

SP = Space  
Default: 0

**NEST\_ROT[ ]**

(Nest Rotate), *command*. Rotates or copies elements in the active group around a point on a two-dimensional plane. {Afab}

NEST\_ROT[XS=##, YS=##, RI=##, CP=##,  
ST=##]

XS = X From Point (required)

Default: None

YS = Y From Point (required)

Default: None

RI = Rotation increment

CP = Copy

0 = Move

1 = Copy

ST = Sort by tools

0 = No

1 = Yes

**NEW[ ]**

(New, Load Job File), *command*. Creates a new CNC Process Model using the current default unit of measurement or units specified by optionally loading a job file.

Note: New, Load job File is not a recordable macro command.

NEW[FN=\$\$, JT=##]

FN = Filename (optional)

JT = Job type

0 = Read .jsf and convert to .jof

1 = Read .jof

Note: JT is ignored in .jsf mode and defaults to 0 in .jof mode.

**NEW\_GRP[ ]**

(New Group), *command*. Removes all elements, from an active group.

NEW\_GRP[]

**NEW\_INCH[ ]**

(New Inch), *command*. Creates a new CNC Process Model using inch units of measurement.

NEW\_INCH[]

**NEW\_METRIC[ ]**

(New Metric), *command*. Creates a new CNC Process Model using metric units of measurement.

NEW\_METRIC[]

**NOCORE[ ]**

(No Core), *command*. Creates a continuous tool path that removes all the material within a boundary without any scrap pieces.  
 {Awedm}

NOCORE[EL=##, XC=##, YC=##, HR=##,  
 FA=##, FC=##, WC=##, LW=##]

EL = Outside boundary element (required)

Default: None

XC = X center of start hole (required)

Default: None

YC = Y center of start hole (required)

Default: None

HR = Start hole diameter (required)

Default: None

FA = Finish amount

Default: 0.0

FC = Finish pass count

Default: 1

WC = Width of cut

Default: None

LW = Last width of cut

Default: None

**NORMDRAW[ ]**

(Normals Draw), *command*. Creates temporary arrows near the center of each surface displaying the surface normal vector direction. {Amill, Ffm}

Note: Normals Draw is not a recordable macro command.

NORMDRAW[GI=##]

GI = Group Index. Indicates whether to draw normals only on surface elements in the active group.

Value 0 = Off. Does not use the active group. All visible (show/masked on) surface elements have their normals drawn.

Value 1 = On. Uses the active group. All surface elements in the active group have their normals drawn.

Default 0

**NORMFLIP[ ]**

(Normals Flip), *command*. Reverses the surface normal vector direction on the ACIS face for each surface element in the active group. {Amill, Ffm}

Note: Normals Flip is not a recordable macro command.

NORMFLIP[MB=##]

Reverses the surface normal vector direction on the ACIS face for each surface element in the active group. The normal is at the surface center ( $u=0.5$ ,  $v=0.5$ ).

MB = Manifold Bodies. Indicates whether to exclude faces that are in manifold solid bodies (or any non-single-face body) in the group of faces to have their normals flipped.

Value 0 = Off. Includes manifold solid body faces in those to be reversed to keep the multi-face bodies pointing the same way.

Value 1 = On. Excludes manifold solid body faces from those to be reversed.

Use Surface Edit—Extract and Extract Surfaces From Solids to change individual faces.

**- O -****OFFSET[ ]**

(Offset Mesh), *command*. Creates a mesh offset from a range of mesh profiles selected using the assigned tool's geometry and the mesh normal orientation. {Amill, Ffm}

OFFSET[E1=\$\$, E2=\$\$, OC=##, OF=##,  
 OA=##, KO=##, GC=##, CM=##,  
 VT=##]

E1 = Surface start element (required)

Default: None

E2 = Surface end element (required)

Default: None

OC = Offset calculation

0 = Full

1 = Partial

2 = De-offset

Default: 0

OF = Offset direction

0 = Positive

1 = Negative

Default: 0

OA = Offset amount (required)

Default: None

KO = Keep original

0 = Off

1 = On  
 Default: 0  
 GC = Gouge correction

0 = Off  
 1 = On  
 Default: 0  
 CM = Connect mesh  
 0 = Off  
 1 = On  
 Default: 0  
 VT = Virtual mesh tolerance  
 Default: Global variable  
 Initial default: 0.001

**OFS( )**  
 (Offset), *function*. Returns offset setting of selected element.

OFS (elnum)  
 -1 = Left  
 1 = Right  
 0 = None

### ON\_LAYER[ ]

(On Layer), *command*. Sets the current insert properties for new elements as layer (reference) elements.

ON\_LAYER[LV=##, WP=\$\$, LY=##, PT=##]

LV = Level (modal)  
 WP = Work plane (modal)  
 LY = On layer (modal)  
 PT = Profile top (modal)  
 Note: To set profile top off, set PT=?.

### OPEN[ ]

(Open Item), *script*. Opens a control panel or dialog box for display in the user interface.

Note: Open Item only functions while running in the macro demo mode without using the default UI scripts.

OPEN[\$\$]

\$\$ = Name of control panel or dialog box

### OPN\_PROF[ ]

(Open Profile), *command*. Creates tool path for a pocket that opens to the side of the part. {Pmill, Amill, Ffm, Aturn}

OPN\_PROF[E1=##, E2=##, E3=##, UA=##, CC=##, CO=##, AP=##, WC=##, FA=##, ED=##, XC=##, YC=##, DS=##, DC=##, DE=##, FL=##, AN=##, EP=##,

IN=##, IP=##, AR=##, CI=##, EW=##, OP=##, RM=##, RT=##, AC=##, RD=##, IT=##, LY=##, NN=\$\$, UT=##]

E1 = Part boundary start element (required)  
 E2 = Part boundary end element (required)  
 E3 = Material boundary element (required)  
 UA = Uncut area geometry—use  
 0 = Off  
 1 = On  
 Default: 0  
 CC = Climb cut  
 0 = Conventional  
 1 = Climb  
 Default: 1  
 CO = Connect passes  
 0 = Off  
 1 = On  
 Default: 0  
 AP = Alternate passes  
 0 = Off  
 1 = On  
 Default: 0

WC = Width of cut (required)  
 FA = Finish amount  
 Default: 0.0  
 ED = Extension distance  
 Default: 0.0  
 XC = X cut point (required)  
 YC = Y cut point (required)  
 DS = First pass level (depth; required)  
 DC = Depth of cut (required)  
 DE = Final level (depth; required)  
 FL = Floor allowance  
 Default: 0.0

AN = Pass angle  
 Default: 0.0  
 EP = Equalized passes (modal)  
 0 = Off  
 1 = On

IN = Group island—use  
 0 = Off  
 1 = On  
 Default: 0  
 IP = Final (island) pass (modal)  
 0 = Off  
 1 = On

AR = Ramp angle  
 Default: 90.0 (vertical)  
 CI = Cut inside out  
 0 = Off (cut outside in)  
 1 = On  
 Default: 1  
 EW = Equalize width passes  
 0 = Off  
 1 = On  
 Default: 0

OP = Overlap passes  
 0 = Off  
 1 = On  
 Default: 0  
 RM = Rough tolerance method  
 0 = Off, minimum  
 1 = On, Mid Tol  
 Default: 0  
 RT = Rough tolerance amount (distance)  
 Default: 0.00005  
 AC = Corner roll angle  
 Default: 60.0  
 RD = Rapid to depth  
 0 = Off  
 1 = On  
 Default: 0  
 IT = Island top machining  
 0 = Full pass  
 1 = Clear top  
 Default: 0  
 LY = Layer  
 Default: 1 (not global)  
 NN = AUM named group name  
 Default: AUM  
 UT = Uncut material tolerance  
 Default: 0.01

**OPNLIST( )**

(Step List Index), *function*. Returns values from the job operations setup step list.

OPNLIST(index)  
 index = 0, returns the number of steps in the step list or -1 If no steps exist.  
 index = Valid step index, returns the step number of that step.  
 index = Greater than the total number of steps or less than 0, returns a -1.

**OPTIMIZE[ ]**

(Optimize), *command*. Resequences tool path elements in the active group to reduce machine travel and tool changes. {Pmill, Amill, Ffm, Afab, Awedm}

OPTIMIZE[XS=##, YS=##, OM=##, XY=##,  
 SP=##, SN=##, ST=##, MT=##]

XS = X Start point (required)  
 Default: None  
 YS = Y Start point (required)  
 Default: None  
 OM = Optimization method  
 0 = Closest  
 1 = Zigzag  
 2 = Improve  
 Default: 0

XY = X or Y direction  
 0 = X direction  
 1 = Y direction  
 Default: 0  
 SP = Spacing  
 Default: 0  
 SN = Sensitivity  
 Default: 0  
 ST = Sort by tools  
 0 = Off  
 1 = On  
 Default: 0  
 MT = Maximum time (for OM=2)  
 Default: Runs till optimum found

**OPTYPE( )**

(Operation Type), *function*. Returns the operation SNCS number for a step number.

OPTYPE(stpnum)

**ORDSTP[ ]**

(Order Step), *command*. Sorts or renames the Step list.

Note: Obsolete. Maps to Plan\_Step\_Order when TY=1.

ORDSTP[TY=##, ST=##, IN=##]

TY = Type

0 = By model  
 1 = By step number  
 2 = Renumber required

ST = Start number (required if TY = 2)

IN = Increment (required if TY = 2)

- P -

**PAN[ ]**

(Pan), *command*. Shifts the location of the viewing window along the distance between two points without changing its size.

PAN[X1=##, Y1=##, X2=##, Y2=##]

X1 = From X (required)  
 Screen coordinate value  
 Default: None  
 Y1 = From Y (required)  
 Screen coordinate value  
 Default: None  
 X2 = To X (required)  
 Screen coordinate value  
 Default: None

PART_CURVES[ ]	50	PCHG_JHP[ ]
<p>Y2 = To Y (required) Screen coordinate value Default: None</p> <p><b>PART_CURVES[ ]</b> (Parting Line Curves), <i>command</i>. Generates polyline curves around the silhouette of the surfaces in the active group, as viewed down the active work plane Z axis from +Z to -Z. {Amill, Ffm}</p> <p>Note: Parting Line Curves is not a recordable macro command.</p> <p><b>PART_CURVES[PT=##]</b></p> <p>PT = Approximation tolerance of how far the curve can deviate from the surface. (Optional) Default: 0.001</p> <p><b>PAUSE[ ]</b> (Pause), <i>command</i>. Pauses the macro while a message box is displayed.</p> <p>Note: Pause is not a recordable macro command.</p> <p><b>PAUSE[TX=\$\$, LR=##, LC=##, SR=##, SC=##, PT=##]</b></p> <p>TX = "Body of text" LR = Location row of upper left corner of dialog box LC = Location column of upper left corner of dialog box SR = Size of dialog box in rows SC = Size of dialog box in columns PT = Pause time options 0 = Single OK button 1 = Two buttons 2 or greater = Delay time (in seconds) for display Use the PAUSE macro command to display a timed message.</p> <p><b>PCHG_HP[ ]</b> (Property Change Holes/Points), <i>command</i>. Changes the properties of hole or point elements in the active group.</p> <p><b>PCHG_HP[TY=##, TL=##, LV=##, CL=##, AN=##, CN=##, PK=##, TD=##]</b></p> <p>Note: This replaces PCHG_JHP in applications not using Job Operations Setup.</p>		<p>TY = Type 0 = N/C 1 = Hole 2 = Point Default: 0</p> <p>TL = Tool Default: N/C</p> <p>LV = Level Default: N/C</p> <p>CL = Clear Default: N/C</p> <p>AN = Tool Angle Default: None</p> <p>CN = Clear on 0 = Off 1 = On 2 = N/C Default: 2</p> <p>PK = Peck 0 = Off 1 = On 2 = N/C Default: 2</p> <p>TD = Tip Depth (Tip Depth is computed from the Spot Diameter or Full Depth) Default: N/C</p> <p><b>PCHG_JHP[ ]</b> (Property Change Jos Hole point), <i>command</i>. Changes the properties of hole or point elements in the active group. Note: This replaces PCHG_HP in applications using Job Operations Setup.</p> <p><b>PCHG_JHP[TY=##, ST=##, LV=##, CL=##, CN=##, PK=##, TD=##]</b></p> <p>TY = Type 0 = N/C 1 = Hole 2 = Point Default: 0</p> <p>ST = Step Default: N/C</p> <p>LV = Level Default: N/C</p> <p>CL = Clear Default: N/C</p> <p>CN = Clear on 0 = Off 1 = On 2 = N/C Default: 2</p> <p>PK = Peck 0 = Off 1 = On</p>

2 = N/C Default: 2	PCHG_TP[TL=##, LV=##, PN=##, PT=##, OF=##, CN=##, CL=##]
TD = Tip Depth (Tip Depth is computed from the Spot Diameter or Full Depth) Default: N/C	Note: This replaces PCHG_ST in applications not using Job Operations Setup.
<b>PCHG_LY[ ]</b> (Property Change Layer), <i>command</i> . Changes one or more layer properties for an active group of elements, including layer, level and profile top.	TL = Tool Default: N/C
PCHG_LY[LY=##]	LV = Level Default: N/C
LY = Layer Default: N/C	PN = Profile top on 0 = Off 1 = On 2 = N/C Default: 2
<b>PCHG_SURFACES[ ]</b> (Property Change Surfaces), <i>command</i> . Changes the settings that control the visual display of surfaces in the active group.	PT = Profile top value Default: N/C
PCHG_SURFACES[CG=##, SU=##, SV=##, ST=##, RN=##, MS=##]	OF = Offset 0 = Left 1 = Right 2 = None 3 = N/C Default: 3
CG = Change grid, whether to change the surface grid settings (by using SU, SV, and ST) 0 = No 1 = Yes Default: 1 (This allows compatibility with macros from previous revisions)	CN = Clear on 0 = Off 1 = On 2 = N/C Default: 2
SU = Surface grid lines, count in U direction Integer greater than 0 Default: 3	CL = Clear Default: N/C
SV = Surface grid lines, count in V direction Integer greater than 0 Default: 3	<b>PCHG_ST[ ]</b> (Property Change Step), <i>command</i> . Changes one or more tool path properties for an active group of elements, including step, tool offset, level, clear and profile top.
ST = Surface grid lines, curve tolerance Floating point number greater than 0 Default: 0.01	PCHG_ST[ST=##, LV=##, PN=##, PT=##, OF=##, CN=##, CL=##]
RN = Reverse normals (required) 0 = No 1 = Yes Default = 0	Note: This replaces PCHG_TP in applications using Job Operations Setup.
MS = Exclude multi-surface bodies 0=No 1 = Yes Default: 0	ST = Step Default: N/C
<b>PCHG_TP[ ]</b> (Property Change Tool Path), <i>command</i> . Changes one or more tool path properties for an active group of elements, including step, tool offset, level, clear and profile top.	LV = Level Default: N/C

PN = Profile top on 0 = Off 1 = On 2 = N/C Default: 2	PN = Profile top on 0 = Off 1 = On 2 = N/C Default: 2
PT = Profile top value Default: N/C	PT = Profile top value Default: N/C
OF = Offset 0 = Left 1 = Right 2 = None 3 = N/C Default: 3	OF = Offset 0 = Left 1 = Right 2 = None 3 = N/C Default: 3
CN = Clear on 0 = Off 1 = On 2 = N/C Default: 2	CN = Clear on 0 = Off 1 = On 2 = N/C Default: 2
CL = Clear Default: N/C	CL = Clear Default: N/C
<b>PCHG_ST[ ]</b> (Property Change Step), <i>command</i> . Changes one or more tool path properties for an active group of elements, including step, tool offset, level, clear and profile top.	PCHG_ST[ST=##, LV=##, PN=##, PT=##, OF=##, CN=##, CL=##]
Note: This replaces PCHG_TP in applications using Job Operations Setup.	Note: This replaces PCHG_TP in applications using Job Operations Setup.
ST = Step Default: N/C	ST = Step Default: N/C
LV = Level Default: N/C	LV = Level Default: N/C
PN = Profile top on 0 = Off 1 = On 2 = N/C Default: 2	PN = Profile top on 0 = Off 1 = On 2 = N/C Default: 2
PT = Profile top value Default: N/C	PT = Profile top value Default: N/C
OF = Offset 0 = Left 1 = Right	OF = Offset 0 = Left 1 = Right

2 = None  
 3 = N/C  
 Default: 3

CN = Clear on  
 0 = Off  
 1 = On  
 2 = N/C  
 Default: 2

CL = Clear  
 Default: N/C

**PCHG\_WP[ ]**

(Property Work Plane), *command*. Assigns elements in the active group to a different work plane while maintaining their current world positions.

PCHG\_WP[WP=\$\$]

WP = Work plane (required)  
 Default: None

**PECK( )**

(Peck), *function*. Returns peck switch setting of selected element.

PECK(eIndex) Returns peck switch setting of selected element.  
 0 = Off  
 1 = On

**PLANAR[ ]**

(Planar Cuts), *command*. Creates planar profiles parallel to the active work plane at the Z levels you specify on a selected range of existing mesh profiles.

PLANAR[E1=\$\$, E2=\$\$, ZT=##, SV=##,  
 BR=##, DV=##, OF=##, OA=##, VT=##]

E1 = Surface start element (required)  
 Default: None

E2 = Surface end element (required)  
 Default: None

ZT = Planar Z (required)  
 Default: None

SV = Spacing value (required)  
 Default: None

BR = Background refine  
 0 = Distance  
 1 = Count  
 2 = Out Tol  
 3 = N/C  
 Default: 3

DV = Background value  
 Default: 0.1

OF = Offset  
 0 = Positive  
 1 = Negative  
 2 = 0  
 Default: 2

OA = Finish amount  
 Default: 0.0

VT = Virtual mesh tolerance  
 Default: Global variable  
 Initial default: 0.001

**PLANE\_DATA[ ]**

(Plane Data), *command*. Use Plane Data to provide information about a work plane's orientation and location in space. You can use Plane Data to inquire about work planes in unfamiliar files or to redefine work planes easily.

PLANE\_DATA[WP=\$\$, RO=##]

WP = Work plane (required)

Default: None

RO = Rotation order (required)

0 = ABC

1 = BAC

2 = ACB

3 = BCA

Default: None

**PLAN\_ALL\_REMOVE[ ]**

(Planner Remove All), *command*. Removes all items in the specified list that are unreferenced by the process model or other lists.

PLAN\_ALL\_REMOVE[LIST=##]

LIST = Which list is to be cleaned up.  
 (required)

1 = Step List (remove Steps)

2 = Tool List (remove tool assignments)

Default: None

**PLAN\_ITEM\_MOVE[ ]**

(Planner Move), *command*. Moves an item from one position in the list to another.

PLAN\_ITEM\_MOVE[WHICHLST=##,  
 WHICH=\$\$, WHERE=##, DEST=##]

WHICHLST = Which list the move occurs in  
 (required)

1 = Step List (move a Step)

2 = Tool List (move a tool assignment)

Default: None

WHICH = The username of the item to move. (required)  
 The Step Number for Steps or the Tool Number for Tools  
 Default: None

WHERE = Where to put the item. (required)  
 0 = After the item specified in the DEST variable  
 1 = At the beginning of the list  
 2 = At the end of the list  
 Default: None

DEST = The item after which the selected item will move if WHERE = 0 (Must be specified if WHERE = 0)  
 The Step Number for Steps or the Tool Number for Tools.  
 Default: 0

**PLAN\_ITEM\_REMOVE[ ]**

(Planner Remove Item), *command*.  
 Removes the specified item from the JOS data if it can be.

**PLAN\_ITEM\_REMOVE[LIST=##,  
 USER=\$\$]**

LIST = Which list the item is to be removed from (required)  
 1 = Step List (remove a Step)  
 2 = Tool List (remove a tool assignment)  
 Default: None

USER = Which item is to be removed (required)  
 The Step Number for Steps or the Tool Number for Tools  
 Default: None

**PLAN\_STEP\_ORDER[ ]**

(Planner Sort By), *command*. Sorts or renumbers the Step list.

**PLAN\_STEP\_ORDER[TY=##, ST=##,  
 IN=##]**

TY = The type of action to perform (required)  
 0 = Reorder Steps by their first appearance in the process model  
 1 = Reorder Steps by their step number  
 2 = Renumber the Step List  
 Default: None.

ST = The number for the first step if steps are being renumbered  
 1 to 9999  
 Default: 1

IN = The increment for each successive step  
 1 to 9999  
 Default: 1

**PLAN\_TOOL\_ORDER[ ]**

(Planner Tool Order), *command*. Sorts the Tool list.

**PLAN\_TOOL\_ORDER[TY=##]**

TY = The type of sort to perform (required)  
 0 = Reorder Tools by their first appearance in the step list  
 1 = Reorder Tools by their first appearance in the process model  
 2 = Reorder Tools by their Tool Number  
 Default: None.

**PLN( )**

(Work Plane Name), *function*. Returns work plane index number of selected element.

**PLN(elnum)**

elnum = Element number or name

Results

0 = XY plane  
 1 = YZ plane  
 2 = XZ plane

**PLNIX( )**

(Plane IX Vector), *function*. Returns X components of plane's I orientation vectors.

**PLNIX(index)**

index = Plane index number

**PLNIY( )**

(Plane IY Vector), *function*. Returns Y components of plane's I orientation vectors.

**PLNIY(index)**

index = Plane index number

**PLNIZ( )**

(Plane IZ Vector), *function*. Returns Z components of plane's I orientation vectors.

**PLNIZ(index)**

index = Plane index number

**PLNJX( )**

(Plane JX Vector), *function*. Returns X components of plane's J orientation vectors.

**PLNJX(index)**

index = Plane index number

**PLNJY()**

(Plane JY Vector), *function*. Returns Y components of plane's J orientation vectors.

## PLNJY(index)

index = Plane index number

**PLNJZ()**

(Plane JZ Vector), *function*. Returns Z components of plane's J orientation vectors.

## PLNJZ(index)

index = Plane index number

**PLNKX()**

(Plane KX Vector), *function*. Returns X components of plane's K orientation vectors.

## PLNKX(index)

index = Plane index number

**PLNKY()**

(Plane KY Vector), *function*. Returns Y components of plane's K orientation vectors.

## PLNKY(index)

index = Plane index number

**PLNKZ()**

(Plane KZ Vector), *function*. Returns Z components of plane's K orientation vectors.

## PLNKZ(index)

index = Plane index number

**PLNTX()**

(Plane TX Vector), *function*. Returns X components of plane's T orientation vectors.

## PLNTX(index)

index = Plane index number

**PLNTY()**

(Plane TY Vector), *function*. Returns Y components of plane's T orientation vectors.

## PLNTY(index)

index = Plane index number

**PLNTZ()**

(Plane TZ Vector), *function*. Returns Z components of plane's T orientation vectors.

## PLNTZ(index)

index = Plane index number

**PLNNUM()**

(Plane Index Number), *function*. Returns the plane index number from the named plane.

PLNNUM(plnname) Returns the plane index number from the named plane.

**POCKET[ ]**

(Pocket), *command*. Creates tool path for removing material from inside a closed profile. {Pmill, Amill, Ffm, Aturn}

**POCKET[**TY=##, EL=##, FA=##, WC=##,  
AN=##, XS=##, YS=##, DS=##, DC=##,  
DE=##, EP=##, IN=##, IP=##, AR=##,  
UA=##, CC=##, RS=##, FL=##, CI=##,  
EW=##, OP=##, RM=##, RT=##,  
AC=##, RD=##, IT=##, LY=##, NN=\$\$,  
UT=##]  
  
TY = Pocketing method  
0 = Spiral  
1 = Zigzag  
2 = Linear  
Default: 0

EL = Outside boundary element (required)

FA = Finish amount

Default: 0.0

WC = Width of cut (required)

AN = Pass angle

Default: 0.0

XS = Start X (no default, not required)

YS = Start Y (no default, not required)

DS = First pass level (depth; required)

DC = Depth of cut (required)

DE = Final level (depth; required)

EP = Equalized passes (modal)

0 = Off

1 = On

IN = Group island—use

0 = Off

1 = On

Default: 0

IP = Final (island) pass (modal)

0 = Off

1 = On

AR = Ramp angle

Default: 90.0 (vertical)

UA = Uncut area geometry—use

0 = Off

1 = On

Default: 0

CC = Climb cut

0 = Conventional

1 = Climb

Default: 1

RS = Ramp from start  
 0 = Off, use ramp angle  
 1 = On, ramp from start point  
 FL = Floor allowance  
 Default: 0.0  
 CI = Cut inside out  
 0 = Off (cut outside in)  
 1 = On  
 Default: 1  
 EW = Equalize width passes  
 0 = Off  
 1 = On  
 Default: 0  
 OP = Overlap passes  
 0 = Off  
 1 = On  
 Default: 0  
 RM = Rough tolerance method  
 0 = Off, minimum  
 1 = On, Mid Tol  
 Default: 0  
 RT = Rough tolerance amount (distance)  
 Default: 0.00005  
 AC = Corner roll angle  
 Default: 60.0  
 RD = Rapid to depth  
 0 = Off  
 1 = On  
 Default: 0  
 IT = Island top machining  
 0 = Full pass  
 1 = Clear top  
 Default: 0  
 LY = Layer  
 Default: 1  
 NN = AUM named group name  
 Default: AUM  
 UT = Uncut material tolerance  
 Default: 0.01

**POINT[ ]**

(Point or Point/Rapid), *command*. Creates a point element.

POINT[XE=##, YE=##, XS=##, YS=##,  
 AN=##, DS=##, LV=##, CO=##, SE=##]  
 XE = X end  
 Default: Null  
 YE = Y end  
 Default: Null  
 XS = X anchor  
 Default: Null  
 YS = Y anchor  
 Default: Null  
 AN = Angle  
 Default: Null

DS = Distance  
 Default: Null  
 LV = Level (modal)  
 CO = Clear Only  
 0 = Off  
 1 = On  
 Default: 0  
 SE = End solution designator  
 0 = +  
 1 = -  
 2 = N/A  
 Default: 0

**POINTPOLY[ ]**

(Polyline From Points), *command*. Creates a polyline element from a sequence of points in the active group with vertices corresponding to each point in the current group in database order.

Note: Polyline From Points is not a recordable macro command.

**POINTPOLY[]****POLY5X[ ]**

(5 Axis Polyline), *command*. Creates a 5-axis polyline tool path necessary for a 4-axis machining operation. {Awedm}

POLY5X[CE=##, CL={x, y, z, u, v, w, ... x, y,  
 z, u, v, w} or #CLVAR]

#clvar can be used instead of CL{}. The default on macro record is DM = 4

CE = Close ends

0 = No  
 1 = Yes  
 Default: 0

CL = Coordinate list (required)

A coordinated list or variable declared as coordinate list.

**POLYLINE[ ]**

(Polyline), *command*. Creates a single element made up of a sequence of line segments.

POLYLINE[CE=##, CL={} or #CLVAR]  
 #clvar can be used instead of CL{}.

CE = Close ends

0 = No  
 1 = Yes  
 Default: 0

CL = Coordinate list (required)

A coordinate list or a variable declared

as a coordinate list  
 Default: None  
 Note: See COORDINATE LIST.

**POLYPOINT[ ]**

(Polyline To Points), *command*. Creates point elements at all the vertices of each polyline in the active group.

Note: Polyline To Points is not a recordable macro command.

**POLYPOINT[]****POLYTHIN[ ]**

(Polyline Thinning), *command*. Refines the polylines in the active group using the current Virtual Mesh Tolerance setting.

Note: Polyline Thinning is not a recordable macro command.

**POLYTHIN[]****PROF\_GRP[ ]**

(Profile Group), *command*. Adds or removes all elements of a selected profile to the active group.

**PROF\_GRP[EL=##, AR=##]**

EL = Element in profile (required)  
 A valid element number  
 Default: None

AR = Add/remove (modal)  
 0 = Add  
 1 = Remove

**PROF\_SEQ[ ]**

(Profile Sequence), *command*. Sets the insert properties to insert new elements before the first element, or after the last element, of an existing profile in the model.

**PROF\_SEQ[BA=##, EL=##, ME=##]**

BA = Before/after

0 = Before  
 1 = After  
 Default: 1

EL = Element (required)

Element number or element name  
 Default: None

ME = Match element (modal)

0 = Off  
 1 = On  
 Default: 0

**PROF\_SLICE[ ]**

(Profile Splice), *command*. Creates a profile on the intersection of a plane with an ACIS solid body. {Amill, Ffm}

**PROF\_SLICE[SE=##, ZL=##, TO=##]**

SE = Element index of surface

Default: None

ZL = Elevation of slice plane

Default: 0.0

TO = Tolerance

Default: 0.001

**PROF\_START[ ]**

(Profile Start), *command*. Re-sequences a single valid profile so that the element you select is the first element.

**PROF\_START[EL=\$\$]**

EL = Element in profile (required)

Default: None

**PROF\_TRIM[ ]**

(Profile Trim), *command*. Trim to intersect, trim or extend, and sequentially order groups of planar elements that are on the same level and work plane.

**PROF\_TRIM[XS=##, YS=##, TO=##]**

XS = X start, for indication point (required)

Default: None

YS = Y start, for indication point (required)

Default: None

TO = Tolerance

Default: 0.1

**PROJECT[ ]**

(Project, Milling), *command*. Projects a polyline copy of the active group of elements onto a plane, cone, cylinder, or sphere. {Amill, Ffm}

**PROJECT[TY=\$\$, E1=\$\$, E2=\$\$, OF=##, OA=##, DE=##, VT=##]**

TY = Type

0 = Plane  
 1 = Cone  
 2 = Sphere  
 3 = Mesh  
 Default: 0

E1 = Start element (required)

Default: None

E2 = End element (required)  
Default: None  
OF = Offset side  
0 = Positive  
1 = Negative  
2 = 0  
Default: 2  
OA = Offset amount  
Default: 0  
DE = Explode distance  
Default: 0.01  
VT = Virtual mesh tolerance  
Default: Global variable  
Initial default: 0.001

**PROJECT[ ]**

(Project, Wire Edm), *command*. Projects an image of the active group of planar elements onto a plane. {Awedm}

**PROJECT[PT=\$\$, E1=\$\$, E2=\$\$, ED=##,  
OS=##, OA=##]**

PT = Project to  
Options: 0 = Plane (No other option)  
Default: 0  
E1 = First element (required)  
Default: None  
E2 = Second element (required)  
Default: None  
ED = Explode distance  
Default: 0.01  
OS = Offset side  
Options: 0 = Pos  
1 = Neg  
2 = Zero  
Default: 2  
OA = Offset amount  
Default: 0

**PROJECTED[ ]**

(Projected), *command*. Creates tool path that follows any line or polyline path you create in SmartCAM across multiple surfaces. {Ffm}

**PROJECTED[OA=##, TI=##, TO=##,  
CF=##, BG=##, LU=##, LN=\$\$, FU=##,  
FN=\$\$, FTS=\$\$]**

OA = Offset (finish) amount (required)  
Default: 0.0  
TI = In tolerance (required)  
Default: 0.01  
TO = Out tolerance (required)  
Default: 0.01

CF = Clear/feed  
0 = Absolute  
1 = Incremental  
2 = Straight  
Default: 0  
BG = Bridge gaps  
0 = Straight  
1 = Clear/feed  
Default: 0  
LU = Log file—use  
0 = Off  
1 = On  
Default: 0  
LN = Log file name  
Default: surfmach.log  
FU = External file—use  
0 = Off  
1 = On  
Default: 0  
FN = External file name  
Default: pmfile. Ext where .ext is  
.sat, .sab, or .igs, depending on the  
file type  
FTS= External file import type  
SAT  
SAB  
IGES

**PROMPT[ ]**

(Prompt), *command*. Pauses the macro displaying A message box that requests input for a user variable.

Note: Prompt is not a recordable macro command.

**PROMPT[TX=\$\$, VN=\$\$, LR=##, LC=##,  
SR=##, SC=##, DV=##]**

TX = “Body of text”  
VN = “Variable name”  
LR = Location row of upper left corner of dialog box  
LC = Location column of upper left corner of dialog box  
SR = Size of dialog box in rows  
SC = Size of dialog box in columns  
DV = Display variable options  
0 = Off  
1 = On (variable name displayed in text)

**PROPERTY[ ]**

(Property), *command*. Sets insert properties for the current layer or step and the tip depth of holes.

**PROPERTY[LV=##, WP=\$\$, PT=##,  
CL=##, OF=##, TD=##]**

LV = Level (modal)  
 WP = Work plane (modal)  
 PT = Pro Top (modal)  
     To set Prof Top off, set PT=?  
 CL = Clear (modal)  
     To set Clear off, set CL=?  
 OF = Offset (modal)  
     0 = Left  
     1 = Right  
     2 = None  
 TD = Tip depth  
     Default: Null

### PROFDIVIDE[ ]

(Profile Divide), *command*. Converts a profile into a polyline that has a specified number of control points.

Note: Profile Divide is not a recordable macro command.

**PROFDIVIDE[E1=#, E2=#, CN=#]**

E1 = Element number for start of profile  
 E2 = Element number for end of profile  
 CN = Count number of points in resultant polyline  
     Default: 2

### PTCNT()

(Point Count), *function*. Returns the number of control points of selected spline or polyline element.

**PTCNT(elnum)**  
 elnum = Element number

### PTOP()

(Profile Top), *function*. Returns the profile top value of selected element.

**PTOP(elnum)**  
 elnum = Element number

**- Q -**

**- R -**

### RAD( )

(Radius), *function*. Returns the radius value of selected arc element.

**RAD(elnum)**

### RANGE\_GRP[ ]

(Range Group), *command*. Adds or removes a selected range of sequential elements from the database to or from the active group.

**RANGE\_GRP[E1=##, E2=##, AR=##]**

E1 = Element start (required)  
     Default: None  
 E2 = Element end (required)  
     Default: None  
 AR = Add/remove (modal)  
     0 = Add  
     1 = Remove

### READ[ ]

(Open), *command*. Opens an existing process model file.

**READ[FN=\$\$, FT=##]**

FN = Filename (required)  
     Default: None  
 FT = File type  
     0 = 2-D (.sh2)  
     1 = 3-D (.sh3)  
     2 = .pm4  
     Default: 1

### READOUT[ ]

(Readout), *command*. Pauses the macro execution, displays a message in the read-out line and waits for a key to be pressed. Used primarily for demos.

Note: Readout is not a recordable macro command.

**READOUT[TX=\$\$]**

TX=pause message (optional)  
 Note: If no text is specified, the phrase "Macro paused. Press a key to continue..." is displayed on the read-out line.

### REDRAW[ ]

(Redraw), *command*. Refreshes the graphic view and redisplays all the visible elements in the active viewing window.

**REDRAW[]**

**REFINE[ ]**

(Refine Mesh), *command*. Changes the controlling point count, spacing, divisions, and cut direction on a range of mesh profiles with the option to keep the original range of profiles. {Amill, Ffm}

**REFINE[E1=\$\$, E2=\$\$, SP=##, DI=##,  
SV=##, DV=##, KO=##, CD=##,  
CM=##]**

E1 = Mesh start element (required)  
Default: None

E2 = Mesh end element (required)  
Default: None

SP = Spacing  
0 = Distance  
1 = Count  
2 = Cusp Hgt  
3 = N/C  
Default: 3

DI = Division  
0 = Distance  
1 = Count  
2 = Mid Tol  
3 = N/C  
Default: 3

SV = Spacing value (required)  
Default: None

DV = Division value (required)  
Default: None

KO = Keep original  
0 = Off  
1 = On  
Default: 0

CD = Change cut direction  
0 = Off  
1 = On  
Default: 0

CM = Connection mesh  
0 = Off  
1 = On  
Default: 0

**REM\_LINK[ ]**

(Remove Link), *command*. Deletes an individual link or a range of links from between two profiles. {Awedm}

**REM\_LINK[P1=##, P2=##, S1=##, S2=##,  
EL=##]**

P1 = Primary range start  
Default: None

P2 = Primary range end  
Default: None

S1 = Secondary range start

Default: None

S2 = Secondary range end

Default: None

EL = Element number or name  
Default: None

**REMOVE\_SYNCH[ ]**

(Delete Synch), *command*. Deletes a pair of matching Wait commands, or all Start, End, and Wait synch commands associated with the active group. {Aturn}

**REMOVE\_SYNCH[EL=##]**

EL = Wait command element (deletes pair)

**RENDER[ ]**

(Render), *command*. Opens the Render Image window and creates a single shaded image of a group of surface elements. The current view angle is used to display the image. {Amill, Ffm}

**RENDER[RT=##, RF=##, GN=\$\$, ST=##,  
NT=##, GL=##, LS=##, L1=##, X1=##,  
Y1=##, Z1=##, I1=##, L2=##, X2=##,  
Y2=##, Z2=##, I2=##, AM=##, MP=##,  
WLX=##, WLY=##, WSX=##, WSY=##]**

RT = Rendering type

0 = Flat

1 = Smooth

RF = Rendering facetting

0 = Coarse

1 = Medium

2 = Fine

3 = Very Fine

GN = Group name for the surface elements to be rendered.

ST = Surface deviation tolerance (required)

Defaults in Inches:

Coarse = 0.1

Medium = 0.01

Fine = 0.005

Very Fine = 0.0005

Note: Defaults are converted to millimeters for metric job file.

NT = Normal tolerance (required)

Between 0 and 180 degrees

Defaults: Coarse = 30

Medium = 10

Fine = 5

Very Fine = 2

GL = Number of Grid Lines (required)

Defaults in Inches:

Coarse = 8

Medium = 8  
 Fine = 16  
 Very Fine = 32  
**LS** = Light Sources  
 0 = Vector light  
 1 = Point light  
 2 = Both vector and point light  
 Default: 0  
**L1** = Light 1 on/off  
 0 = off  
 1 = on  
 Default: 1  
**X1** = View space location of tail of vector, X coordinate (required if Vector light is on)  
 Default: None  
**Y1** = View space location of tail of vector, Y coordinate (required if Vector light is on)  
 Default: None  
**Z1** = View space location of tail of vector, Z coordinate (required if Vector light is on)  
 Default: None  
**I1** = Intensity of light 1 vector light  
 Between 0.0 and 1.0  
 Default: 1.0  
**L2** = Light 2 on/off  
 0 = off  
 1 = on  
 Default: 0  
**X2** = Model space location of point light, X coordinate (required if Point light is on)  
 Default: None  
**Y2** = Model space location of point light, Y coordinate (required if Point light is on)  
 Default: None  
**Z2** = Model space location of point light, Z coordinate (required if Point light is on)  
 Default: None  
**I2** = Intensity of light 2 point light  
 Between 0.0 and 1.0  
 Default: 1.0  
**AM** = Ambient light level  
 Between 0.0 and 1.0  
 Default: 0.0  
**MP** = Mark point light location  
 0 = off  
 1 = on  
 Default: 0  
**WLX** = Window location, X coordinate, upper left corner of the Render Image window  
 units = screen pixels from the upper left corner of the screen with +x to the right and +y down.  
**WLY** = Window location, Y coordinate, upper left corner of the Render Image window  
 units = screen pixels from the upper left

corner of the screen with +x to the right and +y down.  
**WSX** = Window size, width of the Render Image window  
 units = screen pixels. The number of units depends on the size of your screen.  
**WSY** = Window size, height of the Render Image window.  
 units = screen pixels. The number of units depends on the size of your screen.  
 For WLX, WLY, WSX, and WSY, the value's number of units depends on the size of your screen. For example, if your screen resolution is 1024 by 768, a value of 512 would equal half the width and a value of 375 would equal about half the height. A sample setting might be 50, 600, 350, 250.

**RENDER\_LOAD[ ]**

(Render Load), *command*. Reloads an image stored using the RENDER\_SAVE command. {Amill, Ffm}

Note: Render Load is not a recordable macro command.

**RENDER\_LOAD[FN=\$\$]**

**FN** = Image filename (optional)

Note: If a file name is not given, the file name defaults to the same name as the active process model file with an .rnd extension, and retrieves the file from the current model directory.

**RENDER\_SAVE[ ]**

(Render Save), *command*. Stores the render image in a file. The image is stored in a native SmartCAM image file format. The default file name extension is .rnd. The image can be loaded at a later time using the RENDER\_LOAD macro. {Amill, Ffm}

Note: Render Save is not a recordable macro command.

**RENDER\_SAVE[FN=\$\$]**

**FN** = Image filename (optional)

Note: If a file name is not given, the file name defaults to the same name as the active process model file with an .rnd

extension, and stores the file in the current model directory.

**RENDER\_CLOSE[ ]**

(Render Close), *command*. Closes the Render Image window. {Amill, Ffm}

RENDER\_CLOSE[]

**REPORT\_JOB[ ]**

(Report Job), *command*. Prints job information or create a report file that contains job information for the open process model.

REPORT\_JOB[FF=\$\$, OF=\$\$, OD=#]

FF = Report Format File (required)  
     The full path to the report formatter directives file to use to generate the report  
     Default: None  
 OF = Output File (required)  
     The full path of the output file  
     Default: None  
 OD = Output Device (required)  
     0 = Printer  
     1 = File  
     Default: None

**REPORT\_STEP[ ]**

(Report Step), *command*. Prints information about the steps used in the active job operations setup or to create a report file that contains step information.

REPORT\_STEP[SS=##, SB=##, IJ=##,  
           FF=\$\$, OF=\$\$, OD=#]

SS = Selection Set, the Steps that will be reported (required)  
     0 = All Steps  
     1 = Used in process model (The Steps that are used in the Process Model)  
     Default: None  
 SB = Sort By, how to sort the selected steps (required)  
     0 = By current order (show steps as they are in the current process plan)  
     1 = By step number (show steps sorted by Step Number)  
     2 = By process model order (show Steps in the order that they are first referenced in the current process model)  
     Default: None

IJ = Include Job, whether to include the job information (required)  
     0 = Do not include job information  
     1 = Include job information in the report  
     Default: None  
 FF = Report Format File (required)  
     The full path to the report formatter directives file to use to generate the report  
     Default: None  
 OF = Output File (required)  
     The full path of the output file  
     Default: None  
 OD = Output Device (required)  
     0 = Printer  
     1 = File  
     Default: None

**REPORT\_TOOL[ ]**

(Report Tool), *command*. Prints information about the tools in the active job operations setup or to create a report file that contains tooling information.

REPORT\_TOOL[SS=##, SB=##, IJ=##,  
           FF=\$\$, OF=\$\$, OD=#]

SS = Selection Set, the Tools that will be reported (required)  
     0 = All Tools  
     1 = Used by Steps (The tools that are referenced by any Step in the process plan)  
     2 = Used in Process Model (The Tools that are referenced by Steps used in the Process Model)  
     Default: None  
 SB = Sort By, how to sort the selected tools (required)  
     0 = By current order (show tools as they are in the current process plan)  
     1 = By tool number (show tools sorted by Tool Number or Turret/Tool combination for Turning)  
     2 = By step list order (show tools in the order as they first are referenced by Steps in the current Step List)  
     3 = By process model order (show tools in the order that they are first referenced in the current process model)  
     Default: None  
 IJ = Include Job, whether to include the job information (required)  
     0 = Do not include job information  
     1 = Include job information in the report  
     Default: None

FF = Report Format File (required)  
 The full path to the report formatter directives file to use to generate the report  
 Default: None

OF = Output File (required)  
 The full path of the output file  
 Default: None

OD = Output Device (required)  
 0 = Printer  
 1 = File  
 Default: None

**RES\_PLANE[ ]**

(Reserve Plane), *command*. Prevents a work plane from being modified when you use Transform modeling tools or functions such as Kill Plane, Merge Plane, or Name Plane or when you merge a file.

RES\_PLANE[WP=\$\$]

WP = Work plane (required)  
 Default: None

**REV\_ORDER[ ]**

(Reverse Order), *command*. Reverses the direction or database order of a selected profile.

REV\_ORDER[EL=\$\$, RP=##]

EL = Element in profile (required)  
 Default: None

RP = Reverse profile  
 0 = Order and direction  
 1 = Direction only  
 2 = Order only  
 Default: 0

**ROTATE[ ]**

(Rotate), *command*. Rotates or copies an active group of elements about a pivot axis.

ROTATE[XS=##, YS=##, ZS=##, XE=##,  
 YE=##, ZE=##, AN=##, CP=##, NC=##,  
 TS=##]

XS = Pivot Axis Point X coordinate (required)  
 Default: None

YS = Pivot Axis Point Y coordinate (required)  
 Default: None

ZS = Pivot Axis Point Z coordinate (required for 3D)  
 Default: None

XE = Axis End Point X coordinate (required for 3D)  
 Default: None

YE = Axis End Point Y coordinate (required for 3D)  
 Default: None

ZE = Axis End Point Z coordinate (required for 3D)  
 Default: None

AN = Angle (required)  
 Default: None

CP = Copy  
 0 = No  
 1 = Yes  
 Default: 0

NC = Number of copies  
 Default: 1

TS = Tool sort  
 0 = Off  
 1 = On  
 Default: 1

TY = Type  
 0 = 2D  
 1 = 3D

SP = Suppress Planes  
 0 = No  
 1 = Yes

**ROUGH\_SURFACES[ ]**

(Roughing, Surfaces), *command*. Creates a series of roughing cuts limited in Z depth using selected surface elements as the input for the roughing process. {Ffm}

ROUGH\_SURFACES[AN=##, SS=##,  
 SO=##, OA=##, TI=##, TO=##, PT=##,  
 CF=##, BG=##, ZS=##, ZD=##, UE=##,  
 RU=##, RD=##, EU=##, ED=##,  
 PH=##, SU=##, SD=##, UU=##, LU=##,  
 LN=\$\$, CU=##, CE=\$\$, CX=##, CY=##,  
 FU=##, FN=\$\$, FTS=\$\$]

AN = Cut angle (required)

Default: 0.0

SS = Start side

0 = Left

1 = Right

Default: 0

SO = Stepover distance (required)

Default: 0.1

OA = Offset (finish) amount (required)

Default: 0.0

TI = In tolerance (required)

Default: 0.01

TO = Out tolerance (required)

Default: 0.01

PT = Path type 0 = Zigzag 1 = One way no plunge 2 = One way plunge Default: 0	CU = Containment—use 0 = Off 1 = On: Default: 0
CF = Clear/feed 0 = Absolute 1 = Incremental 2 = Straight Default: 0	CE = Containment boundary profile element number Default: None
BG = Bridge Gaps 0 = Straight 1 = Clear/feed Default: 0	CX = Containment cut area and start indication, X
ZS = Start Z level (required) Default: 0.0	CY = Containment cut area and start indication, Y
ZD = Decrement by Z (required) Default: 0.5	FU = External file—use 0 = Off 1 = On: Default: 0
UE = Extras—use 0 = Off 1 = On Default: 0	FN = External file name Default: Taken from <code>ffm.ini</code> file
RU = Roll edge—use 0 = Off 1 = On Default: 0	FTS= External file import type SAT SAB IGSS
RD = Roll edge distance Default: 0.125	<b>ROUGH_TOOLPATH[ ]</b> (Roughing, Toolpath), <i>command</i> . Creates a series of roughing cuts limited in Z depth using selected tool path elements as the input for the roughing process. {Ffm}
EU = Extend—use 0 = None 1 = Start 2 = End 3 = Both Default: 0	<b>ROUGH_TOOLPATH[ZS=##, ZD=##]</b>
ED = Extend distance Default: 0.25	ZS= Start Z level (required) Default: 0.0
PH = Cut phase 0 = As calculated 1 = Odd 2 = Even Default: 0	ZD = Decrement by Z (required) Default: 0.5
SU = Super sample—use 0 = Off 1 = On: Default: 0	<b>RULED[ ]</b> (Ruled Mesh), <i>command</i> , Creates mesh profiles between two defining profiles. {Amill, Ffm}
SD = Super sample distance Default: 0.1	<b>RULED[E1=\$\$, E2=\$\$, E3=\$\$, E4=\$\$, PD=##, SP=##, SV=##, ZT=##, DI=##, DV=##, CM=##, GC=##, OF=##, OA=##]</b>
UU = Uphill motion only 0 = Off 1 = On: Default: 0	E1 = First profile start (required) Default: None
LU = Log file—use 0 = Off 1 = On: Default: 0	E2 = First profile end (required) Default: None
LN = Log file name Default: <code>surfmach.log</code>	E3 = Second profile start (required) Default: None
	E4 = Second profile end (required) Default: None
	PD = Path direction 0 = Cross 1 = Along

2 = Planar  
Default: 0  
SP = Spacing  
0 = Distance  
1 = Count  
2 = Cusp Hgt  
Default: 0  
SV = Spacing value (required)  
Default: None  
ZT = Planar Z  
Default: 0.0  
DI = Division  
0 = Distance  
1 = Count  
2 = Mid Tol  
3 = In Tol  
4 = Out Tol  
Default: 0  
DV = Division value (required)  
Default: None  
CM = Connection mesh  
0 = Off  
1 = On:  
Default: 0  
GC = Gouge correction  
0 = Off  
1 = On:  
Default: 0  
OF = Offset  
0 = Positive  
1 = Negative  
2 = 0  
Default: 2  
OA = Finish amount  
Default: 0.0

## - S -

### **SAVE[ ]**

(Save As), *command*. Saves the current process model and job operations setup file to disk with the existing file names. If the files already exist on disk, a message box is displayed prompting to whether to overwrite existing files.

**SAVE[WF=##, FN=\$\$, JF=\$\$, FT=##,  
GS=##, WP=\$\$]**

WF = Which file  
0 = Process model file only  
1 = Job file only  
2 = Both  
Default: 0

FN = Filename (required for WF = 0 or 2)  
Default: None

JF = Job file name (required for WF = 1 or 2;  
ignored when running in .jsf mode.  
Default: Active job file name when WF = 0  
FT = File type  
Non-ACIS SmartCAM products  
0 = 2-D (.sh2)  
1 = 3-D (.sh3)  
2 = V6.x CAM Connect (.sh3)  
3 = Process Model (.pm4)  
Default: 3  
FreeForm Machining and Advanced Milling only  
0 = 2-D (.sh2)  
1 = 3-D (.sh3)  
2 = V6.x CAM Connect (.sh3)  
3 = Process Model SAB (.pm4)  
4 = No Surfaces (.pm4)  
5 = FreeForm V4.6 (.pm4)  
6 = Process Model SAT (.pm4)  
Default: 4  
GS = Group save  
0 = Entire file  
1 = Active group  
Default: 0  
WP = Work plane (modal; for FT = 0 only)

### **SCALE[ ]**

(Scale), *command*. Increases or reduces the physical size of each element within a selected group of elements proportionally or distorted along the X, Y, or Z axes.

**SCALE[XF=##, YF=##, ZF=##, XS=##,  
YS=##, ZS=##]**

XF = X factor  
Default: 1.0

YF = Y factor  
Default: 1.0

ZF = Z factor  
Default: 1.0

XS = X start (required)  
Default: None

YS = Y start (required)  
Default: None

ZS = Z start (required)  
Default: None

### **SELECT[ ]**

(Select Item), *script*. Selects an item in the user interface.

Note: Select Item only functions while running in the macro demo mode without using the default UI scripts.

**SELECT[\$\$]**

\$\$ = Name of main menu, pull down or workbench item

**SELECT\_ALL[ ]**

(Select All), *command*. Add all non-masked elements into the active group.

**SELECT\_ALL[]**

**SEQ\_MOVE[ ]**

(Sequence Move), *command*. Changes the position of the active group into a different sequence location within the database.

**SEQ\_MOVE[SC=##]**

SC = Sort criteria

0 = Use existing order in group  
1 = Sort by group selection order  
Default: 0

**SEQBA( )**

(Sequence Before Or After), *function*, Returns the insert mode.

SEQBA() Returns the insert mode.

0 = Before  
1 = After

**SEQEL( )**

(Sequence Element), *function*. Returns the current selected insert element number.

**SEQEL()**

**SGN( )**

(Sign), *function*. Returns the sign (+/-) of a numeric expression.

**SGN(numexp)**

numexp = angle in degrees

**SHELL[ ]**

(Shell), *command*. Executes an external script, DOS or UNIX command or executable program to augment the SmartCAM macro system software.

Note: Shell is not a recordable macro command.

**SHELL[CMD\_LN=\$\$, WA=##,DP=##]**

CMD\_LN=DOS or UNIX Command

WA = Wait (required)

0 = Continues operation

1 = Waits for completion of operation

DP = Display option (required)

0 = Runs in window

1 = Runs in background

Note: The DP variable does not work on Sun Sparc workstations.

**SHOW\_PATH[ ]**

(Show Path), *command*. Graphically simulates the sequence and tool path of the model.

**SHOW\_PATH[E1=\$\$, E2=\$\$, ST=##, DT=##, SP=##]**

E1 = Range start, first element

Element number

Default: 1

E2 = Range end, second element

Element number

Default: Last element in database list

ST = Show tool

0 = Animate

1 = Nibble

2 = Draw end

3 = Filled

Default: 0

DT = Draw tool

0 = 3-D (.sh3)

1 = Flat

Default: 0

SP = Speed

0–9

Default: 8

**SHPFILE( )**

(Shape File), *function*. Returns the process model file path plus process model file name.

Note: Shape File is not a recordable macro function.

**SHPFILE()**

**SIN( )**

(Sine), *function*. Returns the sine of an angle.

**SIN(numexp)**

numexp = angle in degrees

**SMFFILE( )**

(Smf File), *function*. Returns the machine file path plus .smf file name.

Note: Smf File is not a recordable macro function.

**SMFFILE()**

**SNUM()**

(Step Number), *function*. Returns the step number of the active step or -1 if layer.

**SNUM()**

**SPLINE[ ]**

(Spline), *command*. Creates a tangent curve through control points and starting and ending tangent vectors.

**SPLINE[IS=##, JS=##, KS=##, IE=##, JE=##, KE=##, DS=##, DE=##, CE=##, CL={} or #CLVAR]**

IS = Start vector I

Default: Null

JS = Start vector J

Default: Null

KS = Start vector K

Default: Null

IE = End vector I

Default: Null

JE = End vector J

Default: Null

KE = End vector K

Default: Null

DS = Start vector distance (length)

Default: 0.0

DE = End vector distance (length)

Default: 0.0

CE = Close end

0 = No

1 = Yes

Default: 0

CL = Coordinate list (required)

A coordinate list or a variable declared as a coordinate list  
Default: None

**SPLIT[ ]**

(Split), *command*. Divides an arc, line, ellipse, or polyline at any point along its length. You can extend or trim the elements at the split point to create a break or an overlap.

**SPLIT[EL=\$\$, XS=##, YS=##, LC=##, DS=##, GW=##, FR=##, OL=##]**

EL = Element to split (required)

Default: None

XS = X start for near point

Default: Null

YS = Y start for near point

Default: Null

LC = Split location

0 = Nearest

1 = Division

2 = Distance

Default: 1

DS = Distance

Default: Null

GW = Gap width

Default: 0.0

FR = From

0 = Start

1 = End

Default: 0

LN = Length

Default: 0.5

**SPUN[ ]**

(Spun Mesh), *command*. Creates mesh profiles by sweeping a profile about an axis.  
{Amill, Ffm}

**SPUN[E1=\$\$, E2=\$\$, E3=\$\$, PD=##, OF=##, SP=##, AN=##, OA=##, SV=##, KO=##, CM=##, ZT=##, GC=##, VT=##]**

E1 = Generator profile start (required)

Default: None

E2 = Generator profile end (required)

Default: None

E3 = Axis element number (required)

Default: None

PD = Path direction

0 = Generator

1 = Radial

2 = Planar

3 = Both

Default: 0

OF = Offset

0 = Positive

1 = Negative

2 = 0

Default: 2

SP = Spacing

0 = Distance

1 = Count

2 = Cusp Hgt

3 = Junction

Default: 0

AN = Revolve angle (required)

Default: None

OA = Finish amount  
 Default: 0.0  
 SV = Spacing value (required)  
 Default: None  
 KO = Keep original entity type  
 0 = Off  
 1 = On:  
 Default: 0  
 CM = Connection mesh  
 0 = Off  
 1 = On:  
 Default: 0  
 ZT = Planar Z  
 Default: 0.0  
 GC = Gouge correction  
 0 = Off  
 1 = On:  
 Default: 0  
 VT = Virtual mesh tolerance  
 Default: Global variable  
 Initial default: 0.001

**SQR( )**

(Square Root), *function*. Returns the square root of a numeric expression.

SQR(numexp)

**SRF\_COONS[ ]**

(Coons Surface), *command*. Creates a sculpted surface by using four connected boundary profiles that define the surface and cross-section profiles that define interior contour. {Ffm}

SRF\_COONS[E1=\$\$, E2=\$\$, E3=\$\$,  
 E4=\$\$, BP=##]

E1 = First profile start (required)  
 Default: None  
 E2 = First profile end (required)  
 Default: None  
 E3 = Second profile start (required)  
 Default: None  
 E4 = Second profile end (required)  
 Default: None  
 BP = By patch-tangents  
 0 = Off  
 1 = On:  
 Default: 0

**SRF\_DRAFT[ ]**

(Draft Surface), *command*. Creates a surface by sweeping a 2-D generator profile along a 2-D or 3-D director curve. The generator rotates as it sweeps so that its projection remains perpendicular to the 2-D

projection of the director curve into the active work plane. {Ffm}

SRF\_DRAFT[E1=\$\$, E2=\$\$, E3=\$\$, E4=\$\$]

E1 = Generator profile start (required)  
 Default: None  
 E2 = Generator profile end (required)  
 Default: None  
 E3 = Director profile start (required)  
 Default: None  
 E4 = Director profile end (required)  
 Default: None

**SRF\_LOFTED[ ]**

(Lofted Surface), *command*. Creates a surface that is defined by being blended through a series of curves in an active group. {Ffm}

SRF\_LOFTED[]

**SRF\_PUNCH[ ]**

(Punch Surface), *command*. Removes a piece of an existing surface, based on the intersection of that surface with a volume defined by a punch profile and punch distance. {Ffm}

SRF\_PUNCH[OS=##, PP=##, PD=##]

OS = Element number of surfaces to edit  
 PP = Profile element (required)  
 Default: None  
 PD = Distance number, default  
 Default: 1000

**SRF RULED[ ]**

(Ruled Surface), *command*. Creates a surface that is defined by straight lines drawn between two profiles. {Ffm}

SRF\_RULED[E1=\$\$, E2=\$\$, E3=\$\$,  
 E4=\$\$]

E1 = Start element of first profile (required)  
 E2 = End element of first profile (required)  
 E3 = Start element of second profile  
 (required)  
 E4 = End element of second profile  
 (required)

**SRF\_SPLIT[ ]**

(Split Surface), *command*. Divides a surface element or group, or to create polyline curves at the intersection of two surfaces or groups. {Ffm}

**SRF\_SPLIT[ET=##, EGN=##, ES=##,  
OT=##, OGN=##, OS=##, CI=##]**

ET = Choose element or group for surfaces  
to edit.

0 = Group  
1 = Element

EGN = Group name for surfaces to edit

ES = Element number of surface to edit.

OT = Choose element or group for  
intersecting surfaces

0 = Group  
1 = Element

OGN = Group name for intersecting  
surfaces

OS = Element number of intersecting  
surface

CI = Create intersection curves

0 = Off  
1 = On:

### **SRF\_SPUN[ ]**

(Spun Surface), *command*. Creates a  
surface by rotating a 2-D generator curve  
around an axis vector line. {Ffm}

**SRF\_SPUN[E1=\$\$, E2=\$\$, E3=\$\$, AN=##]**

E1 = Generator profile start element  
(required)

Default: None

E2 = Generator profile end element  
(required)

Default: None

E3 = Axis element (required)

Default: None

AN = Revolve angle (required)

Default: None

### **SRF\_TRANSLATED[ ]**

(Translated Surface), *command*. Creates a  
surface by sweeping a 2-D generator profile  
along a 2-D or 3-D director curve. The  
generator profile maintains a perpendicular  
orientation to the tangent vector for each  
segment as it moves along the director  
curve. {Ffm}

**SRF\_TRANSLATED[E1=\$\$, E2=\$\$, E3=\$\$,  
E4=\$\$]**

E1 = Generator profile start element  
(required)

Default: None

E2 = Generator profile end element  
(required)

Default: None

E3 = Director profile start element (required)

Default: None

E4 = Director profile end element (required)

Default: None

### **START\_PROF[ ]**

(Start Prof), *command*. Identifies the start  
point of the first element in a new profile.

**START\_PROF[XE=##, YE=##, XS=##,  
YS=##, AN=##, DS=##]**

XE = X end

Default: Null

YE = Y end

Default: Null

XS = X anchor

Default: Null

YS = Y anchor

Default: Null

AN = Angle

Default: Null

DS = Distance

Default: Null

### **STEP( )**

(Step), *function*. Returns the step number of  
selected element.

-1 = when element is on layer

**STEP(elnum)**

### **STEP\_GRP[ ]**

(Step Group), *command*. Adds or removes  
the specified step to or from the active  
group.

**STEP\_GRP[ST=##, AR=##]**

ST = Step (required)

Step number

Default: None

AR = Add/remove (modal)

0 = Add

1 = Remove

### **STEP\_SEQ[ ]**

(Step Sequence), *command*. Inserts new  
elements before the first use, or after the  
last use, of an existing step.

**STEP\_SEQ[BA=##, ST=##, ME=##]**

Note: This replaces TOOL SEQUENCE in applications using Job Operations Setup.

BA = Before/after

0 = Before

1 = After

Default: 1

ME = Match element (modal)

0 = Off

1 = On:

ST = Step (required)

Valid tool number

Default: None

### STEP\_SORT[ ]

(Step Sort), *command*. Resequences a group of elements according to the steps associated with them.

STEP\_SORT[ST=##, SD=##]

ST = Step (required)

Step number, or \* for all steps

Default: None

SD = Sort domain

0 = Entire file

1 = Active group

Default: 1

### STEP\_SORT\_ALL[ ]

(Step Sort All), *command*. Resequences all the step elements in the process model according to the steps associated with them.

STEP\_SORT\_ALL[SD=##]

SD = Sort domain

0 = Entire file

1 = Active group

Default: 1

### STRAIGHT[ ]

(Straight), *command*. Creates tool path that follows a straight line across multiple surfaces. {Ffm}

STRAIGHT[AN=##, SS=##, SO=##, OA=##,  
TI=##, TO=##, PT=##, CF=##, BG=##,  
UE=##, RU=##, RD=##, EU=##,  
ED=##, PH=##, SU=##, SD=##, UU=##,  
LU=##, LN=\$\$, CU=##, CE=\$\$, CX=##,  
CY=##, FU=##, FN=\$\$, FTS=\$\$]

AN = Cut angle (required)

Default: 0.0

SS = Start side

0 = Left

1 = Right

Default: 0

SO = Stepover distance (required)

Default: 0.1

OA = Offset (finish) amount (required)

Default: 0.0

TI = In tolerance (required)

Default: 0.01

TO = Out tolerance (required)

Default: 0.01

PT = Path type

0 = Zigzag

1 = One way no plunge

2 = One way plunge

Default: 0

CF = Clear/feed

0 = Absolute

1 = Increment

2 = Straight

Default: 0

BG = Bridge gaps

0 = Straight

1 = Clear/feed

Default: 0

UE = Extras—use

0 = Off

1 = On:

Default: 0

RU = Roll edge—use

0 = Off

1 = On:

Default: 0

RD = Roll edge distance

Default: 0.125

EU = Extend—use

0 = None

1 = Start

2 = End

3 = Both

Default: 0

ED = Extend distance

Default: 0.25

PH = Cut phase

0 = As calculated

1 = Odd

2 = Even

Default: 0

SU = Super sample—use

0 = Off

1 = On:

Default: 0

SD = Super sample distance

Default: 0.1

UU = Uphill motion only

0 = Off

1 = On:

Default: 0

LU = Log file—use  
   0 = Off  
   1 = On:  
   Default: 0  
 LN = Log file name  
   Default: surfmach.log  
 CU = Containment—use  
   0 = Off  
   1 = On:  
   Default: 0  
 CE = Containment boundary profile element number  
   Default: None  
 CX = Containment cut area and start indication, X  
 CY = Containment cut area and start indication, Y  
 FU = External file—use  
   0 = Off  
   1 = On:  
   Default: 0  
 FN = External file name  
   Default: Taken from ffm.ini file  
 FTS= External file import type  
   SAT  
   SAB  
   IGES

**STREQUAL()**

(String Equal), *function*. Compares 2 string expressions.

Note: String Equal is not a recordable macro function.

**STREQUAL(strexpr1, strexpr2)**  
   0 = strings are not identical.  
   1 = strings are identical.

**STRING:**

(Declare Variable as String), *command*. Declares the variable that follows as a string type.

Note: Declare Variable as String is not a recordable macro command. A variable must be declared as a string before being assigned a text value.

STRING:variable

**STRIP\_EXT()**

(Strip Extension), *function*. Returns a truncated string without file extension.

Note: Strip Extension is not a recordable macro function.

**STRIP\_EXT(strexpr)****STRLEN()**

(String Length), *function*. Returns number of characters in a string.

Note: String Length is not a recordable macro function. Some eastern double-byte characters count as 2.

**STRLEN (strexpr)****STRSUB()**

(String Sub), *function*. Returns a substring of a string beginning at start and continuing for a specified number of characters.

Note: String Sub is not a recordable macro function. Double-byte users must be aware that they can accidentally corrupt 2-byte characters with this function.

**STRSUB (strexpr, start, len)****STRTMP()**

(String Template), *function*. Returns a string containing the combined contents of a variable along with some literal text.

Note: String Template is not a recordable macro function.

**STRTMP ("literal %VAR")**

literal = Any combination of alphanumeric characters. If the character is used as part of the STRTMP syntax (% \ " ) it must be preceded by the backslash (\ ) character in order to be output.  
 %VAR = Any string or numeric variable. The %syntax allows the variable value to be displayed in quotation marks, but only inside STRTMP.

**STX()**

(Starting Point X), *function*. Returns the X coordinate of the start point of selected element.

**STX(elnum)****STY()**

(Starting Point Y), *function*. Returns the Y coordinate of the start point of selected element.

STY(elnum)

**STZ( )**(Starting Point Z), *function*. Returns the Z coordinate of the start point of selected element.

STZ(elnum)

**SUB\_CALL[ ]**(Subroutine Call), *command*. Creates a sub call element that calls a pre-defined subroutine and want to place additional copies of it in the model. {Pmill, Amill, Ffm, Afab, Awedm}

SUB\_CALL[NN=##, CP=##, UE=##, XE=##, YE=##, ZE=##, AS=##, RR=##]

NN = Name of subroutine (required)

CP = Number of repeats to create

Default: 0

UE = Use properties of grouped elements

0 = No

1 = Yes

XE = Insert point X coordinates

YE = Insert point Y coordinates

ZE = Insert point Z coordinates

AS = Start angle

Default: 0

RR = Rotate repeats

0 = No

1 = Yes

Default: 0

**SUB\_DEFINE[ ]**(Define Subroutine), *command*. Assigns the active group of elements to a subroutine and places a related Sub Call element in the database. {Pmill, Amill, Ffm, Afab, Awedm}

SUB\_DEFINE[NN=##, CP=##, UE=##, XE=##, YE=##, ZE=##, AS=##, RR=##]

NN = Name of subroutine (required)

CP = Number of repeats to create

Default: 0

UE = Use properties of grouped elements

0 = No

1 = Yes

Default: 0

XE = Handle point X coordinate

YE = Handle point Y coordinate

ZE = Handle point Z coordinate

AS = Start angle

RR = Rotate repeats

0 = No

1 = Yes

Default: 0

**SUB\_REMOVE[ ]**(Remove Sub), *command*. Deletes a specified subroutine that has no sub call elements in the database. {Pmill, Amill, Ffm, Afab, Awedm}

SUB\_REMOVE[NN=##]

NN = Name of subroutine (required)

**SURFMODES[ ]**(Surface Modes), *command*. Use Surface Modes to control settings that SmartCAM uses for creating mesh tool path and surfaces. {Amill, Ffm}

SURFMODES[VT=##, BT=##, ZM=##, CN=##, NC=##, DS=##, DF=##, GU=##, GV=##, GT=##, RA=##, RZ=##, RF=##, SF=##, MC=##, MA=##, RD=##, IM=##]

VT = Virtual mesh tolerance (required)

Global Value

Default: .001

BT = Boundary tangent angle (required; C1 continuity)

Global Value

Default: 2

ZM = Z maxima tolerance (required)

Global Value

Default: .01

CN = Coincident normals angle (required)

Global Value

Default: 5.0

NC = Non-uniform correction

0 = Off

1 = On:

Default: 0

DS = Initial surface draw

0 = Off

1 = On:

Default: 0

DF = Final surface draw

0 = Off

1 = On:

Default: 1

GU = Display grid lines, count in U direction

(FFM)

Global value

Default: 1

GV = Display grid lines, count in V direction

(FFM)

Global value  
Default: 1  
GT = Display grid tolerance (FFM)  
Global value  
Default: 0.01  
RA = Resolution, Absolute (RESABS) (FFM)  
(required if RD is off)  
Range 1.0E-8 to 1.0E-2  
Default: 1.0E-6  
RZ = Resolution, Zero (RESNOR) (FFM)  
(required if RD is off)  
Range 1.0E-15 to RA\*0.1  
Default: 1.0E-10  
RF = Resolution, Fitting (RESFIT) (FFM)  
(required if RD is off)  
Range RA\*100 to RA\*10000  
Default: 1.0E-3  
SF = Point Set Fitting Tolerance (FFM)  
Global value  
Default: 0.001  
MC = Model Checking (level of checking)  
0 = none  
1 = Low  
2 = Medium  
3 = High  
Default: 0  
MA = Action (FFM)  
0 = None  
1 = Delete  
Default: 0  
RD = Resolution, use system defaults  
0 = Off - Use RA, RZ and RF values  
1 = On - Do not use RA and RF values;  
use system defaults instead  
IM = Incoming Model Resolution (FFM)  
0 = Off - Do not use incoming model  
header values for RESABS and RESFIT  
tolerances. Use the RA and RF values  
instead.  
1 = On - Use incoming model header  
values for RESABS and RESFIT  
tolerances. Do not use the RA and RF  
values. Incoming models are those that  
are being imported or merged into the  
active process model.  
Default: 0

**SYNCHRONIZE[ ]**

(Synchronize), *command*. Creates Start and End user command elements and resequences two turning operations from different turrets for simultaneous turning operations. {Aturn}

SYNCHRONIZE[PR=##]

PR = Primary turret # at start of synched range (required)  
0 = Turret #1  
1 = Turret #2  
Default: None

**SYSTEM\_UNITS[ ]**

(System Units), *command*. Sets the system units for new jobs and controls the display of the New Job Units dialog box when a new file is started.

SYSTEM\_UNITS[UNITSYS=##,  
ASKME=##]

UNITSYS = Unit of measurement

0 = Inch  
1 = Metric

ASKME = Ask for unit for new file.

0 = No  
1 = Yes

- T -

**TAN( )**

(Tangent), *function*. Returns the tangent of an angle.

TAN(numexp)

numexp = angle in degrees

**TAPER\_CHG[ ]**

(Taper Change), *command*. Creates an @TAPER command at the beginning of a tapered profile to be cut containing the desired wire angle value for the profile that follows. {Awedm}

TAPER\_CHG[QA=##, EL=##]

QA = Q angle (required)

Default: None

EL = Element (required)

Default: None

**TCONTOUR[ ]**

(Turn Contour), *command*. Creates centerline tool path with roughing passes that follow the shape of an existing part profile. {Pturn, Aturn}

TCONTOUR[PS=##, PE=##, MM=##,  
MS=##, ME=##, ZS=##, XS=##, DP=##,  
NP=##, LA=##, TA=##, XF=##, ZF=##,  
CD=##, LD=##, BP=##, TP=##, LY=## ]

PS = Part profile starting element  
 PE = Part profile ending element  
 MM = Material closure method  
   0 = Material profile  
   1 = Material point  
   2 = Part profile  
 MS = Material profile starting element  
 ME = Material profile ending element  
 ZS = Z ordinate of implicit material profile  
 XS = X ordinate of implicit material profile  
 DP = Pass depth  
 NP = Number of passes, when MM=2  
 LA = Effective leading edge angle  
 TA = Effective trailing edge angle  
 XF = X-axis finish amount  
 ZF = Z-axis finish amount  
 CD = Clearance distance  
 LD = Lead distance  
 BP = Bidirectional passes  
   0 = Off  
   1 = On  
 TP = Create theoretical part profile (0) off,  
   (1) on  
 LY = Theoretical part profile layer 1..99

**TDESC( )**

(Tool Description), *function*. Returns the tool description (string) for step number.

Note: Tool Description is not a recordable macro function.

TDESC(stpnum)

**TEXT[ ]**

(Text), *command*. Creates line and arc elements depicting alphanumeric characters in the model.

TEXT[FN=\$\$, TX=\$\$, XC=##, YC=##,  
   XS=##, YS=##, AN=##, RA=##, HT=##,  
   TY=##, LV=##]

FN = Filename of font file (modal)

TX = Text string (required)  
   Default: None

XC = X center  
   Default: Null

YC = Y center  
   Default: Null

XS = X start  
   Default: Null

YS = Y start  
   Default: Null

AN = Angle start  
   Default: Null

RA = Radius  
   Default: Null  
 HT = Height (required)  
   Default: None  
 TY = Type (text orientation)  
   0 = Linear  
   1 = CW  
   2 = CCW  
   Default: 2  
 LV = Level  
   Default: Null

**TGROOVE[ ]**

(Turn Groove), *command*. Creates a groove element to cut a groove with straight sides and square, chamfer, or radius corners, on the inside diameter, outside diameter, or face of a part. {Pturn, Aturn}

TGROOVE [PS=##, PE=##, MM=##,  
   MS=##, ME=##, ZS=##, XS=##, DP=##,  
   PM=##, RM=##, PD=##, LA=##, TA=##,  
   XF=##, ZF=##, CD=##, LD=##, BP=##,  
   TP=##, LY=## ]

PS = id of part profile starting element

PE = id of part profile ending element

MM = material closure method

0 = material profile  
 1 = material point  
 2 = part profile

MS = id of material profile starting element

ME = id of material profile ending element

ZS = Z ordinate of implicit material profile

XS = X ordinate of implicit material profile

DP = step over distance

PM = pecking method

0 = default  
 1 = depth first  
 2 = width first

RM = retract method

0 = full retract  
 1 = partial retract

PD = pecking depth

LA = effective leading edge angle

TA = effective trailing edge angle

XF = X-axis finish amount

ZF = Z-axis finish amount

DP = pass width

CD = clearance distance

LD = lead distance

BP = bi-directional passes

0 = off  
 1 = on

TP = create theoretical part profile

0 = off  
 1 = on

LY = theoretical part profile layer 1..99

### THREAD[ ]

(Thread), *command*. Creates a thread element for inside- or outside-diameter threads, straight or tapered threads, or scroll threads with a face-grooving tool. {Pturn, Aturn}

THREAD[ND=##, PT=##, YS=##, XS=##, YE=##, XE=##, CX=##, AN=##, AL=##, DS=##, CL=##, TL=##, FN=\$\$]

ND = Nominal diameter

Default: Null

PT = Pitch

Default: Null

YS = X root start

Default: Null

XS = Z root start

Default: Null

YE = X root end

Default: Null

XE = Z root end

Default: Null

CX = Crest X at start

Default: Null

AN = Taper angle

Default: Null

AL = Axial length

Default: Null

DS = First pass depth

Default: Null

CL = Clear

Default: Null

TL = Thread lead in

Default: Null

FN = Thread table filename

Default: Null

Note: The values required to define a Thread are Root Start and End, Crest, Clearance, Pitch, and depth of first pass. Any of these values can be calculated from other inputs as defined in interactive operations.

Note: If a thread table (FN) is not specified, the macro looks for the default thread table if a nominal diameter (ND) variable is in the option list. Both the ND and FN variables need to be removed from the command list to avoid using a thread table and ensure that the hard-coded values in the command are used as is.

Note: If a thread lookup table is specified, it writes to the fields not

specified in the Macro; changing values of entered data if need be.

### TIME\_OFF[ ]

(Time Off), *command*. Outputs the total time since the TIME\_ON command.

Note: Time Off is not a recordable macro command.

TIME\_OFF[]

### TIME\_ON[ ]

(Time On), *command*. TIME\_ON resets the "clock" and begins measuring the elapsed time from that point and outputs the information to a file.

Note: Time Off is not a recordable macro command.

TIME\_ON[FN=\$\$, TX=\$\$, AP=##, LV=##]

FN = "output\_filename"

Default: stdout, saved to user run directory

TX = "Comment" (annotation, 40 characters maximum)

Default: NULL string

AP = Append

0 = New file

1 = Append file

Default: 0

LV = What information to show

0 = Only time\_on/time\_off

1 = Every macro execution/termination

2 = Every macro command

Default: 0

### TL\_PLANE[ ]

(Tool Plane), *command*. Assigns a tool plane to an existing work plane. {Pmill, Amill, Ffm, Aturn}

TL\_PLANE[WP=\$\$, TP=\$\$]

WP = Work plane (required)

Default: None

TP = Tool plane (required)

Default: None

### TLCMT( )

(Tool Comment), *function*. Returns the tool comment (string) for step number.

Note: Tool Comment is not a recordable macro function.

TLCMT(stpnum)

**TLDIA( )**(Tool Diameter), *function*. Returns the diameter of the tool for step number.

TLDIA(stpnum)

**TLEN( )**(Tool Length), *function*. Returns the length of the tool for step number.

TLEN(stpnum)

**TLINEAR[ ]**(Turn Linear), *command*. Creates centerline tool path with straight line roughing passes that are parallel to each other and equal distances apart. {Pturn, Aturn}TLINEAR[PS=##, PE=##, MM=##, MS=##,  
ME=##, ZS=##, XS=##, DP=##, AN=##,  
FC=##, LA=##, TA=##, XF=##, ZF=##,  
CD=##, LD=##, BD=##, BP=##, OP=##,  
TP=##, LY=##]

PS = id of part profile starting element

PE = id of part profile ending element

MM = material closure method

0 = material profile

1 = material point

2 = part profile

MS = id of material profile starting element

ME = id of material profile ending element

ZS = Z ordinate of implicit material profile

XS = X ordinate of implicit material profile

DP = pass depth

AN = pass angle

FC = facing flag

0 = off

1 = on

LA = effective leading edge angle

TA = effective trailing edge angle

XF = X-axis finish amount

ZF = Z-axis finish amount

CD = clearance distance

LD = lead distance

BD = back-off distance

BP = bi-directional passes

0 = off

1 = on

OP = overlap passes

0 = off

1 = on

TP = create theoretical part profile

0 = off

1 = on

LY = theoretical part profile layer 1..99

**TLTYPE( )**(Tool Type), *function*. Returns the type number of tool for step number.

TLTYPE(stpnum)

**TMPFILE( )**(Tmp File), *function*. Returns the template file path plus .tmp file name.

TMPFILE()

**TNLIST( )**(Tool List Index), *function*. Replaced by OPNLIST( index). Returns values from the job plan tool list based on the following settings:

TNLIST(index)

index = 0 returns the number of tools in the tool list and returns a -1 if no tools exist.

index = a valid index in the tool list,

returns the tool number of that list entry.

index = greater than the total number of entries in the tool list or less than 0,

TNLIST returns a -1.

**TOOL( )**(Tool), *function*. Replaced by JTOOL( ).

Returns the tool number of selected element.

TOOL(elnum)

-1 = when element is on layer

**TOOL\_GRP[ ]**(Tool Group), *command*. Adds or removes elements associated to the specified tool to or from the active group.

TOOL\_GRP[TL=##, AR=##]

TL = Tool (required)

Default: None

AR = Add/remove (modal)

0 = Add

1 = Remove

**TOOL\_SEQ[ ]**

(Tool Sequence), *command*. Inserts new elements before the first use, or after the last use of the specified existing tool.

**TOOL\_SEQ[BA=##, TL=##, ME=##]**

Note: This replaces STEP SEQUENCE and  
JOB TOOL  
in applications not using Job Operations  
Setup.

BA = Before/after

0 = Before

1 = After

Default: 1

TL = Tool (required)

Valid tool number

Default: None

ME = Match element (modal)

0 = Off

1 = On:

**TOOL\_SORT[ ]**

(Tool Sort), *command*. Resequences a group of elements in the process model according to the tools associated with them.

**TOOL\_SORT[TL=##, SD=##]**

TL = Tool (required)

Tool number, or \* for all tools

Default: None

SD = Sort domain

0 = Entire file

1 = Active group

Default: 1

**TOOL\_SORT\_ALL[ ]**

(Tool Sort All), *command*. Resequences all the step elements in the process model according to the tools associated with them.

**TOOL\_SORT\_ALL[SD=##]**

SD = Sort domain

0 = Entire file

1 = Active group

Default: 1

**TOTEL()**

(Total Elements), *function*. Returns the number of elements in the database.

**TOTEL()**

**TPLN( )**

(Tool Plane Name), *function*. Returns the tool plane name assignment (string) of selected element.

Note: Tool Plane Name is not a recordable macro function.

**TPLN(elnum)**

**TPROFILE[ ]**

(Turning Profile), *command*. Creates centerline tool path using single or multiple passes that machine an open or closed profile with an automatic offset from the selected part profile. {Pturn, Aturn}

**TPROFILE [PS=##, PE=##, CC=##, LA=##,  
TA=##, XF=##, ZF=##, CD=##, LD=##,  
BD=##, BP=##, TP=##, LY=##]**

PS = id of part profile starting element

PE = id of part profile ending element

CC = compensation codes

0 = off

1 + on

LA = effective leading edge angle

TA = effective trailing edge angle

XF = X-axis finish amount

ZF = Z-axis finish amount

CD = clearance distance

LD = lead distance

BD = back-off distance

BP = bi-directional passes

0 = off

1 = on

TP = create theoretical part profile

0 = off

1 = on

LY = theoretical part profile layer 1..99

**TRANSLATED[ ]**

(Translated Mesh), *command*. Creates mesh profiles by sweeping a generator profile along the path of a director profile. {Amill, Ffm}

**TRANSLATED[E1=\$\$, E2=\$\$, E3=\$\$,  
E4=\$\$, PD=##, SP=##, OF=##, SV=##,  
ZT=##, OA=##, KO=##, CM=##,  
GC=##, VT=##]**

E1 = Generator profile start (required)

Default: None

E2 = Generator profile end (required)

Default: None

E3 = Director profile start (required) Default: None	1 = Right 2 = Mouse 3 = N/A Default: 3
E4 = Director profile end (required) Default: None	S2 = Second keep side (required) 0 = Left 1 = Right Default: None
PD = Path direction 0 = Generator 1 = Director 2 = Planar 3 = Both Default: 0	IN = Intersection number 1 = First intersection 2 = Second intersection 3 = Third intersection 4 = Fourth intersection Default: 1
SP = Spacing 0 = Distance 1 = Count 2 = Cusp Hgt 3 = Junction Default: 0	<b>TRIM_SURFS[ ]</b> (Trim Mesh), <i>command</i> . Trims two ranges of either tool path or layer geometry at their intersection and/or creates a profile along the points of intersection. {Amill, Ffm}
OF = Offset 0 = Positive 1 = Negative 2 = 0 Default: 2	TRIM_SURFS[E1=\$\$, E2=\$\$, S1=##, T1=##, E3=\$\$, E4=\$\$, S2=##, T2=##, CC=##, VT=##]
SV = Spacing value (required) Default: None	E1 = First surface start (required) Default: None
ZT = Planar Z Default: 0.0	E2 = First surface end (required) Default: None
OA = Finish amount Default: 0.0	S1 = Keep side surface 1 0 = Pos 1 = Neg Default: 0
KO = Keep entity type 0 = Off 1 = On: Default: 0	T1 = Trim surface 1 0 = Off 1 = On: Default: 1
CM = Connection mesh 0 = Off 1 = On: Default: 0	E3 = Second surface start (required) Default: None
GC = Gouge correction 0 = Off 1 = On: Default: 0	E4 = Second surface end (required) Default: None
VT = Virtual mesh tolerance Default: Global variable Initial default: 0.001	S2 = Keep side surface 2 0 = Pos 1 = Neg Default: 0
<b>TRIM_EXT[ ]</b> (Trim Extend), <i>command</i> . Trims and/or extends disconnected elements on the same work plane to their intersection point.	T2 = Trim surface 2 0 = Off 1 = On: Default: 1
TRIM_EXT[E1=\$\$, E2=\$\$, S1=##, S2=##, IN=##]	CC = Create intersecting curve 0 = Off 1 = On: Default: 0
E1 = First element (required) Default: None	VT = Virtual mesh tolerance Default: Global variable Initial Default: 0.001
E2 = Second element (required) Default: None	
S1 = First keep side 0 = Left	

**TRIM\_SURFS[ ]**

(Ruled Intersection), *command*. Determines the intersection between two transition pieces and creates a profile and polylines at the point of intersection on both faces.  
 {Afab}

**TRIM\_SURFS[E1=\$\$, E2=\$\$, E3=\$\$, E4=\$\$, S1=##, T1=##, S2=##, T2=##, CC=##]**

E1 = First surface start (required)  
 Default: Surface range

E2 = First surface end (required)  
 Default: Surface range

E3 = Second surface start (required)  
 Default: None

E4 = Second surface end (required)  
 Default: None

S1 = Keep side of 1st surface  
 0 = Pos  
 (always positive)

T1 = Trim first surface

0 = Off

1 = On:

Default: 1

(means build faces for first surface)

S2 = Keep side of 2nd surface  
 0 = Pos  
 (always positive)

T2 = Trim second surface

0 = Off

1 = On:

Default: 1

(means build faces for second surface)

CC = Create intersection curve

0 = Off

1 = On:

Default: 0

**TYP()**

(Type), *function*. Returns the element type number of selected element.

**TYP(elnum)**

1= Point

2= Line

3 = Arc

4 = USR

5 = Thread

7 = Ellipse

9 = Helix

10 = Polyline

12 = Cubic spline

13 = Groove

14 = Sub call

18 = Poly 5x

**- U -****UEVENT[ ]**

(User Event), *command*. Creates a user command element to output a literal CNC machine code, assign value to a template variable or call a template section at a specific sequence point in the model..

**UEVENT[XS=##, YS=##, LV=##, TX=\$\$]**

XS, YS = Start point (required)

Default: None

LV = Level

Default: None

TX = Text string (required)

Default: None

**UNDO[ ]**

(Undo), *command*. Applicable only to commands that support Undo.

**UNDO[ ]**

**UNFOLD[ ]**  
 (Unfold), *command*. Simultaneously unfolds multiple flange geometry on a 3-D model automatically evaluating the thickness of the material and other factors to ensure accurate part size. {Afab}

**UNFOLD[BE=##, BS=##, ML=##, TH=##, IR=#, KF=##, HC=##, MT=##, AD=##]**

BE = Base element (required)

Number of element in base profile

BS = Bend side

0 = Bottom

1 = Middle

2 = Top

Default: 1

ML = Mold lines

0 = No

1 = Yes

Default: 0

TH = Thickness

Default: 0

IR = Inside radius

Default: 0

KF = K factor

Default: 0

HC = Hem compensation

Default: 0

MT = Multiply

Default: 1

AD = Add  
Default: 0

**UNRES\_PLANE[ ]**

(Unreserve Plane), *command*. Removes the reserved status from a non-system reserved work plane.

UNRES\_PLANE[WP=\$\$]

WP = Work plane  
? = Wild character  
\*= Wildcard (unreserve all)

**UNWRAP[ ]**

(Unwrap), *command*. Restores wrapped geometry to its planar state. {Amill, Ffm, Aturn}

UNWRAP[WP=\$\$]

WP = Unwrap plane name (required)  
Default: None

**UPDATE[ ]**

(Update Fields), *script*. Updates the data displayed in the fields for the macro executed.

Note: Update Fields only functions while running in the macro demo mode without using the default UI scripts.

UPDATE[]

- V -

**VAR\_REMOVE[ ]**

(Variable Remove), *command*. Removes the specified user-defined macro variable from memory.

Note: Variable Remove is not a recordable macro command.

VAR\_REMOVE[VN=\$\$]

VN = Variable Name

**VAR\_REMOVE\_ALL[ ]**

(Variables Remove All), *command*. Removes all user-defined macro variables from memory.

Note: Variable Remove All is not a recordable macro command.

VAR\_REMOVE\_ALL[]

**VIEW\_ANGLE[ ]**

(View Angle), *command*. Changes the view orientation of your model for the most advantageous view.

VIEW\_ANGLE[VA=##, VP=##, A1=##, A2=##, RS=##, WP=##]

VA = Vertical axis

0 = X

1 = Y

2 = Z

Default: 0

VP = View plane

0 = World

1 = Work plane

Default: 0

A1 = Angle 1 (required)

0-2 pi (measured in radians)

Default: None

A2 = Angle 2 (required)

0-2 pi (measured in radians)

Default: None

RS = Redraw size

0 = Envelope

1 = Full

2 = Current

Default: 0

WP = Work plane

0 = XY plane

1 = YZ plane

2 = XZ plane

3 = ZX plane

Default: 0

**VIEWSURF[ ]**

(View Surf), *command*. Displays a simulation of the surface to be created by the wire with a correctly offset tool path by building a temporary ruled surface on the graphic display between the primary and secondary profiles using the links in the active group. {Awedm}

VIEWSURF[P1=##, P2=##, S1=##, S2=##]

P1 = Primary range start

Default: None

P2 = Primary range end

Default: None

S1 = Secondary range start

Default: None

S2 = Secondary range end

Default: None

**VIS( )**

(Visible), *function*. Returns the visibility status of selected element.

VIS(elnum)  
0 = Hidden  
1 = Shown

**- W -****WAIT[ ]**

(Wait), *command*. Create 2 user command elements to control the timing of the two synchronized turrets. {Aturn}

**WAIT[B1=#, E1=##, B2=#, E2=##]**

B1 = Before/after primary element (required)

0 = Before

1 = After

Default: Keep

E1 = Primary turret wait element (required)

Default: None

B2 = Before/after secondary element (required)

0 = Before

1 = After

Default: Keep

E2 = Secondary turret wait element (required)

Default: None

**WALL[ ]**

(Wall Offset), *command*. Creates parallel geometry that is offset from an existing element or a profile.

**WALL[EL=\$\$, SD=##, DS=##, ME=##, RP=##, LR=##, TA=##, TO=##, AN=##]**

EL = Element (required)

Default: None

SD = Side (required)

0 = Left

1 = Right

Default: None

DS = Distance (required)

Default: None

ME = Match element's properties

0 = No

1 = Yes

Default: 0

RP = Repeat

1–999

Default: 1

LR = Loop removal

0 = No

1 = Yes

Default: 0

TA = Tolerance application

0 = Off

1 = On:

Default: 0

TO = Tolerance amount

Default: 0.000005 [0.001]

AN = Corner roll angle

5–180

Default: 180

**WHILE( )**

(Logical While Loop), *command*. Performs a conditional test and while proven true will loop through a series of commands within a macro. Part of a command set that includes WHILE( ), ENDW.

Note: Logical While Loop is not a recordable macro command. Each WHILE command must be followed by a corresponding ENDW command within the macro.

**WHILE(expression)**

true

ENDW

expression = A logic expression that may contain the following operators

= (equal)

<> (not equal)

> (greater than)

>= (greater than or equal to)

< (less than)

<= (less than or equal to)

,AND (logical and)

,OR (logical or)

true = Macro commands to be performed if the logic expression proves true.

**WINDOW[ ]**

(Window), *command*. Magnifies part of the graphic view according to the size of the viewing window specified by two opposing corners.

**WINDOW[X1=##, Y1=##, X2=##, Y2=##]**

X1 = First box corner X (required)

Screen coordinate value

Default: None

Y1 = First box corner Y (required)

Screen coordinate value

Default: None

X2 = Second box corner X (required)  
Screen coordinate value

Default: None

Y2 = Second box corner Y (required)  
Screen coordinate value

Default: None

### WITH\_STEP[ ]

(With Step), *command*. Assigns tool and operation data to each new element, which then becomes part of the tool path.

WITH\_STEP[LV=##, WP=\$\$, ST=##,  
OF=##, CL=##, PT=##]

Note: This replaces WITH TOOL in applications using Job Operations Setup.

LV = Level (modal)

WP = Work plane (modal)

ST = Step (modal)

OF = Offset (modal)

0 = Left

1 = Right

2 = None

CL = Clear (modal)

PT = Profile top (modal)

Note: To set Clear off, set CL=? . To set Prof Top off, set PT =? .

### WITH\_TOOL[ ]

(With Tool), *command*. Assigns tool and operation data to each new element, which then becomes part of the tool path.

WITH\_TOOL[LV=##, WP=\$\$, TL=##,  
OF=##, CL=##, PT=##]

Note: This replaces WITH STEP in applications not using Job Operations Setup.

LV = Level (modal)

WP = Work plane (modal)

TL = Tool (modal)

OF = Offset (modal)

0 = Left

1 = Right

2 = None

CL = Clear (modal)

PT = Prof\_Top (modal)

Note: To set Clear off, set CL=? . To set Prof Top off, set PT =? .

### WKPLN()

(Work Plane Name), *function*. Returns the work plane name assignment (string) of selected element.

WKPLN(elnum)

### WP\_CHANGE\_NAME[ ]

(Work Plane Change Name), *command*.

Use Change Name to change the name of an existing work plane.

WP\_CHANGE\_NAME[WP=\$\$, NN=\$\$]

WP = Work plane (required)

Default: None

NN = New name (required)

Default: None

### WRAP[ ]

(Wrap), *command*. Changes the active group of elements so that they wrap around the X and/or Y axis and assigns a new work plane for rotary contouring. {Amill, Ffm, Aturn}

WRAP[XS=##, YS=##, LV=##, XE=##,  
YE=##, RA=##]

XS = Seam axis start X (required)

Default: None

YS = Seam axis start Y (required)

Default: None

LV = Level

Default: Current level

XE = Seam axis end X (required)

Default: None

YE = Seam axis end Y (required)

Default: None

RA = Radius (required)

Default: None

- X -

- Y -

- Z -

### ZOOM[ ]

(Zoom), *command*. Changes the relative size of geometry displayed in the graphic view by a magnification factor oriented at the zoom center specified.

ZOOM[X1=##, Y1=##, MF=##]

X1 = X center (required)  
Screen coordinate value  
Default: None

Y1 = Y center (required)  
Screen coordinate value  
Default: None

MF = Magnification factor  
0–999  
Default: 1.0

### Z\_SORT[ ]

(Sort By Z Level), *command*. Sorts the elements in the given range by increasing the Z elevation of their start points in the insert work plane coordinate system.

Z\_SORT[E1=##, E2=##]

E1 = Start Element  
E2 = End element

**Preface**

Introduction.....	i
Purpose .....	i
Compatibility.....	i
Disclaimer.....	i
Licenses and Trademarks.....	i
Conventions.....	ii

**- A -**

4AXPATH[ ].....	1
ABS( ).....	1
ACOS( ).....	1
ADD_LAYER[ ].....	1
ANG( ) .....	1
ARC[ ].....	1
ARC_GRP[ ].....	2
ARC_PROF[ ].....	2
AREA_CLR[ ].....	2
ASIN( ).....	3
ATAN( ).....	3
AUTO_ABORT[ ].....	3
AUTO_ANSWER[ ].....	3
AUTO_BALANCE[ ].....	3
AUT_NEST[ ].....	3

**- B -**

BASE[ ].....	4
BEGIN .....	4
BLEND[ ].....	4
BLEND_SURFS[ ] .....	4
BOUND_ALL[ ].....	5
BOUND_ONE[ ].....	5
BOX_GRP[ ] .....	5

**- C -**

CAVITY[ ].....	6
CEY( ).....	6
CEZ( ).....	6
CHAIN[ ] .....	6
CHAMF[ ].....	7
CHECK_MODEL[ ].....	7
CL_NAME_ELMT[ ].....	7
CLOSE[ ] .....	7
CLR() .....	7
CNECT_1WAY[ ].....	7
CNV_A2H[ ].....	8
CODE[ ] .....	8
CODFILE( ).....	8
COLOR_CHG[ ].....	8
CONNECT[ ].....	9
CONTOUR[ ] .....	9
CONTOUR_RGH[ ] .....	10
COONS[ ] .....	10
COORDLST[ ].....	11
COS( ) .....	11
CPX( ).....	11
CPY( ).....	11
CPZ( ) .....	11

CRE_LINK[ ] .....	11
CYLDIAM( ) .....	12

**- D -**

DLGADD[ ].....	12
DRL_DEFINE[ ] .....	12
DEF_PLANE[ ] .....	12
DELETE[ ] .....	13
DIM_RECT[ ] .....	13
DIM_TEX[ ] .....	13
DIR( ) .....	14
DISP_MODE[ ] .....	14
DMS( ) .....	14
DRAFT_SURF[ ] .....	14
DRL_CALL[ ].....	15
DUMP_GR[ ] .....	15
DUMP_LST[ ] .....	15
DYNAMIC_VIEW[ ] .....	15

**- E -**

ELLIPSE[ ] .....	16
ELMT_GRP[ ] .....	16
ELMT_SEQ[ ] .....	16
ELSE .....	16
END .....	17
ENDIF( ).....	17
ENDW.....	17
ENV_XE( ) .....	17
ENV_YE( ) .....	17
ENV_ZE( ) .....	17
ENV_XS( ) .....	17
ENV_YS( ) .....	17
ENV_ZS( ) .....	17
ENVELOPE[ ] .....	17
ENX( ) .....	18
ENY( ) .....	18
ENZ( ) .....	18
EXECUTE[ ] .....	18
EXPLODE[ ] .....	18
EXPORT[ ] .....	18
EXTEND[ ] .....	18
EXTEND_SURF[ ] .....	19
EXTRACT[ ] .....	19

**- F -**

F_CLOSE[ ] .....	19
F_EOF( ) .....	19
F_ERROR( ) .....	20
F_ERRST( ) .....	20
F_EXIST( ) .....	20
F_LINE( ) .....	20
F_OPEN[ ] .....	20
F_READ[ ] .....	20
F_WRITE[ ] .....	20
FAB_HOLE[ ] .....	21
FABRULE[ ] .....	21
FACE[ ] .....	21
FACES[ ] .....	22

FAUTOSEL[ ].....	22	JOS_ITEM_EDIT[ ].....	33
FILTER_USE[ ].....	23	JOS_CONTEXT_NEW[ ].....	33
FIXUP_51[ ].....	23	JOS_ITEM_NEW[ ].....	33
FLOWLINE[ ].....	23	JOS_CONTEXT_OPEN[ ].....	34
FOLDI[ ].....	23	JOS_CHANGES_PROMOTE[ ].....	34
FORM_PATCH[ ].....	24	JOS_STR( ).....	34
FPATH_SET[ ].....	24	JTOOL( ).....	34
FROM_MESH[ ].....	24	JTOOL_SEQ[ ].....	34
FULL[ ].....	25		
<b>- G -</b>			
GEN_MESH[ ].....	25	KILL_PLANE[ ].....	34
GET_GRP[ ].....	25		
GET_NAME( ).....	25		
GET_PATH( ).....	25		
GET_VIEW[ ].....	25		
GOTO( ).....	25		
GRAPHICS_OFF[ ].....	25		
GRAPHICS_ON[ ].....	26		
GROOVE[ ].....	26		
GROOVE_RGH[ ].....	26		
GRP( ).....	26		
GRP_BLEND[ ].....	27		
GRP_CHAIN[ ].....	27		
GRP_DELETE[ ].....	27		
GRP_FILT_ADD[ ].....	27		
GRP_FILT_REMOVE[ ].....	27		
GRP_POCK[ ].....	27		
GROUP_POLYARC_FIT[ ].....	28		
GRP_REVERSE[ ].....	28		
GRP_TRIM[ ].....	28		
GRP_WALL[ ].....	28		
<b>- H -</b>			
HELIX[ ].....	29	MAC_DEMO[ ].....	37
HILITE[ ].....	29	MAC_EXE[ ].....	38
HOLE[ ].....	29	MASK[ ].....	38
HOLE_ALL[ ].....	29	MCLFILE( ).....	38
HOLE_ONE[ ].....	30	MEAS_2D_EL( ).....	38
HOTSAVE[ ].....	30	MEAS_2D_PT( ).....	38
<b>- I -</b>			
IF( ).....	30	MEAS_3D_PT( ).....	38
IMPORT[ ].....	30	MERGE[ ].....	38
INCREMENT[ ].....	31	MERGE_PLANE[ ].....	39
INT().....	31	MIRROR[ ].....	39
INTEGER:.....	31	MO_SPLINE[ ].....	39
INTERSECT[ ].....	31	MOD_ARC[ ].....	39
INTPT[ ].....	32	MOD_DRLS[ ].....	40
<b>- J -</b>			
JOBFILE( ).....	32	MOD_ELLIPSE[ ].....	40
JOBINFO[ ].....	32	MOD_FAB_HOLE[ ].....	41
JOBPLN[ ].....	32	MOD_GROOVE[ ].....	41
JOS( ).....	32	MOD_HELIX[ ].....	42
JOS_CONTEXT_CLOSE[ ].....	32	MOD_HOLE[ ].....	42
JOS_CONTEXT_DUP[ ].....	32	MOD_LINE[ ].....	42
JOS_ITEM_DUPLICATE[ ].....	32	MOD_POINT[ ].....	43
JOS_FIELD_EDIT[ ].....	33	MOD_POLYLINE[ ].....	43
		MOD_PO5X[ ].....	43
		MOD_SUBROUTINE[ ].....	43
		MOD_THREAD[ ].....	44
		MOD_TXT[ ].....	44
		MOD_UEVENT[ ].....	44
		MOD_LINK[ ].....	45
		MOVE[ ].....	45

MOVE_REF[ ].....	45	PLNTY( ).....	54
<b>- N -</b>		PLNTZ( ).....	54
NAME_ELMT[ ].....	45	PLNNUM( ).....	54
NAME_GRP[ ].....	45	POCKET[ ].....	54
NAME_VIEW[ ].....	45	POINT[ ].....	55
NEST_MOV[ ].....	46	POINTPOLY[ ].....	55
NEST_PAR[ ].....	46	POLY5X[ ].....	55
NEST_ROT[ ].....	46	POLYLINE[ ].....	55
NEW[ ].....	46	POLYPOINT[ ].....	56
NEW_GRP[ ].....	46	POLYTHIN[ ].....	56
NEW_INCH[ ].....	46	PROF_GRP[ ].....	56
NEW_METRIC[ ].....	46	PROF_SEQ[ ].....	56
NOCORE[ ].....	47	PROF_SLICE[ ].....	56
NORMDRAW[ ].....	47	PROF_START[ ].....	56
NORMFLIP[ ].....	47	PROF_TRIM[ ].....	56
<b>- O -</b>		PROJECT[ ].....	56
OFFSET[ ].....	47	PROJECTT[ ].....	57
OFS( ).....	48	PROJECTED[ ].....	57
ON_LAYER[ ].....	48	PROMPT[ ].....	57
OPEN[ ].....	48	PROPERTY[ ].....	57
OPN_PROF[ ].....	48	PROFDIVIDE[ ].....	58
OPNLIST( ).....	49	PTCNT( ).....	58
OPTIMIZE[ ].....	49	PTOP( ).....	58
OPTYPE( ).....	49		
ORDSTP[ ].....	49	<b>- Q -</b>	
<b>- P -</b>		RAD( ).....	58
PAN[ ].....	49	RANGE_GRP[ ].....	58
PART_CURVES[ ].....	50	READ[ ].....	58
PAUSE[ ].....	50	READOUT[ ].....	58
PCHG_HP[ ].....	50	REDRAW[ ].....	58
PCHG_JHP[ ].....	50	REFINE[ ].....	59
PCHG_LY[ ].....	51	REM_LINK[ ].....	59
PCHG_SURFACES[ ].....	51	REMOVE_SYNCH[ ].....	59
PCHG_TP[ ].....	51	RENDER[ ].....	59
PCHG_ST[ ].....	51	RENDER_LOAD[ ].....	60
PCHG_WP[ ].....	52	RENDER_SAVE[ ].....	60
PECK( ).....	52	RENDER_CLOSE[ ].....	61
PLANAR[ ].....	52	REPORT_JOB[ ].....	61
PLANE_DATA[ ].....	52	REPORT_STEP[ ].....	61
PLAN_ALL_REMOVE[ ].....	52	REPORT_TOOL[ ].....	61
PLAN_ITEM_MOVE[ ].....	52	RES_PLANE[ ].....	62
PLAN_ITEM_REMOVE[ ].....	53	REV_ORDER[ ].....	62
PLAN_STEP_ORDER[ ].....	53	ROTATE[ ].....	62
PLAN_TOOL_ORDER[ ].....	53	ROUGH_SURFACES[ ].....	62
PLN( ).....	53	ROUGH_TOOLPATH[ ].....	63
PLNIX( ).....	53	RULED[ ].....	63
PLNIY( ).....	53		
PLNIZ( ).....	53	<b>- S -</b>	
PLNJX( ).....	53	SAVE[ ].....	64
PLNJV( ).....	54	SCALE[ ].....	64
PLNJP( ).....	54	SELECT[ ].....	64
PLNJZ( ).....	54	SELECT_ALL[ ].....	65
PLNKX( ).....	54	SEQ_MOVE[ ].....	65
PLNKY( ).....	54	SEQBA( ).....	65
PLNKZ( ).....	54	SEQEL( ).....	65
PLNTX( ).....	54	SGN( ).....	65

SHELL[ ] .....	65	TOOL( ).....	75
SHOW_PATH[ ].....	65	TOOL_GRP[ ].....	75
SHPFILE( ) .....	65	TOOL_SEQ[ ].....	76
SIN( ) .....	65	TOOL_SORT[ ].....	76
SMFFILE( ).....	65	TOOL_SORT_ALL[ ] .....	76
SPLINE[ ].....	66	TOTEL( ).....	76
SPLIT[ ].....	66	TPLN( ) .....	76
SPUN[ ].....	66	TPROFILE[ ] .....	76
SQR() .....	67	TRANSLATED[ ].....	76
SRF_COONS[ ].....	67	TRIM_EXT[ ].....	77
SRF_DRAFT[ ].....	67	TRIM_SURFS[ ].....	77
SRF_LOFTED[ ].....	67	TRIM_SURFS[ ].....	78
SRF_PUNCH[ ].....	67	TYP( ) .....	78
SRF RULED[ ].....	67		
SRF_SPLIT[ ].....	67		
SRF_SPUN[ ].....	68		
SRF_TRANSLATED[ ] .....	68		
START_PROF[ ].....	68	UEVENT[ ].....	78
STEP() .....	68	UNDO[ ].....	78
STEP_GRP[ ].....	68	UNFOLD[ ].....	78
STEP_SEQ[ ].....	68	UNRES_PLANE[ ] .....	79
STEP_SORT[ ].....	69	UNWRAP[ ].....	79
STEP_SORT_ALL[ ].....	69	UPDATE[ ] .....	79
STRAIGHT[ ] .....	69		
STREQUAL( ).....	70		
STRING:.....	70		
STRIP_EXT() .....	70		
STRLEN( ).....	70		
STRSUB().....	70		
STRTMP( ) .....	70		
STX( ) .....	70		
STY( ) .....	70		
STZ( ) .....	71		
SUB_CALL[ ].....	71		
SUB_DEFINE[ ].....	71		
SUB_REMOVE[ ].....	71		
SURFMODES[ ].....	71		
SYNCHRONIZE[ ] .....	72		
SYSTEM_UNITS[ ].....	72		
<b>- T -</b>			
TAN( ) .....	72		
TAPER_CHG[ ].....	72		
TCONTOUR[ ].....	72		
TDESC( ) .....	73		
TEXT[ ] .....	73		
TGROOVE[ ].....	73		
THREAD[ ] .....	74		
TIME_OFF[ ].....	74		
TIME_ON[ ].....	74		
TL_PLANE[ ].....	74		
TLCMT( ) .....	74		
TLDIA( ) .....	75		
TLEN( ) .....	75		
TLINEAR[ ] .....	75		
TLTYPE( ) .....	75		
TMPFILE( ) .....	75		
TNLIST( ).....	75		
<b>- U -</b>			
		VAR_REMOVE[ ].....	79
		VAR_REMOVE_ALL[ ] .....	79
		VIEW_ANGLE[ ] .....	79
		VIEWSURF[ ] .....	79
		VIS( ) .....	80
<b>- V -</b>			
		WAIT[ ].....	80
		WALL[ ].....	80
		WHILE( ) .....	80
		WINDOW[ ].....	80
		WITH_STEP[ ] .....	81
		WITH_TOOL[ ] .....	81
		WKPLN( ) .....	81
		WP_CHANGE_NAME[ ] .....	81
		WRAP[ ] .....	81
<b>- X -</b>			
<b>- Y -</b>			
<b>- Z -</b>			
		ZOOM[ ].....	81
		Z_SORT[ ] .....	82