

# SmartCAM 10.0 Supported Hardware and Operating System Guide

Before installing SmartCAM®, make sure that your hardware and operating system meet the minimum requirements shown in the following charts. For optimum performance, your system should satisfy the recommended configuration. If you are not sure whether a specific system configuration meets the requirements, please contact your SmartCAM dealer.

## Personal Computers

<b>Operating System</b>	Minimum: Microsoft Windows 95™ or Windows NT™ 3.51; Recommended: Windows NT 4.0
<b>Processor</b>	32-bit Intel®-based PC with math coprocessor. Minimum: 386DX; Recommended: Pentium®
<b>Physical RAM</b>	<b>Production Applications (Production Milling™, Production Turning™)</b> Minimum: 8MB; Recommended: 16MB <b>Advanced Applications (Advanced Turning™, Advanced Fabrication™, Advanced Wire EDM™)</b> Minimum: 16MB; Recommended: 32MB <b>SmartCAM Advanced 3-D Machining™, FreeForm Machining, FreeForm Machining /CAMAX Modeler Bundle</b> Minimum: 32MB; Recommended: 64MB
<b>Swap Space</b>	Minimum: 24MB; Recommended: 48MB of permanent swap space
<b>Hard Disk Space</b>	25MB for installation, plus 0.5–5MB for each process model or other data file you expect to use (for example, a .pm4, IGES™®, or ACIS® file)
<b>Video Display</b>	Minimum: SVGA, 800x600 resolution; Recommended: SVGA, 1024x768 resolution, 256 colors
<b>Mouse</b>	Any Windows-supported mouse driver
<b>Printer</b>	Any Windows-supported printer or plotter, configured through the Windows printer setup
<b>Ports</b>	A Centronics-compatible LPT port is required for the SmartCAM Hardware Lock option.
<b>Other Devices</b>	Windows-supported CD-ROM drive. A digitizer must be configured as a mouse.

## Sun® Solaris™ 2 and OpenWindows™

<b>Operating System</b>	Solaris 2.5
<b>Hardware</b>	Sun SPARCstation 2, SPARCstation 5, SPARCstation 10, or IPC
<b>Physical RAM</b>	Minimum: 32MB; Recommended: 64MB
<b>Swap Space</b>	Minimum: 50MB; Recommended: 100MB
<b>Hard Disk Space</b>	50MB for installation, plus 0.5–5MB for each process model or other data file you expect to use (for example, a .pm4 or IGES file).
<b>Mouse</b>	Sun mouse
<b>Other Devices</b>	Accessible CD-ROM drive

## Hewlett-Packard® Series 700™ Workstation

<b>Operating System</b>	HP®/UX™ 10.0, 10.01, 10.10 or 10.20
<b>Hardware</b>	HP model 710, 715/50, 715/75, 712/80
<b>Physical RAM</b>	Minimum: 32MB; Recommended: 64MB
<b>Swap Space</b>	Minimum: 50MB; Recommended: 100MB
<b>Hard Disk Space</b>	50MB for installation, plus 0.5–5MB for each process model or other data file you expect to use (for example, a .pm4 or IGES file).
<b>Mouse</b>	HP mouse
<b>Other Devices</b>	Accessible CD-ROM drive

The information contained in the SmartCAM Product/Platform Guide is not an endorsement of any workstation model or vendor. The Guide summarizes the independent observations and opinions of SDRC/CAMAX. Every effort is made to report only factual and supportable information; however, SDRC/CAMAX makes no guarantee as to the accuracy of the data or comments contained in the Guide. This information is subject to changes and should not be considered current information beyond the end of the calendar quarter it is published. All products listed are registered trademarks, trademarks and copyrights of their respective companies.